

## RETEVIS MA1 Main Board Update Operation


1. Press the "Band" button and the power button simultaneously to turn on the device and enter "Main UPDATE". Select the appropriate port.



2. Open the upgrade tool.




3. Select the corresponding file to upgrade.





## RETEVIS MA1 LCD PANEL Update Operation

1. Press the "CTRL" button and the power button simultaneously to power on the device and enter "LCD UPDATE". Select the appropriate port.



2. Open the upgrade tool.



3. Select the corresponding file to upgrade. The radio will power on again after the firmware updated successfully.

