



FT-991 SCOPE Feature Enhancement

An additional “Waterfall Display Mode” is provided that displays color differentiation between strong and weak signals.

This firmware update provides a SCOPE feature Waterfall Display setting that will present the strong and weak signals in a variation of colors.



normal waterfall display



added waterfall display with color

Referring to the following instructions, you can use the SETUP MENU to select the Spectrum display, the Waterfall display, or the new Waterfall2 display (showing signal variations in color):

1. Press the MENU(SETUP) button to enter the Menu mode.
2. Rotate the MULTI knob to select Menu item “117 SCP DISPLAY MODE”.
3. Touch [SELECT] on the LCD.
4. Rotate the MULTI knob to select “WATER FALL2”.
5. Touch the [ENTER] on the LCD to save the new setting.
6. Press the [BACK] to exit to normal operation.

By adding “WATER FALL2” on Menu item 117, the description in the FT-991 Operating Manual (page 135) is changed as follows:

117 SCP DISPLAY MODE

Function: Sets the scope for the Spectrum display, or one of the Water Fall displays.

Available Values: SPECTRUM / WATER FALL / WATER FALL2

Default Setting: SPECTRUM

Description: Select the type of display when the scope feature is active.

SPECTRUM: Enables the spectrum display.

WATER FALL: Enables the waterfall display.

WATER FALL2: Enables the waterfall display with color.