





## Service Hints

### B9 Buckle SW LH

4 (TMMK Made), 3 (TMC Made)—1 : Closed with driver's seat belt in use

### B10 Buckle SW RH

4 (TMMK Made), 2 (TMC Made)—1 : Closed with front passenger's seat belt in use

## ○ : Parts Location

Code		See Page	Code	See Page	Code	See Page
A22	A	<a href="#">42</a>	B9	<a href="#">46</a>	C5	<a href="#">42</a>
A23	B	<a href="#">42</a>	B10	<a href="#">46</a>	C7	<a href="#">42</a>

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
2K	28	Floor Wire and Driver Side J/B (Lower Finish Panel)
2M	29	Instrument Panel Wire and Driver Side J/B (Lower Finish Panel)
2N		
2R		
3A		
3B	34 (*1)	Instrument Panel Wire and Passenger Side J/B (Instrument Panel Brace RH)
	35 (*3)	
	36 (*2)	
	37 (*4)	
	34 (*1)	
	35 (*3)	
	36 (*2)	
	37 (*4)	

\* 1 : TMC Made Automatic A/C   \* 2 : TMC Made Manual A/C   \* 3 : TMMK Made Automatic A/C   \* 4 : TMMK Made Manual A/C

## □ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC1	52	Instrument Panel Wire and Floor Wire (Left Kick Panel)
IN4	54	Instrument Panel Wire and Floor No.2 Wire (Right Kick Panel)
BD1	58	Floor Wire and Front Seat LH Wire (Under the Driver's Seat)
BE1	58	Floor No.2 Wire and Front Seat RH Wire (Under the Front Passenger's Seat)

## ▽ : Ground Points

Code	See Page	Ground Points Location
II	52	Cowl Side Panel LH
BO	56	Under the Driver's Seat
BP	56	Under the Front Passenger's Seat