



INSTRUCTION MANUAL



MODEL **L-4B**
LINEAR AMPLIFIER





Figure 5-3. Connections for Grid Current Meter Calibration



POWER CONNECTOR SHOWN
FROM SOLDER CONNECTION END

42268801

Figure 5-4. Model L-4B Power Supply Schematic Diagram

