



P802 KEY BOARD




(SHOWN FROM COMPONENT SIDE)

P802 KEY BOARD




(SHOWN FROM SOLDER SIDE)
WG183B2010

P803 SPEAKER/MIC




(SHOWN FROM COMPONENT SIDE)

P803 SPEAKER/MIC




(SHOWN FROM SOLDER SIDE)
WG183B2030

P801 MIC CONTROL





(SHOWN FROM COMPONENT SIDE)

P801 MIC CONTROL



(SHOWN FROM SOLDER SIDE) WG183B2020



[D] --- C1208D
[DS] --- C1208DS
[DA] --- C1208DA

REF. DESIG.	RR30, RR31, RR32, RR33	RR34, RR35, RR36, RR37
MODEL		
CMP844	MOUNT	OPEN
CMP844A	OPEN	MOUNT

● (SOLDER SIDE PATTERN)
● (COMPONENT SIDE PATTERN)

WG183B200 P 0
C1208DA 11 < 0069 >
C1208D 16 < 0069 >
C1208DS 17 < 0069 >

