

SAMS **PHOTOFACT[®]** **CB RADIO** **SERIES**



CB-179
179
MARCH 1978




CONTENTS

TRADE NAME	MODEL	PAGE
COBRA	132XLR.....	5
PRESIDENT	Madison.....	53
ROYCE	1-673.....	101



HOWARD W. SAMS & CO., INC. Indianapolis, Indiana



PHOTOFACT[®] with

CIRCUITRACE[®]

For Supplier Address See PHOTOFACT Index

NOTE

Repair or adjustment of transmitter circuits must be under supervision of a person with first-or second-class radiotelephone license.

(Refer to FCC Rules and Regulations Part 95, Subpart C & D.)

The frequency of the transmitter should be checked periodically with a secondary frequency standard to insure proper and legal operation.

Best results will be obtained when adjusting the final RF output circuit if the antenna normally used is connected and the chassis is as nearly in the cabinet as possible.

Connect either 50-ohm dummy load or the normally used antenna system.



MODEL 132XLR

MANUFACTURER'S SPECIFICATIONS

GENERAL

Channels	40 AM, 40 LSB, 40 USB.
Frequency Range	26.965 to 27.405 MHz.
Frequency Control	Phase Lock Loop (PLL) synthesizer.
Frequency Tolerance	0.005%.
Frequency Stability	0.001%.
Operating Temperature Range	-30°C to +50°C.
Microphone	Plug-in dynamic; with push-to-talk switch and coiled cord.
Input Voltage	13.8 VDC nominal, 15.9V max., 11.7V min. (positive or negative ground).
Current Drain	<i>Transmit:</i> AM full mode., 3A; SSB, 12 watts PEP output, 2.5A. <i>Receive:</i> Squelched, 0.5A; maximum audio output, 1.5A.

TRANSMITTER

Power Output	AM, 4 watts. SSB, 12 watts, PEP.
Modulation	AM, high-and low-level Class B.
Intermodulation Distortion	SSB: 3rd order, more than -25 dB. 5th order, more than -35 dB.
SSB Carrier Suppression	More than -40 dB.
Unwanted Sideband	More than -40 dB.
Frequency Response	AM and SSB: 350 to 2500 Hz.
Output Impedance	50 ohms, unbalanced.
SSB Filter	7.8 MHz, crystal lattice type: 6 dB @ 4.2 KHz. 60 dB @ 7.0 KHz.

Output Indicators Meter shows relative RF output power; percent modulations and SWR. Transmit light glows when transmitter is in operation.

RECEIVER

Sensitivity	SSB: Less than .25 μ V for 10 dB (S+N)/N at greater than 1/2-watt of audio output. AM: Less than .5 μ V for 10 dB (S+N)/N at greater than 1/2-watt of audio output.
Selectivity	SSB and AM: 6 dB @ 3.8 KHz, 50 dB @ 10 KHz.
Cross Modulation	More than 55 dB.
Image Rejection	More than 50 dB.
IF Frequency	AM and SSB: 7.8 MHz.
Adjacent-Channel Rejection	Greater than -50 dB AM & SSB.
AM and SSB RF Gain Control	Adjustable for optimum signal reception.
Automatic Gain Control (AGC)	Less than 12 dB change in audio output for inputs from 10 to 500,000 microvolts.
Squelch	Adjustable; threshold less than .5 μ V.
Noise Blanker	RF type, effective on AM and SSB.
Voice Lock Range	AM, $\pm$ 1.5 KHz; SSB, $\pm$ 1 KHz.
Audio Output Power	4 watts into 8 ohms.
Frequency Response	350 to 2500 Hz.
Distortion	Less than 10% at 4 watts output.
Built-in Speaker	8 ohms, round.
External Speaker (Not Supplied)	8 ohms; disables internal speaker when connected.

PA SYSTEM

Power Output	4 watts into external speaker.
External Speaker for PA (Not Supplied)	8 ohms.

Courtesy of the Manufacturer

COBRA MODEL 132XLR

HOWARD W. SAMS & CO., INC. Indianapolis, Indiana 46206

© 1978 Howard W. Sams & Co., Inc. Printed in U. S. of America 8CF768

ALIGNMENT INSTRUCTIONS

CAUTION: Use isolation transformer or observe polarity when connecting test equipment.
Maintain line voltage at 120V AC. Allow a 15-minute warm-up period.

~~Adjustments made with 9-volt DC input.~~

~~Adjustments made with 12-volt DC input.~~

Adjustments made with 13.8-volt DC input.

Connect low sides of test equipment to ground unless specified otherwise.

Connect 50-ohm dummy load or antenna before keying transmitter.

Suggested Alignment Tools:

GC Electronics:

L5, L7, L301, L302, L303, T1, T2, T3, T9 thru T12, T303. 9440

L304, T4 thru T8, T301, T302..... 5009, 8728-A, 8728

L3..... 9091, 8728-A, 8728

C56, C82..... 5000, 8276

SYNTHESIZER ALIGNMENT

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Input of frequency counter to TP314. (IC302 pin 3).	Ch. 19, AM		Check for 5.120MHz.
Input of frequency counter to TP315. (Q304, emitter).	Ch. 19, AM Voice Lock Midrange	L303	Adjust for 17.0555MHz.
Input of frequency counter to TP311	Ch. 19, USB Voice Lock Midrange	R324	Adjust for 34.9875MHz.
Input of frequency counter to TP311	Ch. 19, USB Voice Lock +	R322	Adjust for 34.9885MHz.
	Ch. 19, USB Voice Lock Midrange	R324	Readjust for 34.9875MHz. Readjust R322 and R324 for a range of +1kHz while maintaining 34.9875MHz. with clarifier at midrange.
	Ch. 1, USB Voice Lock Midrange		Check for 34.7675MHz. Check all channels. (See Truth Chart for correct frequencies).
Input of frequency counter to TP311.	Ch. 19, AM Voice Lock Midrange	R328	Adjust for 34.985MHz.
	Ch. 1, AM Voice Lock Midrange		Check for 34.765MHz. Check all channels. (See Truth Chart for correct frequencies).
	Ch. 1, LSB Voice Lock Midrange		Check for 19.1625MHz. Check all channels. (See Truth Chart for correct frequencies).
Input of frequency counter and oscilloscope to TP311.	Ch. 19, AM Voice Lock Midrange	L302	Adjust for maximum at 34.985MHz.
	Ch. 19, LSB Voice Lock Midrange	L301	Adjust for maximum at 19.3825MHz.
Input of frequency counter to TP4.	Ch. 19, USB	C82	Adjust for 7.8025MHz.
Input of frequency counter and oscilloscope to TP308.	Ch. 19, LSB	T301, T302 T303	Adjust for maximum at 18.507MHz.
Input of oscilloscope to TP317.	Ch. 19, AM	L304	Adjust for MINIMUM squaring.
Input of frequency counter to TP309.	Ch. 1, AM		Check for 655kHz. Check all channels. (See Truth Chart for correct frequency).

RECEIVER ALIGNMENT

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.
Set generator output low enough to prevent AGC limiting.

AM

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to TP318. 7.8MHz, 1000Hz @ 30% modulation.	Ch. 19 AM Voice Lock at midrange RF at maximum NB/ANL Off	T6, T5, T4	Adjust for maximum output.
Output of signal generator thru .01uF to antenna jack. 27.185MHz, 1000Hz @ 30% modulation.	Ch. 19 AM Voice Lock at midrange RF at maximum NB/ANL Off	T1, T2, T3	Adjust for maximum output.

RECEIVER ALIGNMENT

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.
Set generator output low enough to prevent AGC limiting.

SSB

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to TP318. 7.8015MHz unmodulated.	Ch. 19 USB Voice Lock at midrange RF at maximum NB/ANL Off	T5, T4	Adjust for maximum output.

RECEIVER ADJUSTMENTS

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to antenna jack. 27.185MHz, 1000Hz @ 30% modulation. Output 1000uV.	Ch. 19 AM Voice Lock at midrange RF at maximum NB/ANL Off	R49	SQUELCH RANGE Set Squelch Control R51 fully clockwise. Adjust R49 so that squelch just breaks.
Output of signal generator thru .01uF to antenna jack. 27.185MHz, 1000Hz @ 30% modulation. Output 100uV.	Ch. 19 AM Voice Lock at midrange RF at maximum NB/ANL Off	R10	S METER Adjust R10 for 9 on S scale of meter.
Output of signal generator thru .01uF to antenna jack. 27.185MHz, 1000Hz @ 30% modulation. Output 1uV. Input of oscilloscope to speaker voice coil.	Ch. 19 AM Voice Lock at midrange RF at maximum NB/ANL Off	R12	RF GAIN Adjust R12 for best signal to noise ratio.

TRANSMITTER ALIGNMENT

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.
 NOTE: Be sure to check transmitter frequency and power on all active channels
 after alignment of transmitter.
 See page 4 for channel frequencies.

AM

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Input of frequency counter to antenna jack.	Ch. 19 AM	T8,T9,T10, T11,T12,L5, L7	Adjust for maximum.
	Ch. 19 AM	L3	Adjust for 4 watt maximum.
	Ch. 1 AM	R317	Adjust R317 for 26.965MHz.

TRANSMITTER ALIGNMENT

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.
 NOTE: Be sure to check transmit frequency and power on all active channels
 after alignment of transmitter.
 See page 4 for channel frequencies.


SSB

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Inject a 1000Hz, 100mV signal at MIC input.	Ch. 19 USB	T7	Adjust for maximum RF output.


TRANSMITTER ADJUSTMENTS

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.
 NOTE: Be sure to check transmitter frequency and power on all active channels
 after adjustment of transmitter.
 See page 4 for channel frequencies.

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Input of oscilloscope to antenna jack. No signal input.	Ch. 19 USB	R72,C56	CARRIER BALANCE Adjust for MINIMUM RF output.
Inject a 1000Hz, 100mV signal at MIC input.	Ch. 19 AM	R134	AM ALC Adjust for 100% modulation maximum.
Inject a 1000Hz, 100mV signal at MIC input.	Ch. 19 USB	R36,R89	SSB BIAS" Adjust for maximum.
	Ch. 19 AM MOD/RF RF	R9	RF PANEL METER Adjust R9 so that RF panel meter agrees with RF wattmeter.
Inject a 1000Hz, 100mV signal at MIC input.	Ch. 19 USB	R130	SSB ALC Adjust for R130 for 12 watts maximum.
Input of modulation meter or oscilloscope to antenna jack. Inject a 1000Hz signal at MIC input.	Ch. 19 AM MOD/RF MOD	R93	MOD METER Adjust R93 so that MOD panel meter agrees with external modulation meter.



CHASSIS - BOTTOM



MAIN BOARD



CHASSIS - BOTTOM


TRUTH CHART

1 = <u>6.92</u> Volts 0 = <u>0</u> Volts											
C H A N N E L	IC 304 PROGRAM DIVIDER							AM REC & XMT VCO OUTPUT IN MHz AT TP311	USB REC & XMT VCO OUTPUT IN MHz AT TP311	LSB REC & XMT VCO OUTPUT IN MHz AT TP311	AM(REC&XMT) LSB (REC & XMT) USB (REC & XMT) VCM OUTPUT IN MHz AT TP309
	PINS										
	8	7	6	5	4	3	2				
1	1	0	0	0	0	0	1	34.765	34.7675	19.1625	.655
2	1	0	0	0	0	1	0	34.775	34.7775	19.1725	.665
3	1	0	0	0	0	1	1	34.785	34.7875	19.1825	.675
4	1	0	0	0	1	0	1	34.805	34.8075	19.2025	.695
5	1	0	0	0	1	1	0	34.815	34.8175	19.2125	.705
6	1	0	0	0	1	1	1	34.825	34.8275	19.2225	.715
7	1	0	0	1	0	0	0	34.835	34.8375	19.2325	.725
8	1	0	0	1	0	1	0	34.855	34.8575	19.2525	.745
9	1	0	0	1	0	1	1	34.865	34.8675	19.2625	.755
10	1	0	0	1	1	0	0	34.875	34.8775	19.2725	.765
11	1	0	0	1	1	0	1	34.885	34.8875	19.2825	.775
12	1	0	0	1	1	1	1	34.905	34.9075	19.3025	.795
13	1	0	1	0	0	0	0	34.915	34.9175	19.3125	.805
14	1	0	1	0	0	0	1	34.925	34.9275	19.3225	.815
15	1	0	1	0	0	1	0	34.935	34.9375	19.3325	.825
16	1	0	1	0	1	0	0	34.955	34.9575	19.3525	.845
17	1	0	1	0	1	0	1	34.965	34.9675	19.3625	.855
18	1	0	1	0	1	1	0	34.975	34.9775	19.3725	.865
19	1	0	1	0	1	1	1	34.985	34.9875	19.3825	.875
20	1	0	1	1	0	0	1	35.005	35.0075	19.4025	.895


TRUTH CHART

1 = <u>6.92</u> Volts 0 = <u>0</u> Volts											
C H A N N E L	IC 304 PROGRAM DIVIDER							AM REC & XMT VCO OUTPUT IN MHz AT TP311	USB REC & XMT VCO OUTPUT IN MHz AT TP311	LSB REC & XMT VCO OUTPUT IN MHz AT TP311	AM(REC&XMT) LSB (REC & XMT) USB (REC & XMT) VCM OUTPUT IN MHz AT TP309
	PINS										
	8	7	6	5	4	3	2				
21	1	0	1	1	0	1	0	35.015	35.0175	19.4125	.905
22	1	0	1	1	0	1	1	35.025	35.0275	19.4225	.915
23	1	0	1	1	1	1	0	35.055	35.0575	19.4525	.945
24	1	0	1	1	1	0	0	35.035	35.0375	19.4325	.925
25	1	0	1	1	1	0	1	35.045	35.0475	19.4425	.935
26	1	0	1	1	1	1	1	35.065	35.0675	19.4625	.955
27	1	1	0	0	0	0	0	35.075	35.0775	19.4725	.965
28	1	1	0	0	0	0	1	35.085	35.0875	19.4825	.975
29	1	1	0	0	0	1	0	35.095	35.0975	19.4925	.985
30	1	1	0	0	0	1	1	35.105	35.1075	19.5025	.995
31	1	1	0	0	1	0	0	35.115	35.1175	19.5125	1.005
32	1	1	0	0	1	0	1	35.125	35.1275	19.5225	1.015
33	1	1	0	0	1	1	0	35.135	35.1375	19.5325	1.025
34	1	1	0	0	1	1	1	35.145	35.1475	19.5425	1.035
35	1	1	0	1	0	0	0	35.155	35.1575	19.5525	1.045
36	1	1	0	1	0	0	1	35.165	35.1675	19.5625	1.055
37	1	1	0	1	0	1	0	35.175	35.1775	19.5725	1.065
38	1	1	0	1	0	1	1	35.185	35.1875	19.5825	1.075
39	1	1	0	1	1	0	0	35.195	35.1975	19.5925	1.085
40	1	1	0	1	1	0	1	35.205	35.2075	19.6025	1.095


COBRA MODEL 132XLR




MAIN BOARD



MAIN BOARD




MAIN BOARD




COBRA MODEL 132X1R

MAIN BOARD




MAIN BOARD




COBRA MODEL 132XLR

MAIN BOARD




MAIN BOARD







MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD



MAIN BOARD





MAIN BOARD




* Located on bottom of board

CONTROL BOARD







CH. SELECTOR BOARD



CH. SELECTOR BOARD






Ident

B C E

Q27

Front view



* Circuitry not used in some versions

--- Circuitry used in some versions

⊗ See parts list

⊕ Nominal value

⊥ Ground

⏏ Chassis

▽ Common tie point

A PHOTOFACT STANDARD NOTATION SCHEMATIC

WITH **CIRCUITRACE**®

© Howard W. Sams & Co., Inc. 1978

Measurements made in Channel 1 with switching as shown unless noted. Item numbers in rectangles appear in the alignment/adjustment instructions.


Supply voltage maintained as shown at input. Voltages measured with digital meter, no signal. Controls adjusted for normal operation.



Arrow at control indicates direction of advance.


Terminal identification may not be found on unit.


Resistors are 1/2W or less, 5% unless noted.

Value in () used in some versions.









PARTS LIST AND DESCRIPTION

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA									
			GENERAL ELECTRIC PART No.	MALLORY PART No.	MOTOROLA PART No.	RAYTHEON PART No.	RCA PART No.	SPRAGUE PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
CD1	1N60	150-001-9-005	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
CD2	1N60	150-001-9-005	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
CD3	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD4	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD5	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD6	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD7	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD8	1N60	150-001-9-005	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD9	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD10	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD11	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD13	1N60	150-001-9-005	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
CD14	1N60	150-001-9-005	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
CD15	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD16			GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD18			GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD19	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD20	1N60	157-007-9-001	1N60(7)	PTC206M(6)	HEPR9135(7)	RE 86(6)	SK3088(7)	RT-263(7)	ECG110(6)	1N60(7)	WEP134(7)	ZEN-430(7)
CD21	1N60	157-007-9-001	1N60(7)	PTC206M(6)	HEPR9135(7)	RE 86(6)	SK3088(7)	RT-263(7)	ECG110(6)	1N60(7)	WEP134(7)	ZEN-430(7)
CD22	1N60	157-007-9-001	1N60(7)	PTC206M(6)	HEPR9135(7)	RE 86(6)	SK3088(7)	RT-263(7)	ECG110(6)	1N60(7)	WEP134(7)	ZEN-430(7)
CD23	1N60	157-007-9-001	1N60(7)	PTC206M(6)	HEPR9135(7)	RE 86(6)	SK3088(7)	RT-263(7)	ECG110(6)	1N60(7)	WEP134(7)	ZEN-430(7)
CD24	1S1885	151-030-9-005	GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
CD25	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD26	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD27	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD28	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD29	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD30	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD31	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD34	1S1885	151-030-9-005	GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
CD35	1S1885	151-030-9-005	GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
CD36	1S1885	151-030-9-005	GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
CD37	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD39	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD40	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD41	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD42	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD43	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD44	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD45	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD46	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD47	0226.2A	152-047-9-001	GEZD-6.2	ZM6.2A	HEPZ0214A	RE 109	SK3058	RT-237	ECG5013	1N4735A	WEP1414	ZEN-500
CD48	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD49	1S1885	151-030-9-005	GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
CD50a	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD50b	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD50c	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD51	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD52	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD33	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD54	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD55	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD56	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD57	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD58	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD60	1S1885	151-030-9-005	GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
CD61	1S1885	151-030-9-005	GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
CD62	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD63	1S1885	151-030-9-005	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177		WEP1062	
	1S1555		GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177		WEP1062	
CD64	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD301	1S2789				HEPR2502	RE 52	SK3100	RT-218	ECG612			ZEN-452
CD302	1S2789				HEPR2502	RE 52	SK3100	RT-218	ECG612			ZEN-452
CD303	0226.2A	152-047-9-001	GEZD-6.2	ZM6.2A	HEPZ0214A	RE 109	SK3058	RT-237	ECG5013	1N4735A	WEP1414	ZEN-500
CD308	0226.2A	152-047-9-001	GEZD-6.2	ZM6.2A	HEPZ0214A	RE 109	SK3058	RT-237	ECG5013	1N4735A	WEP1414	ZEN-500
CD304	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD305	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD306	1S1658	151-030-9-003	GE-300	PTC214	HEPR2503	RE 52	SK3100	RT-262	ECG614		WEP200	ZEN-453
CD307	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD308	0226.2A	152-047-9-001	GEZD-6.2	ZM6.2A	HEPZ0214A	RE 109	SK3058	RT-237	ECG5013	1N4735A	WEP1414	ZEN-500
CD309	0226.2A	152-047-9-001	GEZD-6.2	ZM6.2A	HEPZ0214A	RE 109	SK3058	RT-237	ECG5013	1N4735A	WEP1414	ZEN-500
CD310	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	
CD312	1S1588	151-051-9-001	GE-514	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG519	1N4148	WEP925	

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results) (cont)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA									
			GENERAL ELECTRIC PART No.	MALLORY PART No.	MOTOROLA PART No.	RAYTHEON PART No.	RCA PART No.	SPRAGUE PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
Q7	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q8	2SC372	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q9a	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q9b	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q10	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q11	2SC1166-Y	176-056-9-005	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC1166		GE-81*	PTC143	2SC1166	RE 210	SK3122	RT-141	ECG297	2SC1166	WEP914	
Q12	2SC1173	172-026-9-001	GE-215	PTC186	2SC1173	RE 201	SK3197	RT-160	ECG236	2SC1173	WEP840	
Q13	2SC1678	172-028-9-001	GE-322	PTC186		RE 203	SK3197	RT-146	ECG235	2SC1306		
Q14	2SC1173	172-026-9-001	GE-268	PTC123*	2SC1213	RE 17*	SK3024*	RT-134	ECG289		WEP910	121-1014
Q15	2SC1307	176-044-9-001(12)	GE-216	PTC186		RE 201	SK3197	RT-158	ECG236		WEP840	
Q16	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q17	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q18	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q19	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q20	2SC732BL	176-056-9-006	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC732		GE-62	PTC139*	2SC732	RE 192	SK3122	RT-302	ECG199	2SC732	WEP66	ZEN-128
Q21	2SC372Y	177-019-9-003	GE-62	PTC139*	2SC732	RE 192	SK3122	RT-302	ECG199	2SC732	WEP66	ZEN-128
	2SC372		GE-221*	PTC103*	2SC732	RE 192	SK3122	RT-302	ECG199	2SC732	WEP66	ZEN-128
Q22	2SC372Y	177-019-9-003	GE-221*	PTC103*	2SC732	RE 192	SK3122	RT-302	ECG199	2SC732	WEP66	ZEN-128
	2SC372		GE-221*	PTC103*	2SC732	RE 192	SK3122	RT-302	ECG199	2SC732	WEP66	ZEN-128
Q23	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q24	2SC372Y	177-032-9-001	GE-244	PTC144	HEPS3032	RE 18	SK3025	RT-115	ECG129		WEP242	
	2SC372		GE-244	PTC144	HEPS3032	RE 18	SK3025	RT-115	ECG129		WEP242	
Q25	2SC372Y	177-032-9-001	GE-244	PTC144	HEPS3032	RE 18	SK3025	RT-115	ECG129		WEP242	
	2SC372		GE-244	PTC144	HEPS3032	RE 18	SK3025	RT-115	ECG129		WEP242	
Q27	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q301	2SK19-GR	182-029-9-001	GE-FET-2	PTC161	HEPF0021	RE 45	SK3116	RT-175	ECG312		WEP920	ZEN-123
	2SK19		GE-FET-2	PTC161	HEPF0021	RE 45	SK3116	RT-175	ECG312		WEP920	ZEN-123
Q302	2SC19GR	182-029-9-001	GE-FET-2	PTC161	HEPF0021	RE 45	SK3116	RT-175	ECG312		WEP920	ZEN-123
	2SK19		GE-FET-2	PTC161	HEPF0021	RE 45	SK3116	RT-175	ECG312		WEP920	ZEN-123
Q303	2SC19GR	182-029-9-001	GE-FET-2	PTC161	HEPF0021	RE 45	SK3116	RT-175	ECG312		WEP920	ZEN-123
	2SK19		GE-FET-2	PTC161	HEPF0021	RE 45	SK3116	RT-175	ECG312		WEP920	ZEN-123
Q304	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q305	2SC387A	176-044-9-003	GE-214	PTC132*	HEPS0020*	RE 10*	SK3039*	RT-134	ECG108*	2SC717*	WEP56*	ZEN-104
	2SC387		GE-214	PTC132*	HEPS0020*	RE 10*	SK3039*	RT-134	ECG108*	2SC717*	WEP56*	ZEN-104
Q306	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q307	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q308	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q309	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q310	2SC387A	176-044-9-003	GE-214	PTC132*	HEPS0020*	RE 10*	SK3039*	RT-134	ECG108*	2SC717*	WEP56*	ZEN-104
	2SC387		GE-214	PTC132*	HEPS0020*	RE 10*	SK3039*	RT-134	ECG108*	2SC717*	WEP56*	ZEN-104
Q311	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q312	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q314	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q315	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q316	2SC372Y	176-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q317	2SC372Y	172-042-9-003	GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
Q318	2SD235-0	172-031-9-003	GE-66	PTC121*	2SD235	RE 21	SK3054	RT-197	ECG152	2SD235	WEP745	
	2SD235T		GE-66	PTC121*	2SD235	RE 21	SK3054	RT-197	ECG152	2SD235	WEP745	

(6) Matched pair.

(7) Two required - select matched pair.

* Lead configuration may vary from original.

(12) 25 WATTS @ 8 AMPS.

ELECTROLYTIC CAPACITORS

ITEM No.	RATING	REPLACEMENT DATA				
		MFR. PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C16	.33 35V	022-074-9-005	PC30-25	TDC334M050EL	QDT1-14	SD50-R339
C30	33 16V	027-076-9-002	PC5-50	VTT33025	QV1-63	EV-1325
C33	3.3 50V	027-076-9-002	PC5-50	VTT33025	QV1-25	EV-1618
C35	3.3 50V	027-076-9-002	PC5-50	VTT33025	QV1-25	EV-1618
C36	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C41	1 50V	022-076-9-001	PC1-50	VTT1A50	QV1-11	EV-1615
C46	1 50V	022-076-9-001	PC1-50	VTT1A50	QV1-11	EV-1615
C47	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C53	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

ELECTROLYTIC CAPACITORS (cont)

ITEM No.	RATING	REPLACEMENT DATA				
		MFR. PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C68	1 50V		PC1-50	VTT1A50	QV1-11	EV-1615
C77	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C83b	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C90	1 50V	022-076-9-001	PC1-50	VTT1A50	QV1-11	EV-1615
C92	1 50V	022-076-9-001	PC1-50	VTT1A50	QV1-11	EV-1615
C93	3.3 50V	027-076-9-002	PC5-50	VTT3R3A50	QV1-25	EV-1618
C94	10 16V		WBR10-25	TT15X10	QE1-177	TVA-1145
C98	33 16V	022-074-9-005	PC30-25	VTT33D25	QV1-63	EV-1325
C104	3.3 16V	027-020-9-001		TDC335M035FL		SD35-3R39
C108	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C109	33 16V	022-074-9-005	PC30-25	VTT33D25	QV1-63	EV-1325
C113	1000 25V	022-150-9-002	WBR1000-25	VTT1000M25	QV1-185	EV-1360
C114	1 50V	022-076-9-001	PC1-50	VTT1A50	QV1-11	EV-1615
C117	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C122	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C123	100 10V	022-074-9-010	PC100-10	VTT100E10	QV1-93	EV-1130
C124	1000 16V	022-150-9-003	PC1000-16	VTT1000L16	QV1-183	EV-1260
C125	1000 16V	022-150-9-003	PC1000-16	VTT1000L16	QV1-183	EV-1260
C127	1 50V	022-076-9-001	PC1-50	VTT1A50	QV1-11	EV-1615
C128	1 50V	022-076-9-001	PC1-50	VTT1A50	QV1-11	EV-1615
C130	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C152	10 16V		PC10-25	VTT10B25	QV1-41	EV-1222
C165	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C200	1 50V	022-076-9-001	PC1-50	VTT1A50	QV1-11	EV-1615
C201	100 16V		PC100-16	VTT100F16	QV1-95	EV-1230
C301	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C306	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C338	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C339a	3.3 16V	027-020-9-001		TDC335M035FL		SD35-3R39
C339b	3.3 16V	027-020-9-001		TDC335M035FL		SD35-3R39
C343	100 10V	022-074-9-010	PC100-10	VTT100E10	QV1-93	EV-1130
C345	.22 35V			TDC224M050EL	QDT1-10	SD50-R229
C350	220 10V	022-076-9-010	PC250-10	VTT220F10	QV1-115	EV-1140
C357	10 16V		PC10-25	VTT10B25	QV1-41	EV-1222
C361	10 16V	022-076-9-003	PC10-25	VTT10B25	QV1-41	EV-1222
C365	.22	027-028-9-001				

COBRA MODEL 132XLR

CAPACITORS

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA			
			CENTRALAB PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.
						Q-LINE GENERAL LINE
C1	.0022				GP222	10TS-022
C2	.470		DD-471	GP470	GP347	10TS-T47
C3	.470		DD-471	GP470	GP347	10TS-T47
C4	.0022				GP222	10TS-022
C5	100		DTZ-100	NP0100	CN0310	10TCC-T10
C6	220 5%		DTZ-220			10TCC-T22
C7	330 5%		DD-331	GP330	GP333	10TS-T33
C8	220 5%		DTZ-220			10TCC-T22
C9	10		DTZ-10	NP010	CN0410	10TCC-010
C10	.0022				GP222	10TS-022
C11	.033	025-060-9-003			*	1FT-S33
C12	22 H220	020-157-9-002				10TCR-Q22
C13	22		DTZ-22	NP022	CN0422	10TCC-Q22
C14	33		DTZ-33	NP033	CN0433	10TCC-033
C15	.0022				GP222	10TS-022
C17	.0022				GP222	10TS-022
C18	1				CN0510	10TCC-V10
C19	.0022				GP222	10TS-022
C20	.0022				GP222	10TS-022
C21	.470		DD-471	GP470	GP347	10TS-T47
C22	.0047		DD-472	GP4700	GP247	5GA-D47
C23	.0047		DD-472	GP4700	GP247	5GA-D47
C24	.0047		DD-472	GP4700	GP247	5GA-D47
C25	.01	025-060-9-001				1FT-S10
C26	.01	025-060-9-001				1FT-S10
C27	.0047		DD-472	GP4700	GP247	5GA-D47
C28	.0047		DD-472	GP4700	GP247	5GA-D47
C29	.0047		DD-472	GP4700	GP247	5GA-D47
C31	.01 50V	025-060-9-001				1FT-S10
C32	.0047		DD-472	GP4700	GP247	5GA-D47
C34	.01	025-060-9-001				1FT-S10
C37	.0047		DD-472	GP4700	GP247	5GA-D47
C39	22		DTZ-22	NP022	CN0422	10TCC-022
C40	.1 25V	033-017-9-001				
C44	3 NPO		DTZ-3R3	NP03P3	CN0533	10TCC-V33

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA				
			CENTRALAB PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
						Q-LINE	GENERAL LINE
C45	5		DTZ-4R7	NP04P7	CN0547		10TCC-V47
C48	.01 50V	025-060-9-001				QFT2-91	1FT-S10
C49	.01 50V	025-060-9-001				QFT2-91	1FT-S10
C50	.0022				GP222		10TS-D22
C51	.0047		DD-472	GP4700	GP247		5GA-D47
C52	.01	025-060-9-001				QFT2-91	1FT-S10
C54	.0022				GP222		10TS-D22
C55	.0047		DD-472	GP4700	GP247		5GA-D47
C56	20	028-026-9-001			*		10TCT-Q10
C57	10 N470	020-170-9-001					10TCC-V33
C58	3		DTZ-3R3	NP03P3	CN0533		10TS-T47
C59	470		DD-471	GP470	GP347		5GA-D47
C60	.0047		DD-472	GP4700	GP247		5GA-D47
C61	.0047		DD-472	GP4700	GP247		10TS-T47
C62	2		DD-471	GP470	GP347		10TCC-V10
C63	1				CN0510		10TCC-V10
C64	1				CN0510		10TS-T47
C65	470		DD-471	GP470	GP347		5GA-D47
C66	.0047		DD-472	GP4700	GP247		5GA-D47
C67	.0047		DD-472	GP4700	GP247		10TCC-T10
C69	100		DTZ-100	NP0100	CN0310		5GA-D47
C70	.0047		DD-472	GP4700	GP247		1FT-S33
C71	.033 50V	025-060-9-003				QFT2-149	10TS-T33
C72	330		DD-331	GP330	GP333		5GA-D47
C73	.0047		DD-472	GP4700	GP247		1FT-S33
C74	.033	025-060-9-003				QFT2-91	5GA-D47
C75	.0047		DD-472	GP4700	GP247		10TCC-T10
C76	100		DTZ-100	NP0100	CN0310		5GA-D47
C78	.0047		DD-472	GP4700	GP247		10TS-T33
C79	330 5%		DD-331	GP330	GP333		5GA-D47
C81	.0047		DD-472	GP4700	GP247		10TCR-Q25
C82	20	028-026-9-001			*		10TCC-T15
C83	22 N220	020-157-9-002					10TCC-T10
C84	150		DTZ-150		CN0315		10TCC-Q10
C85	100		DTZ-100	NP0100	CN0310		5GA-D47
C86	10		DTZ-10	NP010	CN0410		10TS-D22
C87	.0047		DD-472	GP4700	GP247		1FT-S33
C88	.0022				GP222		5GA-D47
C89	.033 50V	025-060-9-003				QFT2-149	5GA-D47
C91	.0047		DD-472	GP4700	GP247		5GA-D47
C95	.0047		DD-472	GP4700	GP247		5GA-D47
C96	.0047		DD-472	GP4700	GP247		5GA-D47
C97	.0047 10%		DD-472	GP4700	GP247		5GA-D47
C99	.0047		DD-472	GP4700	GP247		5GA-D47
C100	.01 50V	025-060-9-001				QFT2-91	1FT-S10
C101	.01 50V	025-060-9-001				QFT2-91	1FT-S10
C102	.022	025-071-9-002				QFT2-127	1FT-S22
C103	.0047		DD-472	GP4700	GP247		5GA-D47
C105	100		DTZ-100	NP0100	CN0310		10TCC-T10
C106	.1		CK-104		MAG5001		
C107	.1		CK-104		MAG5001		
C110	100		DTZ-100	NP0100	CN0310		10TCC-T10
C111	.1		CK-104		MAG5001		
C112	.0047		DD-472	GP4700	GP247		5GA-D47
C115	.1		CK-104		MAG5001		
C116	.0047		DD-472	GP4700	GP247		5GA-D47
C118	.01 50V	025-060-9-001				QFT2-91	1FT-S10
C119	470		DD-471	GP470	GP347		10TS-T47
C120	.0047		DD-472	GP4700	GP247		5GA-D47
C121	.033 50V	025-060-9-003				QFT2-149	1FT-S33
C126	.0047		DD-472	GP4700	GP247		5GA-D47
C131a	.0047		DD-472	GP4700	GP247		5GA-D47
C131b	.0047		DD-472	GP4700	GP247		5GA-D47
C132	.0047		DD-472	GP4700	GP247		5GA-D47
C133	.0047		DD-472	GP4700	GP247		5GA-D47
C135	.0047		DD-472	GP4700	GP247		5GA-D47
C136	.0047		DD-472	GP4700	GP247		5GA-D47
C137	.0047		DD-472	GP4700	GP247		5GA-D47
C138	.0047		DD-472	GP4700	GP247		5GA-D47
C139	.0047		DD-472	GP4700	GP247		5GA-D47
C140	.0047		DD-472	GP4700	GP247		5GA-D47
C141	100		DTZ-100	NP0100	CN0310		10TCC-T10
C142	100		DTZ-100	NP0100	CN0310		10TCC-T10
C143	.0047		DD-472	GP4700	GP247		5GA-D47
C144	.0047	020-C88-9-008					
C145	.0047	020-088-9-008					

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFG. PART No.	REPLACEMENT DATA				
			CENTRALAB PART No.	CORNELL DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
						Q-LINE	GENERAL LINE
C147	.0047	020-088-9-008			GP222		10TS-D22
C151	.0022				GP247		5GA-D47
C153	.0047		DD-472	GP4700	GP247		5GA-D47
C154	.0047		DD-472	GP4700	GP247		5GA-D47
C155	.033		UK50-333		MAG50133		
C157	.033 50V	025-060-9-003					
C158	.0047		DD-472	GP4700	GP247		5GA-D47
C159	.0047		DD-472	GP4700	GP247		5GA-D47
C160	.0047		DD-472	GP4700	GP247		5GA-D47
C163	.0047		DD-472	GP4700	GP247		5GA-D47
C164	.033	025-060-9-003			GP247		5GA-D47
C166	.033 50V					QFT2-149	1FT-S33
C167	.0047		DD-472	GP4700	GP247	QFT2-149	1FT-S33
C168	.01		UK50-103		MAG5011		5GA-D47
C169	.0047	020-088-9-008					
C173	.0047	020-088-9-008	DD-472	GP4700	GP247		5GA-D47
C174	.0047	020-088-9-008	DD-472	GP4700	GP247		5GA-D47
C175	.0047	020-088-9-008				QFT2-63	1FT-D47
C176	.0047						
C177	.033						
C180	.0047	020-088-9-008					
C182	470	020-097-9-022					
C185	.0047	020-088-9-008	DD-472	GP4700	GP247		5GA-D47
C186	.0047		DD-472	GP4700	GP247		5GA-D47
C187	.0047		DD-472	GP4700	GP247		5GA-D47
C195	.0047						
C196	.0047		DD-472	GP4700	GP247		5GA-D47
C197	.0047	020-088-9-008	DD-472	GP4700	GP247		5GA-D47
C199	.0047		DD-472	GP4700	GP247		5GA-D47
C302	15 N220		DD-472	GP4700	GP247		5GA-D47
C303	10 N750			N10	CN7410		10TCR-Q15
C304	22 N750			N22	CN7422		10TCU-Q10
C305	2	020-076-9-003	DTZ-2R2	NP02P2	CN0522		10TCU-Q22
C307	1				CN0510		10TCC-V22
C308	10 N220				*		10TCC-V10
C309	33 N750			N33			10TCR-Q10
C310	100 N750			N100			10TCU-Q33
C311	10	025-060-9-003	DTZ-10	NP010	CN0410		10TCU-T10
C314	.033					QFT2-149	10TCC-Q10
C315	.0047						1FT-S33
C316	.0047						
C318	47 N220		DD-472	GP4700	GP247		5GA-D47
C319	.0047	020-088-9-002	DD-472	GP4700	GP247		10TCR-Q47
C320	47 N220	020-088-9-002			GP247		5GA-D47
C321	47 N220				*		10TCR-Q47
C322	10		DTZ-10	NP010	CN0410		10TCR-Q47
C323	.0047		DD-472	GP4700	GP247		10TCC-Q10
C324	47		DTZ-47	NP047	CN0447		5GA-D47
C325	.0022	025-060-9-004			GP222		10TCC-Q47
C326	220		DTZ-220				10TS-D22
C327	.1					QFT2-215	10TCC-T22
C328	22		DTZ-22	NP022	CN0422		1FT-P10
C329	10		DTZ-10	NP010	CN0410		10TCC-Q22
C330	.0047	020-088-9-002	DD-472	GP4700	GP247		10TCC-Q10
C331	2		DTZ-2R2	NP02P2	CN0522		5GA-D47
C332	.0022				GP222		10TCC-V22
C333	.0047		DD-472	GP4700	GP247		10TS-D22
C334	220		DTZ-220				5GA-D47
C335	47 N220	020-088-9-002			*		10TCC-T22
C336	47 N220	020-088-9-002			*		10TCR-Q47
C337	.033	020-060-9-003				QFT2-149	1FTCR-Q47
C340	10	025-060-9-004	DTZ-10	NP010	CN0410		1FT-S33
C344a	.033					QFT2-149	10TCC-Q10
C344b	.033 50V						1FT-S33
C346	.001					QFT2-1	1FT-D10
C349	470		DD-471	GP470	GP347		10TS-T47
C351	22	025-060-9-004	DTZ-22	NP022	CN0422		10TCC-Q22
C353	.033 50V					QFT2-149	1FT-S33
C354							
C359	.0047		DD-472	GP4700	GP247		5GA-D47
C360	.0047		DD-472	GP4700	GP247		5GA-D47
C363	.0022	025-060-9-004			GP222		10TS-D22
C366	470		DD-471	GP470	GP347		10TS-T47
C367	470		DD-471	GP470	GP347		10TS-T47
C368	470		DD-471	GP470	GP347		10TS-T47

* Not normally in distributor's stock. Available thru distributor on order to manufacturer.

COBRA MODEL 132XLR

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CONTROLS (All wattages 1/2 watt, or less, unless listed)

ITEM No.	FUNCTION	RESIST-ANCE	REPLACEMENT DATA				
			MFGR. PART No.	CENTRALAB PART No.	CLAROSTAT PART No.	MALLORY PART No.	TRW PART No.
R8	SWR/CAL	20K	008-300-9-001 (18)				
R90	RF Gain	5000					
R9	RF Meter	10K	008-206-9-008				U260R103B
R10	S Meter	10K	008-206-9-008				U260R103B
R12	RF Gain	10K	008-206-9-008				U260R103B
R49	Squelch Range	10K	008-206-9-008				U260R103B
R51	Squelch	20K	008-300-9-002				
R72	Carrier Balance	5000	008-206-9-005				U260R502B
R86	Bias	100	008-206-9-004				
R89	Bias	100	008-206-9-004				
R93	MOD Meter	100K	002-104-5-104				U260R105B
R120	Volume/Switch	50K	008-300-9-003				
R130	SSB ALC	20K	008-206-9-009				U260R253B
R134	AM ALC	10K	008-206-9-008				U260R103B
R143	Dynamike	50K	008-300-9-004				
R317	26.965MHz	10K	008-206-9-008				U260R103B
R322	34.9885MHz	1000	008-206-9-010				U260R102B
R324	34.9875MHz	30K	008-206-9-002				U260R504B
R326	Voice Lock	20K	008-300-9-002				
R328	34.985MHz	30K	008-206-9-002				U260R504B

(18) Includes R8 and R90.

RESISTORS (Power and Special)

ITEM No.	RATING	REPLACEMENT DATA		ITEM No.	RATING	REPLACEMENT DATA	
		WORKMAN PART No.	MFGR. PART No.			WORKMAN PART No.	MFGR. PART No.
R46	2K Cold NTC		004-099-9-002	R372	Resistor Network		013-027-9-007 (1)

(1) Consist of seven 100K ohms 1/4 watt resistors.

COILS (RF-IF)

ITEM No.	FUNCTION	REPLACEMENT DATA			REMARKS
		PART No.	OTHER IDENTIFICATION	MILLER PART No.	
L1	Pi Filter	044-025-9-005			
L2	Pi Filter	044-025-9-005			
L3	Ant Match	041-096-9-001			
L4	RF Choke	042-022-9-002			
L5	XMT RF	041-096-9-002			
L6	RF Choke	042-027-9-001			
L7	XMT Driver	041-096-9-003			
L8	RF Choke	042-027-9-001			
L9	RF Choke	042-009-9-003			
L11	Pi Filter	044-025-9-005			
L13	RF Choke	042-027-9-002			
L14	RF Choke	042-027-9-002			
L15	RF Choke	042-027-9-003			
L16	RF Choke	042-027-9-003			
L301	Buffer Input (17.0555MHz)	041-096-9-004	25095		
L302	Phase Comparator Output (34.985MHz)	041-096-9-005	25096		
L303	Osc 17.0555MHz	041-096-9-006	25097		
L304	XMT Mixer	041-084-9-003	25090		
T1	Rec Antenna (27MHz)	066-028-9-001	25099		
T2	RF (27MHz)	066-013-9-002	L1641	CBS815-TC	
T3	RF (27MHz)	066-013-9-002	L1641	CBS815-TC	
T4	IF (7.8MHz)	066-028-9-002	25091		
T5	IF (7.8MHz)	066-028-9-002	29051		
T6	IF (7.8MHz)	066-029-9-001	L1839	CBS415-7TC	
T7	XMT Mixer (7.8MHz)	066-015-9-001	L1786	CBS412-7TC	
T8	XMT Mixer (7.8MHz)	066-015-9-002	L1787	CBS413-7TC	
T9	XMT Mixer (27MHz)	066-015-9-003	L1785	CBS816-TC	
T10	XMT Mixer (27MHz)	066-013-9-002	L1641	CBS815-TC	
T11	XMT Mixer (27MHz)	066-013-9-002	L1641	CBS815-TC	
T12	XMT RF (27MHz)	066-013-9-002	L1641	CBS815-TC	
T301	Mixer (18.507MHz)	066-028-9-003	25093		
T302	Multiplier Input (18.507MHz)	066-028-9-003	25093		
T303	Multiplier Output (18.507MHz)	066-028-9-004	24094		

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

FILTER CHOKE

ITEM No.	RATINGS			REPLACEMENT DATA			NOTES
	CURRENT (Measured)	DC RES.	INDUCTANCE (0 CURRENT 1000~)	MFGR. PART No.	THORDARSON PART No.	TRIAD PART No.	
L10	1.6A	.12	1.14mH	042-022-9-003 5015(1)			(1) Number on unit.

TRANSFORMER (Audio Output)

ITEM No.	IMPEDANCE		REPLACEMENT DATA			NOTES
	PRI.	SEC.	MFGR. PART No.	THORDARSON PART No.	TRIAD PART No.	
T13	32	18	061-029-9-001 5014(1)		MCB-18	(1) Number on unit.

SPEAKER

ITEM No.	TYPE	REPLACEMENT DATA		NOTES
		MFGR. PART No.	QUAM. PART No.	
SP1	2 1/4" X 6 1/4" PM 16 Ohms	580-012-9-001		

FUSE DEVICES

ITEM No.	DESCRIPTION	REPLACEMENT DATA						
		PART No.		BUSS PART No.		LITTELFUSE PART No.		WORKMAN PART No.
		DEVICE	HOLDER	DEVICE	HOLDER	DEVICE	HOLDER	DEVICE
F1	3A Quick Acting	191-251-9-003		AGC-3	HDJ	312003	150145	FG3-2

COBRA MODEL 132XLR

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

MICROPHONE

ITEM No.	REPLACEMENT DATA				CONNECTION DATA						
	MFGR. PART No.	GC PART No.	GC NOISE CANCEL	GC POWER	GC CONNECTOR	GC Red	GC Shield	GC Yellow	GC Blue	GC White	GC Black
MK1	562-003-9-001	18-032	18-034	18-010	18-092	2	1	3	NC	NC	4

MISCELLANEOUS

ITEM No.	PART NAME	PART No.	NOTES
CD316	LED	158-013-9-002	TLR-312
CD317	LED	158-013-9-002	TLR-312
J1	Jack	772-002-9-001	Antenna
J2	Jack	773-057-9-001	Microphone
J3	Jack	773-084-9-001	PA
J4	Jack	773-084-9-001	External Speaker
K1	Relay	441-010-9-001	XMT/Rec
K2	Relay	441-020-9-001	XMT/Rec
M1	Meter	320-036-9-001	RF
PL	Lamp		6.36V @ 30mA Meter
S1	Switch	080-007-9-002	CAL/SWL
S2	Switch	080-007-9-001	MOD/RF
S3	Switch	080-007-9-002	ANL/NB ANL
S4	Switch	080-007-9-002	LSB/AM/USB
S5	Switch	080-007-9-001	CB/PA
S301	Switch	083-213-9-001	Channel Selector
S302	Switch	080-007-9-001	Dim/Bright
U1	Filter	143-007-9-001	Crystal (7.8MHz)
W1	Coru	426-019-9-001	DC
X1	Crystal	133-017-9-001	7.8025MHz
X301	Crystal	133-017-9-002	17.05625MHz
X302	Crystal	133-012-9-001	5.12MHz

CABINETS & CABINET PARTS (When ordering specify model, chassis & color)

ITEM	PART No.	ITEM	PART No.
Knob, Control	751-144-9-002	Knob, SWR	751-144-9-003
Knob, RF	751-144-9-004		

WIRING DATA

General-use Hook-up Wire (available in 5 colors)	BELDEN No. 8523	Coiled Microphone Cable	
Shielded Hook-up Wire (spiral wrapped)	BELDEN No. 8421	3-conductor (1 shielded)	23AWG BELDEN No. 9471 (5')
(braided)	BELDEN No. 8401		BELDEN No. 8497 (6')
Speaker Cable (available in 4 colors)	BELDEN No. 8782		BELDEN No. 9472 (7-1/2')
Bonding Strap	BELDEN No. 8672		28AWG BELDEN No. 9466 (6')
AC Power Cord	(6') BELDEN No. 17106		31AWG BELDEN No. 9468 (10')
	(9') BELDEN No. 17109	4-conductor (unshielded)	23AWG BELDEN No. 8415 (6')
		5-conductor (1 shielded)	28AWG BELDEN No. 9467 (6')
			BELDEN No. 9465 (7-1/2')



PHOTOFACT[®] with

CIRCUITRACE[®]

For Supplier Address See PHOTOFACT Index

NOTE

Repair or adjustment of transmitter circuits must be under supervision of a person with first-or second-class radiotelephone license.

(Refer to FCC Rules and Regulations Part 95, Subpart C & D.)

The frequency of the transmitter should be checked periodically with a secondary frequency standard to insure proper and legal operation.

Best results will be obtained when adjusting the final RF output circuit if the antenna normally used is connected and the chassis is as nearly in the cabinet as possible.

Connect either 50-ohm dummy load or the normally used antenna system.

PRESIDENT MODEL MADISON



MODEL MADISON

HOWARD W. SAMS & CO., INC. Indianapolis, Indiana 46206

© 1978 Howard W. Sams & Co., Inc. Printed in U. S. of America 8CF773

ALIGNMENT INSTRUCTIONS

CAUTION: Use isolation transformer or observe polarity when connecting test equipment. Maintain line voltage at 120V AC. Allow a 15-minute warm-up period. Adjustments made with 13.8-volt DC input. Connect low sides of test equipment to ground unless specified otherwise. Connect 50-ohm dummy load or antenna before keying transmitter. Suggested Alignment Tools: GC ELECTRONICS:
L27, L30, L32 5009, 5000, 8276, 8728, 8728A
L1 thru L8, L16, L17, L24, L37, L39 9440
CT1 thru CT7 5000, 8276

SYNTHESIZER ALIGNMENT

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Input of RF VTVM to TP6.	Ch. 1 Clarifier-Midrange AM	L24	Adjust for maximum.
Input of DC meter to TP7.	Ch. 1	L17	Adjust for 2.0 volts.
Input of RF VTVM to TP8.	Ch. 19	L16	Adjust for maximum.
Input of frequency counter to TP8.	Ch. 19	CT6	Adjust for 34.9850MHz $\pm$ 20Hz.
Input of frequency counter to TP8.	Ch. 19, USB	CT4	Adjust for 34.9875MHz $\pm$ 20Hz.
Input of frequency counter to TP8.	Ch. 19, LSB	CT5	Adjust for 34.9825MHz $\pm$ 20Hz.
Input of frequency counter to TP8.	Ch. 19, LSB, Xmit	VR9	Adjust for 34.9825MHz $\pm$ 20Hz.
Input of frequency counter to TP9.	Ch. 19, USB, Xmit	CT2	Adjust for 7.8025MHz $\pm$ 5Hz -0Hz.
Input of frequency counter to TP9.	Ch. 19, LSB, Xmit	CT3	Adjust for 7.7975MHz $\pm$ 0Hz -5Hz.

RECEIVER ALIGNMENT

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.

AM

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to antenna jack. 23.5MHz, no modulation. Output 200uV. Input of RF VTVM to TP5.	Ch. 19, AM RF Gain-Maximum NB-On	L1, L2	Adjust for maximum.

RECEIVER ALIGNMENT

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.

SSB

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to antenna jack. 27.186MHz, no modulation. Output .25uV.	Ch. 19, USB RF Gain-Maximum Clarifier-Midrange Volume-Maximum	L8, L7, L5, L6, L4, L3	Adjust for maximum output.
Output of signal generator thru .01uF to antenna jack. 27.186MHz, no modulation. Output .25uV.	Ch. 19	CT1	Adjust for .5 watts audio.

RECEIVER ADJUSTMENTS

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to antenna jack. 27.185MHz, no modulation. Output 1000uV.	Ch. 19, USB RF Gain-MINIMUM Volume-Maximum	VR2	SSB AGC Adjust VR2 for .5 watts audio.
Output of signal generator thru .01uF to antenna jack. 27.186MHz, no modulation. Output 100uV.	Ch. 19	VR1	S METER Adjust for 9 on S scale of meter.

RECEIVER ADJUSTMENTS (cont)

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to antenna jack. 27.186MHz, no modulation. Output 1000uV.	Ch. 19	VR3	SQUELCH RANGE Set squelch control VR404 fully clockwise. Adjust VR3 so that squelch just breaks.
Output of signal generator thru .01uF to antenna jack. 27.185MHz, 1000Hz @ 30% modulation. Output .5uV.	Ch. 19, AM	VR5	AM AGC Adjust VR5 for .5 watts audio.

TRANSMITTER ALIGNMENT

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.
NOTE: Be sure to check transmit frequency and power on all active channels after alignment of transmitter.
See page 4 for channel frequencies.

AM

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Input of spectrum analyzer to antenna jack.	Ch. 19	L27	Adjust for MINIMUM at 54MHz.

TRANSMITTER ALIGNMENT

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.
NOTE: Be sure to check transmit frequency and power on all active channels after alignment of transmitter.
See page 4 for channel frequencies.


SSB

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of 2 tone generator to mike input. 500Hz and 2400Hz at .5 volts.	Ch. 19, USB Mike Gain-Maximum	L39,L37, L32,L30	Adjust for maximum.
Output of 2 tone generator to mike input. 500Hz and 2400Hz at .5 volts.	Ch. 19, USB	CT7	Adjust CT7 for 11.0 watts.


TRANSMITTER ADJUSTMENTS

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.
NOTE: Be sure to check transmit frequency and power on all active channels after adjustments of transmitter.
See page 4 for channel frequencies.


TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
DC current meter to TP3 and TP4. No modulation.	Ch. 19, USB	VR15	BIAS Adjust VR15 for 40mA +10mA.
DC current meter to TP1 and TP2. No modulation.	Ch. 19, USB	VR16	BIAS Adjust VR16 for 15mA. +10mA.
No modulation.	Ch. 19, USB	VR4	BALANCE Adjust for MINIMUM RF.
No modulation.	Ch. 19, AM	VR8	AM REG Adjust VR8 for 3.8 watts.
No modulation.	Ch. 19, AM	VR12	RF PANEL METER Adjust VR12 for 3.8 watts on RF scale of meter.
Inject a 1000Hz signal at mic input. Modulation meter to antenna jack.	Ch. 19, AM AMC-Maximum	VR7	AM AMC Adjust signal for 50% modulation. Increase signal 630 times. Adjust VR7 for 95% modulation.
Modulation meter to antenna jack. Inject a 1000Hz signal at mic input.	Ch. 13, AM	VR14	MOD Adjust VR14 so that MOD panel meter agrees with external modulation meter.



CHASSIS - TOP




CHASSIS - TOP




MAIN BOARD






MAIN BOARD




PRESIDENT MODEL MADISON


MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD



MAIN BOARD




MAIN BOARD




PRESIDENT MODEL MADISON


CH. SELECTOR BOARD




SWITCH BOARD



NOISE BLANKER BOARD



POWER SUPPLY BOARD



TRUTH CHART

1 = 4.68 Volts 0 = 0 Volts


1 = 4.68 Volts 0 = 0 Volts													
CHANNEL	IC7 PROGRAM DIVIDER										AM REC/TX VCO OUTPUT IN MHz AT TP8	LSB REC/TX VCO OUTPUT IN MHz AT TP8	USB REC/TX VCO OUTPUT IN MHz AT TP8
	PINS												
	13	14	15	16	17	18	19	20	21				
1	1	0	0	0	1	0	0	1	0	34.765	34.7625	34.7675	
2	0	1	0	0	1	0	0	1	0	34.775	34.7725	34.7775	
3	1	1	0	0	1	0	0	1	0	34.785	34.7825	34.7875	
4	1	0	1	0	1	0	0	1	0	34.705	34.8025	34.8075	
5	0	1	1	0	1	0	0	1	0	34.815	34.8125	34.8175	
6	1	1	1	0	1	0	0	1	0	34.825	34.8225	34.8275	
7	0	0	0	1	1	0	0	1	0	34.835	34.8325	34.8375	
8	0	0	0	0	0	0	0	0	1	34.855	34.8525	34.8575	
9	1	0	0	0	0	0	0	0	1	34.865	34.8625	34.8675	
10	0	1	0	0	0	0	0	0	1	34.875	34.8725	34.8775	
11	1	1	0	0	0	0	0	0	1	34.885	34.8825	34.8875	
12	1	0	1	0	0	0	0	0	1	34.905	34.9125	34.9075	
13	0	1	1	0	0	0	0	0	1	34.915	34.9125	34.9175	
14	1	1	1	0	0	0	0	0	1	34.925	34.9225	34.9275	
15	0	0	0	1	0	0	0	0	1	34.935	34.9325	34.9375	
16	0	0	0	0	1	0	0	0	1	34.955	34.9525	34.9575	
17	1	0	0	0	1	0	0	0	1	34.965	34.9625	34.9675	
18	0	1	0	0	1	0	0	0	1	34.975	34.9725	34.9775	
19	1	1	0	0	1	0	0	0	1	34.985	34.9825	34.9875	
20	1	0	1	0	1	0	0	0	1	34.005	35.0025	35.0075	
21	0	1	1	0	1	0	0	0	1	34.015	35.0125	35.0175	
22	1	1	1	0	1	0	0	0	1	34.025	35.0225	35.0275	
23	0	0	0	0	0	1	0	0	1	34.055	35.0525	35.0575	
24	0	0	0	1	1	0	0	0	1	34.035	35.0325	35.0375	
25	1	0	0	1	1	0	0	0	1	34.045	35.0425	35.0475	
26	1	0	0	0	0	1	0	0	1	34.065	35.0625	35.0675	
27	0	1	0	0	0	1	0	0	1	34.075	35.0725	35.0775	
28	1	1	0	0	0	1	0	0	1	34.085	35.0825	35.0875	
29	0	0	1	0	0	1	0	0	1	34.095	35.0925	35.0975	
30	1	0	1	0	0	1	0	0	1	34.105	35.1025	35.1075	
31	0	1	1	0	0	1	0	0	1	34.115	35.1125	35.1175	
32	1	1	1	0	0	1	0	0	1	34.125	35.1225	35.1275	
33	0	0	0	1	0	1	0	0	1	34.135	35.1325	35.1375	
34	1	0	0	1	0	1	0	0	1	34.145	35.1425	35.1475	
35	0	0	0	0	1	1	0	0	1	34.155	35.1525	35.1575	
36	1	0	0	0	1	1	0	0	1	34.165	35.1625	35.1675	
37	0	1	0	0	1	1	0	0	1	34.175	35.1725	35.1775	
38	1	1	0	0	1	1	0	0	1	34.185	35.1825	35.1875	
39	0	0	1	0	1	1	0	0	1	34.195	35.1926	35.1975	
40	1	0	1	0	1	1	0	0	1	34.205	35.2025	35.2075	

AND
AM TX

PRESIDENT MODEL MADISON

all should be 35.-----

BLOCK DIAGRAM



From CircuitTrace 1
at S406 on PLL
Schematic

NOTE


Repair or adjustment of transmitter circuits must be under supervision of a person with first-or second-class radiotelephone license.
(Refer to FCC Rules and Regulations Part 95, Subpart C & D.)

The frequency of the transmitter should be checked periodically with a secondary frequency standard to insure proper and legal operation.

Best results will be obtained when adjusting the final RF output circuit if the antenna normally used is connected and the chassis is as nearly in the cabinet as possible.

Connect either 50-ohm dummy load or the normally used antenna system.

PRESIDENT MODEL MADISON



✱ Circuitry not used in some versions

--- Circuitry used in some versions

⊙ See parts list

✱ Nominal value

⊕ Ground

⊕ Chassis

▽ Common tie point

A PHOTOFACT STANDARD NOTATION SCHEMATIC


WITH **CIRCUITTRACE®**


© Howard W. Sams & Co., Inc. 1978

Measurements made in Channel 1 with switching as shown unless noted.
Item numbers in rectangles appear in the alignment/adjustment instructions.
Supply voltage maintained as shown at input.
Voltages measured with digital meter, no signal.
Controls adjusted for normal operation.
Arrow at control indicates direction of advance.
Terminal identification may not be found on unit.
Resistors are 1/2W or less, 5% unless noted.
Value in () used in some versions.









PARTS LIST AND DESCRIPTION
(When ordering parts, state Model, Part Number, and Description.)

ITEM No.	TYPE No.	MFG. PART No.	REPLACEMENT DATA										THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
			GENERAL ELECTRIC PART No.	MALLORY PART No.	MOTOROLA PART No.	RAYTHEON PART No.	RCA PART No.	SPRAGUE PART No.	SYLVANIA PART No.						
D1	1S2473	2000-317	GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S1588		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S2472		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
D3	1S2473	2000-317	GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S1588		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S2472		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
D4	1S2473	2000-317	GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S1588		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S2472		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
D5	1S2473	2000-317	GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S1588		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S2472		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
D6	1S2473	2000-317	GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S1588		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S2472		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
D7	1S2473	2000-317	GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S1588		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S2472		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
D8	1S2473	2000-317	GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S1588		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S2472		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
D9	1S2473	2000-317	GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S1588		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S2472		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
D10	1N60P	2000-318	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109			WEP1062			
	1N60		PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109			WEP1062				
	1N60P		PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109			WEP1062				
D11	1S2473	2000-317	GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177			WEP1062			
	1S1588		GE-300	PTC214	HEPRO602	RE 52	SK3100	RT-218	ECG177						

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results) (cont)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA									
			GENERAL ELECTRIC PART No.	MALLORY PART No.	MOTOROLA PART No.	RAYTHEON PART No.	RCA PART No.	SPRAGUE PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
D41	1S2687D	2000-323	GEZD-9.1	ZB9.1A	HEPR2502	RE 114	SK3060	RT-240	ECG612	1N4739A	WEP200	ZEN-452
	1S2687				HEPR2502				ECG612		WEP200	ZEN-452
	1S2686				HEPR2502				ECG612		WEP200	ZEN-452
D43	1S2687D	2000-327	GEZD-9.1	ZB9.1A	HEPR2502	RE 114	SK3060	RT-240	ECG612	1N4739A	WEP200	ZEN-452
	1S2687				HEPR2502				ECG612		WEP200	ZEN-452
	1S2686				HEPR2502				ECG612		WEP200	ZEN-452
D44	C2092	2000-323	GEZD-9.1	ZB9.1A	HEP20412	RE 114	SK3060	RT-240	ECG139	1N4739A	WEP1109	103-272
D45	1S2687D				HEPR2502				ECG612		WEP200	ZEN-452
	1S2687				HEPR2502				ECG612		WEP200	ZEN-452
	1S2686	2000-317	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N60	WEP1062	ZEN-452
	1S2473				HEPR0602				ECG177		WEP1062	ZEN-452
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-452
	1S2472	2000-317	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N60	WEP1062	ZEN-452
	1S2473				HEPR0602				ECG177		WEP1062	ZEN-452
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-452
D48	1N60P	2000-337	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
	1N60P				HEPR9135				ECG109		WEP134	ZEN-430
D49	1N60P	2000-337	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
D50	1N60P	2000-318	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
D51	MV1Y	2000-339	GE-300	PTC301	HEPR0602	RE 250	SK3100	RT-218	ECG601	1N4004	WEP1062	ZEN-430
D52	MV1Y				HEPR0602				ECG177		WEP1062	ZEN-430
D53	1S2473				HEPR0602				ECG177		WEP1062	ZEN-430
	1S1588	2000-317	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N4004	WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
	SR1K2				HEPR0602				ECG177		WEP1062	ZEN-430
	G2B3	2000-320	GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
	SSV				HEPR0052				ECG116		WEP156	212-61
	1N60P				HEPR0052				ECG116		WEP156	212-61
D55	1N60P	2000-318	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
D56	1S2473	2000-302	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N60	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2473	2000-302	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N60	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
D58	1S2473	2000-302	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N60	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
D59	1N60P	2000-318	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
D61	1S2473	2000-319	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N4004	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
D62	1S2473	2000-319	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N4004	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
D64	1S2473	2000-319	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N4004	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
D65	1S2473	2000-319	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N4004	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
D74	SR1K2	2000-320	GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
D75	1S2473				HEPR0052				ECG116		WEP156	212-61
	1S1588				HEPR0052				ECG116		WEP156	212-61
	1S2472	2000-319	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N4004	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
D76	1S2473	2000-319	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N4004	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
D84	1S2473	2000-319	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N4004	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
D301	WZ061	2000-328	GEZD-6.2	ZM6.2B	HEPR0602	RE 109	SK3100	RT-237	ECG5013	1N4735A	WEP1414	ZEN-123
D302	BZ162				HEPR0602				ECG5013		WEP1414	ZEN-123
D406	S5VB10				HEPR0602				ECG5013		WEP1414	ZEN-123
D601	1N60P	2000-337	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
	1N60P				HEPR9135				ECG109		WEP134	ZEN-430
D602	1N60P	2000-337	1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
	1N60				HEPR9135				ECG109		WEP134	ZEN-430
D603	1S2473	2000-319	GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N60	WEP1062	ZEN-430
	1S1588				HEPR0602				ECG177		WEP1062	ZEN-430
	1S2472				HEPR0602				ECG177		WEP1062	ZEN-430
FET1	3SK45B	2000-102	GE-FET-4	PTC182	HEPF2004	RE 199	SK3050	RT-181	ECG222	1N60	WEP905	121-826
	3N201				HEPF2004				ECG222		WEP905	121-826
	3SK45				HEPF2004				ECG222		WEP905	121-826
	3SK41	2000-102	GE-FET-4	PTC182	HEPF2004	RE 199	SK3050	RT-181	ECG222	1N60	WEP905	121-826
	2SK19BL				HEPF2004				ECG222		WEP905	121-826
	2N2338				HEPF2004				ECG222		WEP905	121-826
FET2	3SK45B	2000-102	GE-FET-4	PTC182	HEPF2004	RE 199	SK3050	RT-181	ECG222	1N60	WEP905	121-826
	3N201				HEPF2004				ECG222		WEP905	121-826
	2SK19BL				HEPF2004				ECG222		WEP905	121-826
	2N2338	2000-105	GE-FET-2	PTC161	HEPF0021	RE 45	SK3116	RT-175	ECG312	1N60	WEP920	ZEN-123
	3N201				HEPF0021				ECG312		WEP920	ZEN-123
	2SK19				HEPF0021				ECG312		WEP920	ZEN-123
	2SK33	2000-105	GE-FET-2	PTC161	HEPF0021	RE 45	SK3116	RT-175	ECG312	1N60	WEP920	ZEN-123
	2SK68A				HEPF0021				ECG312		WEP920	ZEN-123
	2SK68				HEPF0021				ECG312		WEP920	ZEN-123
	2SK30A	2000-104	GE-FET-1	PTC151	HEPF0010	RE 46	SK3112	RT-176	ECG133	1N60	WEP801	ZEN-123
	2SK68AM				HEPF0010				ECG133		WEP801	ZEN-123
	3SK45B				HEPF0010				ECG133		WEP801	ZEN-123
FET4	3SK45	2000-104	GE-FET-4	PTC182	HEPF2004	RE 199	SK3050	RT-181	ECG222	1N60	WEP905	121-826
	3SK45				HEPF2004				ECG222		WEP905	121-826
	3N201				HEPF2004				ECG222		WEP905	121-826
	3SK40	2000-103	GE-FET-4	PTC182	HEPF2004	RE 199	SK3050	RT-181	ECG222	1N60	WEP905	121-826
	3SK41				HEPF2004				ECG222		WEP905	121-826
	3SK45-B-09				HEPF2004				ECG222		WEP905	121-826
FET5	2SK68A	2000-104	GE-FET-1	PTC151	HEPF0010	RE 46	SK3112	RT-176	ECG133	1N60	WEP801	ZEN-123
	2SK68				HEPF0010				ECG133		WEP801	ZEN-123
	2SK30A				HEPF0010				ECG133		WEP801	ZEN-123
	2SK68AM	2000-104	GE-FET-1	PTC151	HEPF0010	RE 46	SK3112	RT-176	ECG133	1N60	WEP801	ZEN-123
	3SK45				HEPF0010				ECG133		WEP801	ZEN-123
	3N201				HEPF0010				ECG133		WEP801	ZEN-123

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results) (cont)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA									
			GENERAL ELECTRIC PART No.	MALLORY PART No.	MOTOROLA PART No.	RAYTHEON PART No.	RCA PART No.	SPRAGUE PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
FET6	2SK198L JF1033 2SK19 2NJ33B	2000-105	GE-FET-2 GE-FET-2 GE-FET-2	PTC161 PTC161 PTC161	HEPF0021 HEPF0021 HEPF0021	RE 45 RE 45 RE 45	SK3116 SK3116 SK3116	RT-175 RT-175 RT-175	ECG312 ECG312 ECG312		WEP920 WEP920 WEP920	ZEN-123 ZEN-123 ZEN-123
FET7	3SK45B 3N201 3SK45 3SK40 3SK41	2000-102	GE-FET-2 GE-FET-4 GE-FET-4 GE-FET-4 GE-FET-4	PTC161 PTC182 PTC182 PTC182 PTC182	HEPF0021 HEPF2004 HEPF2004 HEPF2004 HEPF2004	RE 45 RE 199 RE 199 RE 199 RE 199	SK3116 SK3050 SK3050 SK3050 SK3050	RT-175 RT-181 RT-181 RT-181 RT-181	ECG312 ECG222 ECG222 ECG222 ECG222		WEP920 WEP905 WEP905 WEP905 WEP905	ZEN-123 ZEN-123 ZEN-123 ZEN-123 ZEN-123
FET601	JF1033G JF1033 2SK19 2NJ233B	2000-106	GE-FET-2 GE-FET-2 GE-FET-2 GE-FET-2	PTC161 PTC161 PTC161 PTC161	HEPF0021 HEPF0021 HEPF0021 HEPF0021	RE 45 RE 45 RE 45 RE 45	SK3116 SK3116 SK3116 SK3116	RT-175 RT-175 RT-175 RT-175	ECG312 ECG312 ECG312 ECG312		WEP801 WEP801 WEP801 WEP801	ZEN-123 ZEN-123 ZEN-123 ZEN-123
IC1	UPC577H NJM2201 MB3202	2000-007	GEIC-140 GEIC-140 GEIC-140			RE 341-M RE 341-M RE 341-M			ECG1082 ECG1082 ECG1082	UPC577H UPC577H UPC577H	WEP939 WEP939 WEP939	
IC2	MC1496N MC1496A LM1496N	2000-009			HEPC6050G HEPC6050G HEPC6050G							
IC3	UPC592H2 TA7120P	2000-006	GEIC-103						ECG1195 ECG1087			
IC4	UPC1156H NJM2016 MB3710	2000-005					SK3285		ECG1194 ECG1194 ECG1194			
IC5	UHC005A UHC005	2000-011							ECG1204 ECG1204			
IC6	78L05A NJM78L05A 78L05 78L05AV	2000-004				RE 387-IC RE 387-IC RE 387-IC RE 387-IC			ECG977 ECG977 ECG977 ECG977			
IC7	UPD858 UPD858C KM858C	2000-001							ECG1198 ECG1198 ECG1198			
TR1	25C945A 25C945 25C828 25C1740 25C945AP	2000-235	GE-212 GE-212 GE-61* GE-62	PTC121* PTC121* PTC121* PTC121*	25C945 25C945 HEPS0015* 25C945	RE 192 RE 192 RE 192 RE 13*	SK3124 SK3124 SK3122 SK3122	RT-107A RT-107A RT-302 RT-109*	ECG199 ECG199 ECG199 ECG123A*	25C945 25C945 25C828	WEP1945 WEP1945 WEP828 WEP736*	121-Z9000 121-Z9000 ZEN-119 121-972
TR2	25C945AP 25A733P 25A733 25A495 25A564	2000-236	GE-48 GE-48 GE-221* GE-65	PTC103* PTC103* PTC103* PTC103*	25A733 25A733 25A495 25A564	RE 219 RE 219 RE 26* RE 193	SK3138 SK3138 SK3114 SK3114	RT-303 RT-303 RT-303 RT-303	ECG294 ECG294 ECG159* ECG234	25A733 25A733 25A495 25A564	WEP916 WEP916 WEP495 WEP564	121-972 121-972 ZEN-106 121-879
TR3	25C1730L 25C1730 25C945 25C828 25C1740	2000-214	GE-17* GE-17* GE-212 GE-61* GE-62	PTC136* PTC136* PTC121* PTC121* PTC121*	HEPS0025* HEPS0025* 25C945 25C828 HEPS0015*	RE 9 RE 9 RE 192 RE 192 RE 13*	SK3018* SK3018* SK3124 SK3122 SK3122	RT-107A RT-107A RT-107A RT-302 RT-109*	ECG107 ECG107 ECG199 ECG199 ECG123A*	25C945 25C828	WEP535 WEP535 WEP1945 WEP828 WEP736*	121-881 121-881 121-Z9000 ZEN-119 121-972
TR4	25C945AP 25C945A 25C945 25C828 25C1740	2000-235	GE-212 GE-212 GE-212 GE-212	PTC121* PTC121* PTC121* PTC121*	25C945 25C945 25C945 25C945	RE 192 RE 192 RE 192 RE 192	SK3124 SK3124 SK3124 SK3124	RT-107A RT-107A RT-107A RT-107A	ECG199 ECG199 ECG199 ECG199	25C945 25C945 25C945 25C828	WEP1945 WEP1945 WEP1945 WEP1945	121-Z9000 121-Z9000 121-Z9000 ZEN-119
TR5	25C828 25C1740 25C1730L 25C1730 25C460	2000-214	GE-62 GE-17* GE-17* GE-61* GE-60*	PTC121* PTC136* PTC136* PTC136* PTC132*	HEPS0015* HEPS0025* HEPS0025* 25C460 25C930	RE 13* RE 9 RE 9 RE 9 RE 9	SK3122 SK3018* SK3018* SK3018* SK3039*	RT-302 RT-109* RT-107A RT-107A RT-308	ECG199 ECG123A* ECG107 ECG107 ECG229*	25C828 25C460 25C930	WEP828 WEP736* WEP535 WEP460 WEP956*	ZEN-119 121-972 121-881 121-722 ZEN-127
TR6	25C1675 25C1675L 25C1675 25C460 25C829	2000-213	GE-213 GE-213 GE-213 GE-61* GE-61*	PTC139* PTC139* PTC139* PTC136* PTC132*	25C1675 25C1675 25C1675 25C460 25C839	RE 13* RE 13* RE 13* RE 9 RE 13*	SK3124 SK3124 SK3124 SK3018* SK3018*	RT-308 RT-308 RT-308 RT-134 RT-308	ECG229* ECG229* ECG229* ECG107 ECG229*	25C460 25C839 25C829	WEP956* WEP956* WEP956* WEP460 WEP736*	ZEN-127 ZEN-127 ZEN-127 121-722 ZEN-120
TR7	25C829 25C1675L 25C1675 25C460 25C839	2000-213	GE-20* GE-213 GE-213 GE-61* GE-61*	PTC121* PTC139* PTC139* PTC136* PTC132*	25C829 25C1675 25C1675 25C460 25C839	RE 9* RE 13* RE 13* RE 9 RE 13*	SK3122 SK3124 SK3124 SK3018* SK3018*	RT-308 RT-308 RT-308 RT-134 RT-308	ECG229* ECG229* ECG229* ECG107 ECG123A*	25C829 25C839 25C829	WEP829 WEP956* WEP956* WEP460 WEP736*	ZEN-127 ZEN-127 ZEN-127 121-722 ZEN-120
TR8	25C839H 25C839 25C1675 25C829 25C460	2000-234	GE-61* GE-61* GE-213 GE-20* GE-61*	PTC132* PTC132* PTC139* PTC121* PTC136*	25C839 25C839 25C1675 25C829 25C460	RE 13* RE 13* RE 13* RE 9* RE 9	SK3018* SK3018* SK3124 SK3122 SK3018*	RT-308 RT-308 RT-308 RT-308 RT-134	ECG123A* ECG123A* ECG229* ECG107 ECG229*	25C839 25C839 25C829 25C460 25C829	WEP736* WEP736* WEP956* WEP460 WEP829	ZEN-120 ZEN-120 ZEN-127 121-722 ZEN-127
TR9	25C839H 25C839 25C1675 25C829 25C460	2000-234	GE-61* GE-61* GE-213 GE-20* GE-61*	PTC132* PTC132* PTC139* PTC121* PTC136*	25C839 25C839 25C1675 25C829 25C460	RE 13* RE 13* RE 13* RE 9* RE 9	SK3018* SK3018* SK3124 SK3122 SK3018*	RT-308 RT-308 RT-308 RT-308 RT-134	ECG123A* ECG123A* ECG229* ECG107 ECG229*	25C839 25C839 25C829 25C460 25C460	WEP736* WEP736* WEP956* WEP460 WEP829	ZEN-120 ZEN-120 ZEN-127 121-722 ZEN-127
TR10	25C839H 25C839 25C1675 25C829 25C460	2000-234	GE-61* GE-61* GE-213 GE-20* GE-61*	PTC132* PTC132* PTC139* PTC121* PTC136*	25C839 25C839 25C1675 25C829 25C460	RE 13* RE 13* RE 13* RE 9* RE 9	SK3018* SK3018* SK3124 SK3122 SK3018*	RT-308 RT-308 RT-308 RT-134 RT-308	ECG123A* ECG123A* ECG229* ECG107 ECG229*	25C839 25C839 25C829 25C460 25C460	WEP736* WEP736* WEP956* WEP460 WEP829	ZEN-120 ZEN-120 ZEN-127 121-722 ZEN-127
TR11	25C945AP 25C945A 25C945 25C828 25C1740	2000-235	GE-212 GE-212 GE-212 GE-61* GE-62	PTC121* PTC121* PTC121* PTC121* PTC121*	25C945 25C945 25C945 25C828 HEPS0015*	RE 192 RE 192 RE 192 RE 192 RE 13*	SK3124 SK3124 SK3124 SK3122 SK3122	RT-107A RT-107A RT-107A RT-302 RT-109*	ECG199 ECG199 ECG199 ECG199 ECG123A*	25C945 25C945 25C945 25C828 25C945	WEP1945 WEP1945 WEP1945 WEP828 WEP736*	121-Z9000 121-Z9000 121-Z9000 ZEN-119 121-972
TR12	25C945AP 25C945A 25C945 25C828 25C1740	2000-235	GE-212 GE-212 GE-212 GE-61* GE-62	PTC121* PTC121* PTC121* PTC121* PTC121*	25C945 25C945 25C945 25C828 HEPS0015*	RE 192 RE 192 RE 192 RE 192 RE 13*	SK3124 SK3124 SK3124 SK3122 SK3122	RT-107A RT-107A RT-107A RT-302 RT-109*	ECG199 ECG199 ECG199 ECG199 ECG123A*	25C945 25C945 25C945 25C828 25C945	WEP1945 WEP1945 WEP1945 WEP828 WEP736*	121-Z9000 121-Z9000 121-Z9000 ZEN-119 121-972

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results) (cont)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA									
			GENERAL ELECTRIC PART No.	MALLORY PART No.	MOTOROLA PART No.	RAYTHEON PART No.	RCA PART No.	SPRAGUE PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
TR13	2SC945AP	2000-235	GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC828		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC1740		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
TR14	2SC945AP	2000-235	GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC828		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC1740		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
TR15	2SC945AP	2000-235	GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
	2SC945A		GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC945		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC828		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC1740		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
TR16	2SC945AP	2000-235	GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC945A		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC945		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
	2SC828		GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC1740		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
TR17	2SC945AP	2000-236	GE-48	PTC103*	2SA733	RE 219	SK3138	RT-303	ECG294	2SA733	WEP916	
	2SC945A		GE-48	PTC103*	2SA733	RE 219	SK3138	RT-303	ECG294	2SA733	WEP916	
	2SC945		GE-221*	PTC103*	2SA495	RE 26*	SK3114	RT-303	ECG159*	2SA495	WEP495	ZEN-106
	2SC828		GE-65	PTC103*	2SA564	RE 193	SK3114	RT-303	ECG234	2SA564	WEP564	121-879
	2SC1740		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
TR18	2SC945AP	2000-235	GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC828		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC1740		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
TR19	2SC945AP	2000-236	GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC945A		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC945		GE-48	PTC103*	2SA733	RE 219	SK3138	RT-303	ECG294	2SA733	WEP916	
	2SC828		GE-221*	PTC103*	2SA495	RE 26*	SK3114	RT-303	ECG159*	2SA495	WEP495	ZEN-106
	2SC1740		GE-65	PTC103*	2SA564	RE 193	SK3114	RT-303	ECG234	2SA564	WEP564	121-879
TR20	2SC945AP	2000-235	GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC828		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC1740		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
TR21	2SC945AP	2000-235	GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC945A		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC828		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC1740		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
TR22	2SC945AP	2000-235	GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC945A		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
	2SC945		GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC828		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC1740		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
TR23	2SC945AP	2000-235	GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC828		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC1740		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
TR24	2SC945AP	2000-235	GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC945A		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC828		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC1740		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
TR25	2SC945AP	2000-216	GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC945A		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
	2SC945		GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC828		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC1740		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
TR26	2SC945AP	2000-235	GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC828		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC1740		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
TR27	2SC945AP	2000-213	GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC945A		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC945		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*		WEP956*	ZEN-127
	2SC828		GE-61*	PTC136*	2SC460	RE 9	SK3018*	RT-134	ECG107	2SC460	WEP460	121-722
	2SC1740		GE-20*	PTC121*	2SC829	RE 9*	SK3018*	RT-308	ECG123A*	2SC829	WEP829	ZEN-120
TR28	2SC945AP	2000-213	GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*		WEP956*	ZEN-127
	2SC945A		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*		WEP956*	ZEN-127
	2SC945		GE-61*	PTC136*	2SC460	RE 9	SK3018*	RT-134	ECG107	2SC460	WEP460	121-722
	2SC828		GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP839	ZEN-120
	2SC1740		GE-20*	PTC121*	2SC829	RE 9*	SK3122	RT-308	ECG229*	2SC829	WEP829	ZEN-127

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results) (cont)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA									
			GENERAL ELECTRIC PART No.	MALLORY PART No.	MOTOROLA PART No.	RAYTHEON PART No.	RCA PART No.	SPRAGUE PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
TR29A	2SC945AP	2000-235	GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC828		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC1740		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC458		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
	2SC900		GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC945AP		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
TR29B	2SC945A	2000-235	GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC828		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC1740		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC458		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
	2SC900		GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC839H		GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	121-Z9000
	2SC1675L		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC839	WEP956*	ZEN-127
	2SC1675		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC839	WEP956*	ZEN-127
TR30	2SC460	2000-234	GE-61*	PTC136*	2SC460	RE 9	SK3018*	RT-134	ECG107	2SC460	WEP460	121-722
	2SC839		GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	ZEN-120
	2SC829		GE-20*	PTC121*	2SC829	RE 9*	SK3122	RT-308	ECG229*	2SC829	WEP829	ZEN-127
	2SC839H		GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	ZEN-120
	2SC1675L		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC1675		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC460		GE-61*	PTC136*	2SC460	RE 9	SK3018*	RT-134	ECG107	2SC460	WEP460	121-722
	2SC839		GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	ZEN-120
	2SC829		GE-20*	PTC121*	2SC829	RE 9*	SK3122	RT-308	ECG229*	2SC829	WEP829	ZEN-127
	2SC839H		GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	ZEN-120
TR31	2SC1675L	2000-234	GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC1675		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC460		GE-61*	PTC136*	2SC460	RE 9	SK3018*	RT-134	ECG107	2SC460	WEP460	121-722
	2SC839		GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	ZEN-120
	2SC829		GE-20*	PTC121*	2SC829	RE 9*	SK3122	RT-308	ECG229*	2SC829	WEP829	ZEN-127
	2SC945AP		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC828		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC1740		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
TR32	2SC458	2000-235	GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
	2SC900		GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC1675L		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC1675		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC839		GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	ZEN-120
	2SC829		GE-20*	PTC121*	2SC829	RE 9*	SK3122	RT-308	ECG229*	2SC829	WEP829	ZEN-127
	2SC460		GE-61*	PTC136*	2SC460	RE 9	SK3018*	RT-134	ECG107	2SC460	WEP460	121-722
	2SC458C		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
	2SC458		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
TR34	2SC945AP	2000-213	GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC828		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC1740		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC458		GE-210*	PTC121*	2SC458	RE 13*	SK3124	RT-187	ECG123A*	2SC458	WEP458	ZEN-114
	2SC900		GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC1675L		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC1675		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
TR35	2SC839	2000-213	GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	ZEN-120
	2SC829		GE-20*	PTC121*	2SC829	RE 9*	SK3122	RT-308	ECG229*	2SC829	WEP829	ZEN-127
	2SC460		GE-61*	PTC136*	2SC460	RE 9	SK3018*	RT-134	ECG107	2SC460	WEP460	121-722
	2SC945AP		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC828		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC1740		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
	2SC900		GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
TR38	2SC1675L	2000-213	GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC1675		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC839		GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	ZEN-120
	2SC829		GE-20*	PTC121*	2SC829	RE 9*	SK3122	RT-308	ECG229*	2SC829	WEP829	ZEN-127
	2SC460		GE-61*	PTC136*	2SC460	RE 9	SK3018*	RT-134	ECG107	2SC460	WEP460	121-722
	2SC945AP		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945A		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC828		GE-61*	PTC121*	2SC828	RE 192	SK3122	RT-302	ECG199	2SC828	WEP828	ZEN-119
	2SC1740		GE-62	PTC121*	HEPS0015*	RE 13*	SK3122	RT-109*	ECG123A*		WEP736*	121-972
TR39	2SC900	2000-213	GE-62	PTC139*	2SC900	RE 192	SK3124	RT-302	ECG199	2SC900	WEP66	ZEN-119
	2SC372		GE-61*	PTC121*	2SC372	RE 13*	SK3122	RT-308	ECG123A*	2SC372	WEP372	ZEN-114
	2SC1675L		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC1675		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*	2SC1675	WEP956*	ZEN-127
	2SC839		GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	ZEN-120
	2SC829		GE-20*	PTC121*	2SC829	RE 9*	SK3122	RT-308	ECG229*	2SC829	WEP829	ZEN-127
	2SC460		GE-61*	PTC136*	2SC460	RE 9	SK3018*	RT-134	ECG107	2SC460	WEP460	121-722
	2SC945AP		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z900

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results)(cont)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA									
			GENERAL ELECTRIC PART No.	MALLORY PART No.	MOTOROLA PART No.	RAYTHEON PART No.	RCA PART No.	SPRAGUE PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
TR302	2SC1419B (16)	2000-216	GE-66	PTC167	HEPS5027	RE 21	SK3054	RT-197	ECG152		WEP745	
TR401	2SC1419	2000-221	GE-66	PTC167	HEPS5027	RE 21	SK3054	RT-197	ECG152		WEP745	
	2SC1618		GE-14	PTC140	HEPS7004	RE 19	SK3027	RT-131	ECG130		WEP704	
	2SC1777		GE-14	PTC140	HEPS7004	RE 19	SK3027	RT-131	ECG130		WEP704	
	2SD188		GE-75	PTC118	HEPS7004	RE 29	SK3029	RT-131	ECG130		WEP704	
TR402	2SC1618B	2000-216	GE-14	PTC140	HEPS7004	RE 19	SK3027	RT-131	ECG130		WEP745	
	2SC1419		GE-66	PTC167	HEPS5027	RE 21	SK3054	RT-197	ECG152		WEP751	
	2SD325		GE-28	PTC110	2SD325	RE 42	SK3197	RT-197	ECG186	2SD325	WEP1096	
	2SC1096		GE-28	PTC110	2SC1096	RE 42	SK3197	RT-166	ECG186A	2SC1096	WEP745	
TR403	2SD235	2000-216	GE-66	PTC167	HEPS5027	RE 21	SK3054	RT-197	ECG152	2SD235	WEP745	
	2SC1419B		GE-66	PTC167	HEPS5027	RE 21	SK3054	RT-197	ECG152		WEP745	
	2SC1419		GE-66	PTC167	HEPS5027	RE 21	SK3054	RT-197	ECG152		WEP745	
	2SD325		GE-28	PTC110	2SD325	RE 42	SK3197	RT-197	ECG186	2SD325	WEP751	
TR601	2SC1096	2000-216	GE-28	PTC110	2SC1096	RE 42	SK3197	RT-166	ECG186A	2SC1096	WEP1096	
	2SD235		GE-66	PTC167	HEPS5027	RE 21	SK3054	RT-197	ECG152	2SD235	WEP745	
	2SC1675L		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*		WEP956*	ZEN-127
	2SC1675		GE-213	PTC139*	2SC1675	RE 13*	SK3124	RT-308	ECG229*		WEP956*	ZEN-127
TR601	2SC839	2000-213	GE-61*	PTC132*	2SC839	RE 13*	SK3018*	RT-308	ECG123A*	2SC839	WEP736*	ZEN-120
	2SC829		GE-20*	PTC121*	2SC829	RE 9*	SK3122	RT-308	ECG229*	2SC829	WEP829	ZEN-127
	2SC460		GE-61*	PTC136*	2SC460	RE 9	SK3018*	RT-134	ECG107	2SC460	WEP460	121-722

(14) 25 Watt @ 8.0 Amp.

(15) 12 Watt @ 3.0 Amp.

(16) 20 Watt @ 2.0 Amp.

ELECTROLYTIC CAPACITORS

ITEM No.	RATING	REPLACEMENT DATA				
		MFR. PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C14	33 10V	1800-323	PC30-25	VTT33B10	QV1-61	EV-1125
C17B	2.2 25V	1800-603		TDC225M035FL		SD35-2R29
C35	1 50V	1800-302	PC1-50	VTT1A50	QV1-11	EV-1615
C39	.1 16V	1800-501		TDC104M050EL	QDT1-2	SD50-R109
C42	10 16V	1800-306	PC10-25	VTT10B25	QV1-41	EV-1222
C43	10 16V	1800-306	PC10-25	VTT10B25	QV1-41	EV-1222
C44	4.7 25V	1800-304	PC5-50	VTT4R7B50	QV1-27	EV-1319
C47	47 10V	1800-316	PC50-16	VTT47D16	QV1-73	EV-1226
C49	47 10V	1800-316	PC50-16	VTT47D16	QV1-73	EV-1226
C50	47 10V	1800-316	PC50-16	VTT47D16	QV1-73	EV-1226
C52	1 25V	1800-606		TDC105M035EL		SD35-19
C55	2.2 25V	1800-303	PC2-100	VTT2R2A50	QV1-19	EV-1517
C58	1 50V	1800-302	PC1-50	VTT1A50	QV1-11	EV-1615
C59	47 10V	1800-316	PC50-16	VTT47D16	QV1-73	EV-1226
C60	.1 16V	1800-501		TDC104M050EL	QDT1-2	SD50-R109
C63	10 16V	1800-306	PC10-25	VTT10B25	QV1-41	EV-1222
C66	47 10V	1800-316	PC50-16	VTT47D16	QV1-73	EV-1226
C67	4.7 25V	1800-304	PC5-50	VTT4R7B50	QV1-27	EV-1319
C68	4.7 25V	1800-304	PC5-50	VTT4R7B50	QV1-27	EV-1319
C69	10 16V	1800-306	PC10-25	VTT10B25	QV1-41	EV-1222
C76	47 10V	1800-316	PC50-16	VTT47D16	QV1-73	EV-1226
C77	.47 50V	1800-301	PC1-50	VTT4R7A63	QV1-3	EV-1610
C78	.47 50V	1800-301	PC1-50	VTT4R7A63	QV1-3	EV-1610
C79	.47 50V	1800-301	PC1-50	VTT4R7A63	QV1-3	EV-1610
C81	220 16V	1800-314	PC250-25	VTT220H16	QV1-117	EV-1240
C84	1 50V	1800-302	PC1-50	VTT1A50	QV1-11	EV-1615
C87	10 16V	1800-306	PC10-25	VTT10B25	QV1-41	EV-1222
C88	4.7 25V	1800-607		TDC475M010EL	QDT1-48	SD10-4R79
C89	33 16V	1800-307	PC30-25	VTT33D25	QV1-63	EV-1325
C92	33 16V	1800-307	PC30-25	VTT33D25	QV1-63	EV-1325
C94	470 16V	1800-309	PC500-16	VTT470K16	QV1-151	EV-1250
C95	470 16V	1800-309	PC500-16	VTT470K16	QV1-151	EV-1250
C97	4.7 25V	1800-304	PC5-50	VTT4R7B50	QV1-27	EV-1319
C98	1 50V	1800-302	PC1-50	VTT1A50	QV1-11	EV-1615
C99	10 16V	1800-306	PC10-25	VTT10B25	QV1-41	EV-1222
C101	100 10V	1800-310	PC100-10	VTT100E10	QV1-93	EV-1130
C102	220 10V	1800-325	PC250-10	VTT220F10	QV1-115	EV-1140
C103	470 10V	1800-327	PC500-16	VTT470K16	QV1-149	EV-1150
C104	330 10V	1800-326	WBR300-35	VTT330G10	QV1-131	EV-1145
C107	1000 16V	1800-328	PC1000-16	VTT1000L16	QV1-183	EV-1260
C110	.1 16V	1800-501		TDC104M050EL	QDT1-2	SD50-R109
C120	47 10V	1800-316	PC50-16	VTT47D16	QV1-73	EV-1226
C126	1 50V	1800-302	PC1-50	VTT1A50	QV1-11	EV-1615
C135	220 10V	1800-325	PC250-10	VTT220F10	QV1-115	EV-1140
C140	10 6.3V	1800-602		TDC106M025FL	QDT1-64	SD25-109
C141	10 6.3V	1800-602		TDC106M025FL	QDT1-64	SD25-109
C158	1 50V	1800-302	PC1-50	VTT1A50	QV1-11	EV-1615
C199	1 50V	1800-302	PC1-50	VTT1A50	QV1-11	EV-1615
C211	2.2 25V	1800-303	PC2-100	VTT2R2A50	QV1-19	EV-1517
C218	4.7 25V	1800-304	PC5-50	VTT4R7B50	QV1-27	EV-1319
C224	1 50V	1800-302	PC1-50	VTT1A50	QV1-11	EV-1615
C226	1 50V	1800-302	PC1-50	VTT1A50	QV1-11	EV-1615
C302	220 16V	1800-314	PC250-25	VTT220H16	QV1-117	EV-1240
C304	3300 25V	1800-329	WBR3000-35	TC2530		TVA-1214
C605	.1 16V	1800-501		TDC104M050EL	QDT1-2	SD50-R109

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFG. PART No.	REPLACEMENT DATA				
			CENTRALAB PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
						Q-LINE	GENERAL LINE
C1	39 NPO 50V				CN0439		10TCC-Q39
C2	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C4	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C5	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C6	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C7	47 NPO 50V		DTZ-47	NP047	CN0447		10TCC-Q47
C8	100 50V		DD-101	GP100	GP310		10TS-T10
C9	.001 50V		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C10	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C11	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C12	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C13	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C15	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C16	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C17A	.01 50V			WMF1S1	EWFA1A110	QF1-91	1PB-S10
C18	.039 50V			DPMS6S39	PVC6139		6PS-S39
C19	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C20	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C21	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C22	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C23	.022 50V			DPMS2S22	EWFA1A122	QF1-127	1PB-S22
C24	56 NPO 50V				CN0456		10TCC-Q56
C25	.039 50V			DPMS6S39	PVC6139		6PS-S39
C26	.039 50V			DPMS6S39	PVC6139		6PS-S39
C27	.039 50V			DPMS6S39	PVC6139		6PS-S39
C28	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C29	.039 50V			DPMS6S39	PVC6139		6PS-S39
C30	.039 50V			DPMS6S39	PVC6139		6PS-S39
C31	.039 50V			DPMS6S39	PVC6139		6PS-S39
C32	5 NPO 50V		DTZ-4R7	NP04P7	CN0547		10TCC-V47
C33	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C34	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C36	5 NPO 50V		DTZ-4R7	NP04P7	CN0547		10TCC-V47
	3 50V	(1)	DTZ-3R3	NP03P3	CN0533		10TCC-V33
C37	7 NPO 50V	(1)	DTZ-6R8	NP06P8	CN0568		10TCC-V68
	2 50V		DTZ-2R2	NP02P2	CN0522		10TCC-V22
C38	330 N750 50V		DTN-330	N330	CN7333		10TCU-T33
C40	.039 50V			DPMS6S39	PVC6139		6PS-S39
C41	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C45	47 NPO 50V		DTZ-47	NP047	CN0447		10TCC-Q47
C46	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C51	.022 50V			DPMS2S22	EWFA1A122	QF1-127	1PB-S22
C54	22 NPO 50V		DTZ-22	NP022	CN0422		10TCC-Q22
C57	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C61	.047 50V			DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C62	.047 50V			DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C64	.039 50V			DPMS6S39	PVC6139		6PS-S39
C71	.068 50V			WMF1S68	EWFA1A168	QF1-195	1PB-S68
C72	.022 50V			DPMS2S22	EWFA1A122	QF1-127	1PB-S22
C73	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C74	.022 50V			DPMS2S22	EWFA1A122	QF1-127	1PB-S22
C75	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C80	.0068 50V			DPMS6S12	PVC6112		6PS-S12
	.01 50V	(1)	DC-103	MGP01	TA110	QC2-141	TG-S10
C82	.047 50V	(1)		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C83	.01 50V			WMF1S1	EWFA1A110	QF1-91	1PB-S10
C85	.039 50V			DPMS6S39	PVC6139		6PS-S39
C86	.022 50V			DPMS2S22	EWFA1A122	QF1-127	1PB-S22
C91	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C93	68 NPO 50V		DTZ-68	NP068	CN0468		10TCC-Q68
C96	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C100	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C105	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C106	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C109	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C111	18 NPO 50V				CN0418		10TCC-Q18
C112	18 NPO 50V				CN0418		10TCC-Q18
C113	.001 50V		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C114	.001 50V		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C115	100 NPO 50V		DTZ-100	NP0100	CN0310		10TCC-T10
C116	10 NPO 50V		DTZ-10	NP010	CN0410		10TCC-Q10
C117	1 NPO 50V				CN0510		10TCC-V10
C118	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C121	.039 50V			DPMS6S39	PVC6139		6PS-S39
C122	47 NPO 50V		DTZ-47	NP047	CN0447		10TCC-Q47
C123	47 NPO 50V		DTZ-47	NP047	CN0447		10TCC-Q47
C124	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C125	270 50V			GP270	GP327		10TS-T27
C127	470 50V			GP470	GP347		10TS-T47
C128	220 50V				GP322		10TS-T22
C129	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C130	10 NPO 50V		DTZ-10	NP010	CN0410		10TCC-Q10
C131	.01 50V			DPMS2S2	PVC212		2PS-S20
C133	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C134	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C136	470 50V		DD-471	GP470	GP347		10TS-T47
C137	220 50V		DD-221		GP322		10TS-T22
C138	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C139	10 NPO 50V		DTZ-10	NP010	CN0410		10TCC-Q10
C142	68 NPO 50V		DTZ-68	NP068	CN0468		10TCC-Q68
C143	7 NPO 50V		DTZ-6R8	NP06P8	CN0568		10TCC-V68
C146	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C147	470 50V		DD-471	GP470	GP347		10TS-T47
C148	220 50V		DD-221		GP322		10TS-T22
C149	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C150	10 NPO 50V		DTZ-10	NP010	CN0410		10TCC-Q10
C151	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C152	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C153A	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10

PRESIDENT MODEL MADISON

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA				
			CENTRALAB PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
						Q-LINE	GENERAL LINE
C153B	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C154	10 NPO 50V		DTZ-10	NP010	CN0410		10TCC-Q10
C155	1 NPO 50V				CN0510		10TCC-V10
C156	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C157	.039 50V			DPMS6S39	PVC6139		6PS-S39
C159	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C160	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C161	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C162	.0047 50V		UD-472	GP4700	GP247		5GA-D47
C163	47 NPO 50V		DTZ-47	NP047	CN0447		10TCC-Q47
C164	68 NPO 50V		DTZ-68	NP068	CN0468		10TCC-Q68
C165	220 NPO 50V		DTZ-220				10TCC-T22
C166	.01 50V	(1)	DC-103	MGP01	TA110	QC2-141	TG-S10
	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C167	390 50V		DD-391	GP390	GP339		10TS-T39
C168	.5 NPO 50V	1800-002					
C169	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C170	470 50V		DD-471	GP470	GP347		10TS-T47
C172	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C173	220 N220 50V	1800-098			*		10TCR-T22
C174	56 NPO 50V				CN0456		10TCC-Q56
C175	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C176	56 NPO 50V				CN0456		10TCC-Q56
C177	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C178	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C183	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C184	120 NPO 50V	(1)	DTZ-120		CN0312		10TCC-T12
	82 50V		DTZ-82	NP082	CN0482		10TCC-Q82
C185	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C186	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C187	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C188	.1 50V	(1)		DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C189	.047 50V			DPMS2S47	EWFA1A147	QF1-171	1PB-S47
	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C190	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C191	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C192	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C193	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C194	.039 50V			DPMS6S39	PVC6139		6PS-S39
C195	10 NPO 50V	(1)	DTZ-10	NP010	CN0410		10TCC-Q10
	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C196	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C197	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C198	.1 50V	(1)		DPMS2P1	EWFA1A010	QF1-215	1PB-P10
	.039 50V			DPMS6S39	PVC6139		6PS-S39
C200	.01 50V			WMF1S1	EWFA1A110	QF1-91	1PB-S10
C202	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C204	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C205	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C206	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C207	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C208	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C209	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C210	.01 50V			WMF1S1	EWFA1A110	QF1-91	1PB-S10
C213	.1 50V		DC-104	MGP1	TA010	QC2-233	TG-P10
C214	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C215	.047 50V	(1)		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
	.022 50V			DPMS2S22	EWFA1A122	QF1-127	1PB-S22
C216	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C217	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C219	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C220	.047 50V	(1)		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
	.022 50V			DPMS2S22	EWFA1A122	QF1-127	1PB-S22
C221	.1 50V		DC-104	MGP1	TA010	QC2-233	TG-P10
C222	.1 50V		DC-104	MGP1	TA010	QC2-233	TG-P10
C223	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C225	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C227	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C228	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C231	.1 50V			DPMS2P1	EWFA1A010	QF1-215	1PB-P10
C233	.1 50V		DC-104	MGP1	TA010	QC2-233	TG-P10
C236	33 NPO 50V		DTZ-33	NP033	CN0433		10TCC-Q33
C239	.1 50V		DC-104	MGP1	TA010	QC2-233	TG-P10
C240	.01 50V			WMF1S1	EWFA1A110	QF1-91	1PB-S10
C242	47 NPO 50V		DTZ-47	NP047	CN0447		10TCC-Q47
C243	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C244	33 NPO 50V	(1)	DTZ-33	NP033	CN0433		10TCC-Q33
C245	.047 50V		DC-503	MGP05	TA150	QC2-207	TG-S50
C247	.047 50V		DC-503	MGP05	TA150	QC2-207	TG-S50
C248	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C249	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C250	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C251	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C255	.001 50V		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C257	27 NPO 50V	(1)			CN0427		10TCC-Q27
	68 NPO 50V		DTZ-68	NP068	CN0468		10TCC-Q68
C258	330 50V		DD-331	GP330	GP333		10TS-T33
C259	.039 50V			DPMS6S39	PVC6139		6PS-S39
C260	.047 50V		DC-503	MGP05	TA150	QC2-207	TG-S50
C261	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C262	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C265	.047 50V		DC-503	MGP05	TA150	QC2-207	TG-S50
C266	.047 50V		DC-503	MGP05	TA150	QC2-207	TG-S50
C268	100 NPO 50V		DTZ-100	NP0100	CN0310		10TCC-T10
C269	270 50V		DD-271	GP270	GP327		10TS-T27
C270	470 50V		DD-471	GP470	GP347		10TS-T47
C277	.047 50V		DC-503	MGP05	TA150	QC2-207	TG-S50
C278	.047 50V		DC-503	MGP05	TA150	QC2-207	TG-S50
C280	27 NPO 50V				CN0427		10TCC-Q27
C281	.047 50V		DC-503	MGP05	TA150	QC2-207	TG-S50
C282	.047 50V		DC-503	MGP05	TA150	QC2-207	TG-S50
C285	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C286	.0047 50V		DD-472	GP4700	GP247		5GA-D47
C287	.1 50V		DC-104	MGP1	TA010	QC2-233	TG-P10
C288	5 NPO 50V		DTZ-4R7	NP04P7	CN0547		10TCC-V47

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA				
			CENTRALAB PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
						Q-LINE	GENERAL LINE
C289	.001 50V		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C290	.047 50V			DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C301	.039 50V			DPMS6S39	PVC6139		6PS-S39
C303	.039 50V			DPMS6S39	PVC6139		6PS-S39
C308	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C310	.01 50V		UC-103	MGP01	TA110	QC2-141	TG-S10
C401	.047 50V			DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C403	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C404	.01 50V		UC-103	MGP01	TA110	QC2-141	TG-S10
C413	.01 50V		UC-103	MGP01	TA110	QC2-141	TG-S10
C414	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C415	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C416	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C418	.1 50V		DC-104	MGP1	TA010	QC2-233	TG-P10
C419	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C420	.001 50V		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C421	.001 50V		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C422	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C423	.022 50V		DC-203	MGP02	TA120	QC2-157	TG-S20
C424	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C425	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C426	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C601	8 NPO 50V		DTZ-6R8	NP06P8	CN0568		10TCC-V68
C602	.0047 50V		UD-472	GP4700	GP247		5GA-D47
C603	.01 50V		DC-103	MGP01	TA110	QC2-141	TG-S10
C604	39 NPO 50V				CN0439		10TCC-Q39
C606	.01 50V	1800-103	DC-103	MGP01	TA110	QC2-141	TG-S10
C701	.01 50V	1800-103	DC-103	MGP01	TA110	QC2-141	TG-S10
C703	.01 50V	1900-203	DC-103	MGP01	TA110	QC2-141	TG-S10
C704	.01 50V	1900-203	DC-103	MGP01	TA110	QC2-141	TG-S10
C705	.01 50V	1900-203	DC-103	MGP01	TA110	QC2-141	TG-S10
CC1	50V	1800-103					
CC2	50V	1800-103					
CT1	20 50V	1900-203					
CT2	20 50V	1900-203					
CT3	20 50V	1900-203					
CT4	20 50V	1900-203					
CT5	20 50V	1900-203					
CT6	20 50V	1900-203					
CT7	20 50V	1900-203					

* Not normally in distributor's stock. Available thru distributor on order to manufacturer.

(1) Used in some versions.

PRESIDENT MODEL MADISON

CONTROLS (All wattages 1/2 watt, or less, unless listed)

ITEM No.	FUNCTION	RESISTANCE	REPLACEMENT DATA				
			MFR. PART No.	CENTRALAB PART No.	CLAROSTAT PART No.	MALLORY PART No.	TRW PART No.
RT301	Volt Adj	300	1900-221	T-300		MTC32L1	X201R351B
VR1	Reg Meter	20K	1900-223				U260R253B
VR2	RF Gain Range	200K	1900-224				U260R254B
VR3	Squelch Range	100K	1900-219				U260R104B
VR4	Balance	50K	1900-218				U260R503B
VR5	AM Gain Range	500K	1900-225				U260R504B
VR7	AM AMC	5000	1900-216				U260R502B
VR8	AM Reg	10K	1900-217				U260R103B
VR9	34.9825MHz	5000	1900-216				U260R502B
VR12	Xmit Meter	100K	1900-219				U260R104B
VR14	Mod	100K	1900-219				U260R104B
VR15	Bias	300	1900-222				
VR16	Bias	300	1900-222				
VR401	Clarifier	20K	3000-105				
VR402	RF Meter	100K	3000-114				
VR403-1	SWR/CAL	5000	3000-116(18)				
VR403-2	SWR/CAL	5000					
VR404	Squelch	100K	3000-120(19)				
VR405	Volume/Power Switch	10K					
VR406	Tone	10K	3000-105				
VR408	Mic Gain	10K	3000-105				

(18) Includes VR403-1 and VR403-2.

(19) Includes VR404, VR405 and S406.

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

RESISTORS (Power and Special)

ITEM No.	RATING	REPLACEMENT DATA		ITEM No.	RATING	REPLACEMENT DATA	
		WORKMAN PART No.	MFR. PART No.			WORKMAN PART No.	MFR. PART No.
R404 RR1	10 5W Resistor Network	5W-SQ-10	1900-601 1800-104	RR401 RR402	Resistor Network Resistor Network		1900-402 1900-402

COILS (RF-IF)

ITEM No.	FUNCTION	REPLACEMENT DATA			REMARKS	
		PART No.	OTHER IDENTIFICATION	MILLER PART No.		
L1	Noise Blanker (23.5MHz)	2200-001	LA-029	CBS740-T		
L2	Noise Blanker (23.5MHz)	2200-054	LA-060			
L3	Rec Antenna (27MHz)	2200-024	LA-152			
L4	Rec RF (27MHz)	2200-026	LA-156			
L5	IF (7.8MHz)	2200-033	LA-178			
L6	IF (7.8MHz)	2200-029	LA-179			
L7	IF (7.8MHz)	2200-022	LA-038			
L8	IF (7.8MHz)	2200-023	LA-096			
L9	RF Choke (470uH)	2200-040	LZ-012			
L10	Filter (56mH)	2200-041	LZ-015			
L11	Filter (68mH)	2200-042	LZ-015	CBS512-7TC CBS511-7TC		
L12	RF Choke (470uH)	2200-040	LZ-012			
L13	RF Choke (470uH)	2200-040	LZ-012			
L14	RF Choke (470uH)	2200-040	LZ-012			
L16	VCO	2200-055	LA-195			
L17	VCO	2200-031	LA-191			
L19	RF Choke (100uH)	2200-202	LZ-012			
L20	RF Choke (470uH)	2200-040	LZ-012			
L21	RF Choke (470uH)	2200-040	LZ-012			
L22	RF Choke (470uH)	2200-040	LZ-012			
L23	RF Choke (470uH)	2200-040	LZ-012	CB304		
L24	Tripler (33MHz)	2200-030	LA-190			
L25	RF Choke (470uH)	2200-040	LZ-012			
L27	TVI Trap (54MHz)	2200-020	LC-018			
L28	Antenna Match	2200-060	LE-068			
L29	Pi Filter	2200-060	LE-068			
L30	Final (27MHz)	2200-056	LC-019			
L31	RF Choke	2200-036	LD-018			
L32	Xmit Driver (27MHz)	2200-020	LC-018			
L33	RF Choke	2200-036	LD-018	CB304		
L34	RF Choke	2200-036	LD-018			
L35	Xmit Predriver (27MHz)	2200-037	LD-057			
L36	Xmit Amp (27MHz)	2200-037	LD-057	CBS512-7TC		
L37	Xmit Mixer (27MHz)	2200-027	LA-196			
L38	RF Choke (470uH)	2200-040	LZ-012			
L39	Carrier Inj (7.8MHz)	2200-022	LA-038			
L43	RF Choke (1uH)	2200-206	LZ-002			
L44	RF Choke (1uH)	2200-206	LZ-002			
L45	RF Choke (100uH)	2200-202	LZ-012			
L46	RF Choke (10uH)	2200-205	LZ-001			
L48	IF (7.8MHz)	2200-061	LD-096			
L50	RF Choke (470uH)	2200-040	LZ-012			
L401	RF Choke	2200-059	LD-089			
L405	RF Choke	2200-059	LD-089			
L406	RF Choke	2200-059	LD-089			
L407	RF Choke	2200-035	LD-013			
L408	RF Choke	2200-035	LD-013			
L409	RF Choke	2200-059	LD-089			
L410	RF Choke	2200-059	LD-089			
L421	RF Choke	2200-062	LD-094			
L701	RF Choke	2200-059	LD-089			
L702	RF Choke	2200-059	LD-089			
L703	RF Choke	2200-059	LD-089			

FILTER CHOKE

ITEM No.	RATINGS			REPLACEMENT DATA			NOTES
	CURRENT (Measured)	DC RES.	INDUCTANCE (0 CURRENT 1000~)	MFR. PART No.	THORDARSON PART No.	TRIAD PART No.	
T402	2.4A	.238	2.85mH	2300-003			

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

TRANSFORMER (Audio Output)

ITEM No.	IMPEDANCE		REPLACEMENT DATA			NOTES
			MFGR. PART No.	THORDARSON PART No.	TRIAD PART No.	
T1	5.12	8	2600-006 TF-109(1)		MCB-20	(1) Number on unit.

TRANSFORMER (Power)

ITEM No.	RATING		REPLACEMENT DATA			NOTES
			MFGR. PART No.	THORDARSON PART No.	TRIAD PART No.	
T401	120V AC @ .460A	20.0V @ 4.68A	2600-007 TF-108(1)			(1) Number on unit.

SPEAKER

ITEM No.	TYPE	REPLACEMENT DATA		NOTES
		MFGR. PART No.	QUAM PART No.	
SP401	4" PM, 8 Ohms	3100-001		

FUSE DEVICES

ITEM No.	DESCRIPTION	REPLACEMENT DATA						
		PART No.		BUSS PART No.		LITTELFUSE PART No.		WORKMAN PART No.
		DEVICE	HOLDER	DEVICE	HOLDER	DEVICE	HOLDER	DEVICE
F401	4 Amp	2800-003	2700-004	AGC4	HDJ	311004	150145	
F402	4 Amp	2800-003	2800-004	AGC4	HKP	311004	342001L	

MICROPHONE

ITEM No.	REPLACEMENT DATA				CONNECTION DATA						
	MFGR. PART No.	GC PART No.	GC NOISE CANCEL	GC POWER	GC CONNECTOR	GC Red	GC Shield	GC Yellow	GC Blue	GC White	GC Black
MIC	3200-003	18-032	18-034	18-010	18-092	2	1	3	NC	NC	1

PRESIDENT MODEL MADISON

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

MISCELLANEOUS

ITEM No.	PART NAME	PART No.	NOTES
D401	LED	2000-306	Channel Display (13.5mA @ 1.85V)
D403	LED	2000-307	LSB Indicator (15mA @ 1.62V)
D404	LED	2000-307	USB Indicator (15mA @ 1.62V)
D405	LED	2000-307	AM Indicator (15mA @ 1.62V)
D407	LED	2000-307	TX (12mA @ 1.68V)
FT1	Crystal Filter	2100-001	7.8MHz
FT2	Crystal Filter	2100-002	7.8MHz
J401	Jack	1100-002	Antenna
J402	Jack	1100-004	Microphone
J403	Jack	1100-001	PA
J404	Jack	1100-001	External Speaker
J405	Jack	1100-014	Phone
J406	Jack	1100-003	DC Power
J407	Jack	1100-016	AC Power
L26	Ferrite Bead	2200-057	
L47	Ferrite Bead	2200-058	
M401	Meter	2900-005	S/R
M402	Meter	2900-007	SWR/MOD
M	Clock	3600-001	Digital
PL401	Lamp	2500-001	S/R Meter (44mA @ 11.64V)
PL402	Lamp	2500-001	SWR/MOD (44mA @ 11.64V)
REL1	Relay	2400-002	Xmit/Rec
S401	Switch	3000-003	NB
S402	Switch	3000-103	AM/USB/LSB
S403	Switch	3000-003	SWR/RF-MOD
S404	Switch		AC Power (Part of Clock)
S405	Switch	3000-003	CB/PA
S406	Switch		Power (Part of Volume Control)
S408	Switch	3000-105	Channel Selector
S409	Switch		Power Conversion (Part of AC Power Jack)
X1	Crystal	2100-004	7.8025MHz
X2	Crystal	2100-005	7.7975MHz
X3	Crystal	2100-008	11.285MHz
X4	Crystal	2100-006	11.2842MHz
X5	Crystal	2100-009	10.240MHz
X6	Crystal	2100-007	11.865MHz
	Printed Circuit Board	3500-014	Main (PC-346AA)
	Printed Circuit Board	3500-022	Channel Selector Switch (PC-259AA)
	Printed Circuit Board	3500-009	Power Supply (PC-006EB)
	Printed Circuit Board	3500-023	Push Switch (PC-277AA)
	Printed Circuit Board	3500-024	Noise Blanking (PC-244AA)
	Printed Circuit Board	3500-025	PA-External Speaker Jack (PC-246AA)
	Printed Circuit Board	3500-026	Microphone Jack (PC-275AA)
	Printed Circuit Board	3500-028	TR401-TR402 (PC-298AA)
	Socket	1400-002	Crystal (SK-001)
	Socket	1400-001	Relay (SK-018)
	Power Cord	2700-004	AC
	Power Cord	2700-001	DC

CABINETS & CABINET PARTS (When ordering specify model, chassis & color)

ITEM	PART No.	ITEM	PART No.
Knob, Channel	1300-004	Knob, Clock (Sleep)	1300-013
Knob, Volume	1300-012	Cabinet (Transceiver)	3300-815
Knob, Squelch	1300-011	Plate (Transceiver, Bottom)	3300-810
Knob, Mike Gain/RF Gain/SWR-CAL/Clarifier/Tone	1300-002	Cabinet (Speaker)	3300-811
Knob, Mode Switch	1300-005	Plate (Speaker Bottom)	3400-512
Knob, SWR-RF MOD/NB/PA-CB	1300-003	Microphone Hanger	3300-401
Knob, Clock (Alarm-Time Set)	1300-015	Escutcheon (Transceiver)	3400-511
Knob, Clock (Select)	1300-014	Escutcheon (Speaker)	3400-513

WIRING DATA

General-use Hook-up Wire (available in 5 colors)	BELDEN No. 8523	Coiled Microphone Cable	
Shielded Hook-up Wire (spiral wrapped)	BELDEN No. 8421	3-conductor (1 shielded) 23AWG	BELDEN No. 9471 (5')
(braided)	BELDEN No. 8401		BELDEN No. 8497 (6')
Speaker Cable (available in 4 colors)	BELDEN No. 8782		BELDEN No. 9472 (7-1/2')
Bonding Strap	BELDEN No. 8672		28AWG BELDEN No. 9466 (6')
AC Power Cord	(6') BELDEN No. 17106		31AWG BELDEN No. 9468 (10')
	(9') BELDEN No. 17109	4-conductor (unshielded) 23AWG	BELDEN No. 8415 (6')
		5-conductor (1 shielded) 28AWG	BELDEN No. 9467 (6')
			BELDEN No. 9465 (7-1/2')



PHOTOFACT[®] with

CIRCUITRACE[®]

For Supplier Address See PHOTOFACT Index

NOTE

Repair or adjustment of transmitter circuits must be under supervision of a person with first-or second-class radiotelephone license.

(Refer to FCC Rules and Regulations Part 95, Subpart C & D.)

The frequency of the transmitter should be checked periodically with a secondary frequency standard to insure proper and legal operation.

Best results will be obtained when adjusting the final RF output circuit if the antenna normally used is connected and the chassis is as nearly in the cabinet as possible.

Connect either 50-ohm dummy load or the normally used antenna system.



MODEL 1-673

MANUFACTURER'S SPECIFICATIONS

RECEIVER

- | | |
|---|----------------------------------|
| 1. Frequency Range (MHz) | : 26.965- 27.405. |
| 2. Sensitivity | : 0.5uV for 10db S+N/N |
| 3. Selectivity | 5KHz minimum at 6db down |
| 4. Adj. Channel Rejection | : More than 60db. |
| 5. Audio Power output at 8 ohms | : More than 4W at 10% distortion |
| 6. Audio fidelity (1KHz=0db, 6db down) | : 400Hz-2,000Hz |
| 7. A.G.C. figure of merit (Input 94db for 10db range) | : More than 80db |
| 8. Squelch sensitivity (Threshold) | : Less than 0.5uV |
| 9. Spurious Rejection | : More than 45db |

TRANSMITTER

- | | |
|--------------------------|-------------------|
| 1. Frequency Range (MHz) | : 26.965— 27.405. |
| 2. RF Output Power | : 4W average |
| 3. Modulation Capability | : 100% |
| 4. Spurious Suppression | : More than 60db. |
| 5. Frequency Tolerance | : $\pm 0.005\%$ |

Courtesy of the Manufacturer

ROYCE MODEL 1-673

HOWARD W. SAMS & CO., INC. Indianapolis, Indiana 46206

© 1978 Howard W. Sams & Co., Inc. Printed in U. S. of America 8CE742

ALIGNMENT INSTRUCTIONS

CAUTION: Use isolation transformer or observe polarity when connecting test equipment. Maintain line voltage at 120V AC. Allow a 15-minute warm-up period.

Adjustments made with 13.8-volt DC input.

Connect low sides of test equipment to ground unless specified otherwise.

Connect 50-ohm dummy load or antenna before keying transmitter.

Suggested Alignment Tools: GC ELECTRONICS:

T201.....5009, 8728-A, 8728

T101, T102.....9440

L403, L404, T401, T402.....9091, 8728-A, 8728

SYNTHESIZER ALIGNMENT

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Input of frequency counter to TP1 (PLL-1, Pin 2).	Ch.1		Check for 10.240MHz.
Input of frequency counter to TP2 (PLL-1, Pin 19).	Ch.1		Check for 37.660MHz. Check all channels. (See Truth Chart for correct frequencies).
Input of frequency counter to TP4 (PLL-1, Pin 23).	Ch.1, Xmt		Check for 26.965MHz. Check all channels. (See Truth Chart for correct frequencies).

RECEIVER ALIGNMENT


Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.
Set generator output low enough to prevent AGC limiting.

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to TP5 (Q201, base). 455kHz, 1000Hz @ 30% modulation.	Ch. 19, Squelch-MINIMUM ANL-Off	T201	Adjust for maximum output.
Output of signal generator thru .01uF to antenna Jack. 27.185MHz, 1000Hz @ 30% modulation.	Ch. 19, Squelch-MINIMUM ANL-Off	T102,T101	Adjust for maximum output. If necessary readjust T201.

TRANSMITTER ALIGNMENT

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.
NOTE: Be sure to check transmit frequency and power on all active channels after alignment of transmitter.
See page 4 for channel frequencies.

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
	Ch. 19	T401,T402, L403,L404	Adjust for maximum.
	Ch. 19	T402	Adjust for 4 watts maximum.




CHASSIS-BOTTOM

TRUTH CHART


1 = <u>7.58</u> Volts 0 = <u>0</u> Volts								
C H A N N E L	PLL-1 PROGRAM DIVIDER						REC VCO OUTPUT IN MHz AT TP2	XMT VCO OUTPUT IN MHz AT TP3
	PINS							
	6	5	7	8	10	9		
1	0	0	0	0	0	0	37.660	26.965
2	0	0	0	0	0	1	37.670	26.975
3	0	0	0	0	1	0	37.680	26.985
4	0	0	0	1	0	0	37.700	27.005
5	0	0	0	1	0	1	37.710	27.015
6	0	0	0	1	1	0	37.720	27.025
7	0	0	0	1	1	1	37.730	27.035
8	0	0	1	0	0	1	37.750	27.055
9	0	0	1	0	1	0	37.760	27.065
10	0	0	1	0	1	1	37.770	27.075
11	0	0	1	1	0	0	37.780	27.085
12	0	0	1	1	1	0	37.800	27.105
13	0	0	1	1	1	1	37.810	27.115
14	0	1	0	0	0	0	37.820	27.125
15	0	1	0	0	0	1	37.830	27.135
16	0	1	0	0	1	1	37.850	27.155
17	0	1	0	1	0	0	37.860	27.165
18	0	1	0	1	0	1	37.870	27.175
19	0	1	0	1	1	0	37.880	27.185
20	0	1	1	0	0	0	37.900	27.205

1 = 7.58 Volts 0 = 0 Volts								
CHANNEL	PLL-1 PROGRAM DIVIDER						REC VCO OUTPUT IN MHZ AT TP2	XMT VCO OUTPUT IN MHZ AT TP3
	PINS							
	6	5	7	8	10	9		
21	0	1	1	0	0	1	37.910	27.215
22	0	1	1	0	1	0	37.920	27.225
23	0	1	1	1	0	1	37.950	27.255
24	0	1	1	0	1	1	37.930	27.235
25	0	1	1	1	0	0	37.940	27.235
26	0	1	1	1	1	0	37.960	27.265
27	0	1	1	1	1	1	37.970	27.275
28	1	0	0	0	0	0	37.980	27.285
29	1	0	0	0	0	1	37.990	27.295
30	1	0	0	0	1	0	38.000	27.305
31	1	0	0	0	1	1	38.010	27.315
32	1	0	0	1	0	0	38.020	27.325
33	1	0	0	1	0	1	38.030	27.335
34	1	0	0	1	1	0	38.040	27.345
35	1	0	0	1	1	1	38.050	27.355
36	1	0	1	0	0	0	38.060	27.365
37	1	0	1	0	0	1	38.070	27.375
38	1	0	1	0	1	0	38.080	27.385
39	1	0	1	0	1	1	38.090	27.395
40	1	0	1	1	0	0	38.100	27.405




ROYCE MODEL 1-673


MOTHER BOARD




U-1 BOARD




U-1 BOARD




U-2 BOARD




U-2 BOARD




U-3 BOARD




U-3 BOARD




U-4 BOARD




U-4 BOARD



MOTHER BOARD



BLOCK DIAGRAM



Terminal Guides



Q101
Bottom view




Q102, Q201,
Q202, Q203,
Q204, Q205,
Q401
Bottom view



Q207, Q206,
Q301
Bottom view




Q402
Front view



Q303
Front view



Q403
Bottom view




LED 1001, 1002
Rear view

- ✖ Circuitry not used in some versions
 - Circuitry used in some versions
 - ⊕ See parts list
 - ✱ Nominal value
 - ⊥ Ground
 - ⏏ Chassis
 - ▽ Common tie point
- Measurements made in Channel 1 with switching as shown unless noted.
Item numbers in rectangles appear in the alignment/adjustment instructions.
Supply voltage maintained as shown at input.
Voltages measured with digital meter, no signal.
Controls adjusted for normal operation.
Arrow at control indicates direction of advance.
Terminal identification may not be found on unit.
Resistors are 1/2 W or less, 5% unless noted.
Value in () used in some versions.

A PHOTOFACT STANDARD NOTATION SCHEMATIC.

WITH **CIRCUITRACE**

© Howard W. Sams & Co., Inc. 1978



PARTS LIST AND DESCRIPTION
(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA									
			GENERAL ELECTRIC PART No.	MALLORY PART No.	MOTOROLA PART No.	RAYTHEON PART No.	RCA PART No.	SPRAGUE PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
D101	100-1		GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
D102a	100-1		GE-504A	PTC201	HEPR0052	RE 49	SK3030	RT-213	ECG116	1N4004	WEP156	212-61
D102b	EQB01-09		GEZD-5.1		HEPZ0406		SK3056	RT-235		1N4733A	WEP1103	
D201	1N60		1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
D202	1N60		1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109	1N60	WEP134	ZEN-430
D203	1S2075K		GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177		WEP1062	
D204	1N60		1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109		WEP134	
D205	WG713		GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177		WEP1062	
D206	HV-23		GE-300	PTC301		RE 250			ECG601			
D207	HV-23			PTC301		RE 250			ECG601			
D301	100-1		GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177		WEP1062	
D303	100-1		GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177	1N60	WEP1062	ZEN-430
D401	1N60		1N60	PTC206	HEPR9135	RE 47	SK3088	RT-263	ECG109		WEP134	
DM1	100-1		GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177		WEP1062	
DM3	100-1		GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177		WEP1062	
DM4	1S2075K		GE-300	PTC214	HEPR0602	RE 52	SK3100	RT-218	ECG177		WEP1062	
Q101	2SC1856		GE-81	PTC121	HEPS0010	RE 10	SK3018	RT-107A	ECG108		WEP56	ZEN-104
Q102	2SC710		GE-211*	PTC132	2SC710	RE 13*	SK3018*	RT-308*	ECG123A*	2SC710	WEP710	ZEN-114
	2SC710C		GE-211*	PTC132	2SC710	RE 13*	SK3018*	RT-308*	ECG123A*	2SC710	WEP710	ZEN-114
Q201	2SC711		GE-211*	PTC132	2SC710	RE 13*	SK3018*	RT-308*	ECG123A*	2SC710	WEP710	ZEN-114
	2SC711E		GE-211*	PTC132	2SC710	RE 13*	SK3018*	RT-308*	ECG123A*	2SC710	WEP710	ZEN-114
Q202	2SC711		GE-211*	PTC132	2SC710	RE 13*	SK3018*	RT-308*	ECG123A*	2SC710	WEP710	ZEN-114
	2SC711E		GE-211*	PTC132	2SC710	RE 13*	SK3018*	RT-308*	ECG123A*	2SC710	WEP710	ZEN-114
Q203	2SC711		GE-211*	PTC132	2SC710	RE 13*	SK3018*	RT-308*	ECG123A*	2SC710	WEP710	ZEN-114
	2SC711D		GE-211*	PTC132	2SC710	RE 13*	SK3018*	RT-308*	ECG123A*	2SC710	WEP710	ZEN-114
	2SC710D		GE-62*	PTC121	2SC711	RE 192*	SK3124*	RT-302*	ECG199*	2SC711	WEP66*	ZEN-116
Q204	2SA695		GE-48	PTC144*	HEPS3012*	RE 18*	SK3025*	RT-115*	ECG129*		WEP60*	
	2SA695D		GE-48	PTC144*	HEPS3012*	RE 18*	SK3025*	RT-115*	ECG129*		WEP60*	
Q205	2SC620		GE-20*	PTC125*	2SC620	RE 13*	SK3020*	RT-107A*	ECG123A*	2SC620	WEP736*	ZEN-127
	2SC620D		GE-20*	PTC125*	2SC620	RE 13*	SK3020*	RT-107A*	ECG123A*	2SC620	WEP736*	ZEN-127
Q206	2SC945L		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945Q		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
Q207	2SC945		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
	2SC945Q		GE-212	PTC121*	2SC945	RE 192	SK3124	RT-107A	ECG199	2SC945	WEP1945	121-Z9000
Q301	2SB561B		GE-82	HEPS0019		RE 26	SK3114	RT-126A	ECG159		WEP740	
Q302	2SC711		GE-62*	PTC121	2SC711	RE 192*	SK3124*	RT-302*	ECG199*	2SC711	WEP66*	ZEN-116
	2SC711E		GE-62*	PTC121	2SC711	RE 192*	SK3124*	RT-302*	ECG199*	2SC711	WEP66*	ZEN-116
Q303	AN315								ECG1240			
Q401	2SC1908E		GE-20*	PTC136*	HEPS0015*	RE 9*	SK3124*	RT-107A*	ECG107*	2SC380*	WEP535*	
Q402	2SC1728		GE-275			RE 204		RT-310	ECG302		WEP918	
Q403	2SC756A	(12)	GE-46	PTC158		RE 206		RT-306F	ECG282		WEP909	

* Lead configuration may vary from original.
(12) 10 WATTS @ 4 AMPS.

ELECTROLYTIC CAPACITORS

ITEM No.	RATING	REPLACEMENT DATA				
		MFR. PART No.	CORNELL- DUBILIER PART No.	MALLORY PART No.	SPRAGUE	PART No.
					Q-LINE	GENERAL LINE
C107	10 16V		WBR10-25	TT15X10	QE1-177	TVA-1145
C114A	220 16V		WBR250-16	TT15X260A	QE1-495	TVA-1161
C206	.33 50V			TDC334M050EL	QDT1-14	SD50-R339
C208	1 50V		WBR1-50	TT50X1	QE1-11	TVA-1300
C211	47 10V		WBR50-25	TT10X50A	QE1-351	TVA-1150
C301	1 50V		WBR1-50	TT50X1	QE1-11	TVA-1300
C302	22 10V		WBR25-25	TT10X25	QE1-291	TVA-1148
C304	1 50V		WBR1-50	TT50X1	QE1-11	TVA-1300
C305	.22 25V			TDC224M050EL	QDT1-10	SD50-R229
C306	1 50V		WBR1-50	TT50X1	QE1-11	TVA-1300
C307	47 10V		WBR50-25	TT10X50A	QE1-351	TVA-1150
C312	47 10V		WBR50-25	TT10X50A	QE1-351	TVA-1150
C316	1000 16V		WBR1000-16	TT15X1000B	QE1-591	TVA-1163
C318	47 10V		WBR50-25	TT10X50A	QE1-351	TVA-1150
C319	10 16V		WBR10-25	TT15X10	QE1-177	TVA-1145
C320	47 10V		WBR50-25	TT10X50A	QE1-351	TVA-1150
C323	1 25V		WBR1-50	TT25X1	QE1-11	TVA-1300
C324	47 10V		WBR50-25	TT10X50A	QE1-351	TVA-1150
CM4	1000 16V		PC1000-16	VTT1000L16	QV1-183	EV-1260
CM7	220 16V		PC250-25	VTT220H16	QV1-117	EV-1240
CM8	220 16V		PC250-25	VTT220H16	QV1-117	EV-1240
CM13	47 16V		PC50-16	VTT47D16	QV1-73	EV-1226

CAPACITORS

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA					
			CENTRALAB PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.		
						Q-LINE	GENERAL LINE	
C101	82 N750		DTN-220	N220	CN7482		10TCU-Q82	
C102	220 N750				CN7322		10TCU-T22	
C103	22 N220				*		10TCR-Q22	
C104	.022		DC-253	MGP025	TA125		TG-S25	
C105	.022		DC-253	MGP025	TA125		TG-S25	
C106	.022		DC-253	MGP025	TA125		TG-S25	
C108	.022		DC-253	MGP025	TA125		TG-S25	
C109	22 N220				*		10TCR-Q22	
C110	.022		DC-253	MGP025	TA125		TG-S25	
C111	.022		DC-253	MGP025	TA125		TG-S25	
C112	.022		DC-253	MGP025	TA125		TG-S25	
C113	.001		DD-102G	GP1000	GP210		QC2-81	5GA-D10

PARTS LIST AND DESCRIPTION (CONTINUED)
(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA				
			CENTRALAB PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
						Q-LINE	GENERAL LINE
C114B	33 N220				*		10TCR-Q33
C115	.022		DC-253	MGP025	TA125		TG-S25
C201	.022		DC-253	MGP025	TA125		TG-S25
C202	220 N750		DTN-220	N220	CN7322		10TCU-T22
C203	.039		UK50-333		MAG50133		
C204	.022		DC-253	MGP025	TA125		TG-S25
C205	.001		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C207	.01			WMF1S1	EWF1A110	QF1-91	1PB-S10
C209	.039		UK50-333		MAG50133		
C210	.022		DC-253	MGP025	TA125		TG-S25
C212	.039		UK50-333		MAG50133		
C303	.022		DC-253	MGP025	TA125		TG-S25
C308	.01			WMF1S1	EWF1A110	QF1-91	1PB-S10
C310	.039			DPMSG539	PVC6139		6PS-S39
C314	.001		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C321	.001		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C322	.001		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C401	.022		DC-253	MGP025	TA125		TG-S25
C402	.022		DC-253	MGP025	TA125		TG-S25
C403	68 N220				*		10TCR-Q68
C404	.022		DC-253	MGP025	TA125		TG-S25
C405	39 N220				*		10TCR-Q39
C406	.022		DC-253	MGP025	TA125		TG-S25
C407	.022		DC-253	MGP025	TA125		TG-S25
C408	.001		DD-102G	GP1000	GP210	QC2-81	5GA-D10
C409	82 N220				*		10TCR-Q82
C410	22 N220				*		10TCR-Q22
C411	220 N750		DTN-220	N220	CN7322		10TCU-T22
C412	100 N470				*		10TCT-T100
C413	220 N750		DTN-220	N220	CN7322		10TCU-T22
C414	39 N220				*		10TCR-Q39
C415	2 NPO		DTZ-2R2	NP02P2	CN0522		10TCC-V22
C416	120 N750		DTN-120				10TCU-T12
C417	.022		DC-253	MGP025	TA125		TG-S25
C418	.022		DC-253	MGP025	TA125		TG-S25
C419	10 NPO		DTZ-10	NP010	CN0410		10TCC-Q10
CM1	.01		DC-103	MGP01	TA110	QC2-141	TG-S10
CM2	.01		DC-103	MGP01	TA110	QC2-141	TG-S10
CM5	.039		UK50-333		MAG50133		
CM6	560		DD-561		GP356		10TS-T56
CM9	.039		UK50-333		MAG50133		
CM10	.039		UK50-333		MAG50133		
CM11	.039		UK50-333		MAG50133		
CM12	.039		UK50-333		MAG50133		
CM15	560		DD-561		GP356		10TS-T56
CM16	.01		DC-103	MGP01	TA110	QC2-141	TG-S10
CM17	8 NPO		DTZ-6R8	NP06P8	CN0568		10TCC-V68
CM18	560		DD-561		GP356		10TS-T56
CM29	120 NPO		DTZ-120		CN0312		10TCC-T12
CM31	.039		UK50-333		MAG50133		
CM32	32		DTZ-33	NP033	CN0433		10TCC-Q33
CM33	.022		DC-253	MGP025	TA125		TG-S25
CM34	.001		DD-102G	GP1000	GP210	QC2-81	5GA-D10
CM36	560		DD-561		GP356		10TS-T56
CM37	560		DD-561		GP356		10TS-T56
CM38	.001		DD-102G	GP1000	GP210	QC2-81	5GA-D10
CM39	.001		DD-102G	GP1000	GP210	QC2-81	5GA-D10
CM40	.001		DD-102G	GP1000	GP210	QC2-81	5GA-D10
CM41	.001		DD-102G	GP1000	GP210	QC2-81	5GA-D10

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

RESISTORS (Power and Special)

ITEM No.	RATING	REPLACEMENT DATA		ITEM No.	RATING	REPLACEMENT DATA	
		WORKMAN PART No.	MFGR. PART No.			WORKMAN PART No.	MFGR. PART No.
THM1	550 Cold NTC		TD5-165				

COILS (RF-IF)

ITEM No.	FUNCTION	REPLACEMENT DATA			REMARKS
		PART No.	OTHER IDENTIFICATION	MILLER PART No.	
L101 L301 L401 L402 L403 L404 T101 T102 T201 T401 T402	RF Choke RF Choke RF Choke RF Choke Final(27MHz) Pi Filter(27MHz) Rec Antenna(27MHz) Rec RF(27MHz) IF(455kHz) Xmt Amp(27MHz) Xmt Driver(27MHz)		ETC15089 ETC15061 ETC15090	CBS774 CBS708-TC CBS506-4TC	

FILTER CHOKE

ITEM No.	RATINGS			REPLACEMENT DATA			NOTES
	CURRENT (Measured)	DC RES.	INDUCTANCE (0 CURRENT 1000~)	MFGR. PART No.	THORDARSON PART No.	TRIAD PART No.	
TM1 TM2	1.4A 1.4A	.1 .1	1.45mH 1.45mH	1002(1) 1002(1)	TR509 TR509		(1) Number on Unit

TRANSFORMER (Audio Output)

ITEM No.	IMPEDANCE		REPLACEMENT DATA			NOTES
	PRI.	SEC.	MFGR. PART No.	THORDARSON PART No.	TRIAD PART No.	
T301	3.92	1 8 20.48	62017(1)	TR827		(1) Number on Unit

SPEAKER

ITEM No.	TYPE	REPLACEMENT DATA		NOTES
		MFGR. PART No.	QUAM PART No.	
SP	3" PM. 8 Ohms		30A05Z8R	

(When ordering parts, state **Model**, **Part Number**, and **Description**.)

ITEM No.	DESCRIPTION	REPLACEMENT DATA							
		PART No.		BUSS PART No.		LITTELFUSE PART No.		WORKMAN PART No.	
		DEVICE	HOLDER	DEVICE	HOLDER	DEVICE	HOLDER	DEVICE	
M16	2 Amps			AGC2	HDJ	312002	150145	FG2-2	

ITEM No.	REPLACEMENT DATA				CONNECTION DATA						
	MFGR. PART No.	GC PART No.	GC NOISE CANCEL	GC POWER	GC CONNECTOR	GC Red	GC Shield	GC Yellow	GC Blue	GC White	GC Black
MIC		18-032	18-034	18-010	18-092	1	2	3	NC	NC	2

ITEM No.	PART NAME	PART No.	NOTES
F101	Ceramic Filter		10.7MHz
F201	Ceramic Filter		455kHz
F202	Ceramic Filter		455kHz
LEDP1	LED		TX Indicator
M1	Meter		S/R
M3	Ferrite Bead		
M4	Ferrite Bead		
M5	Lamp		Channel Indicator(45mA @ 13.78V)
M6	Jack		Power
M7	Jack		Antenna
M8	Jack		Microphone
M9	Jack		PA
M10	Jack		External Speaker
M11	Ferrite Bead		
M13	Ferrite Bead		
M14	Ferrite Bead		
M15	Lamp		Meter(29mA @ 10.13V)
PLM1	Relay		XT/REC
SM1	Switch		Power(Part of Volume Control)
SM2	Switch		CB/PA
SM3	Switch		ANL
SM4	Switch		Channel Selector

General-use Hook-up Wire (available in 5 colors)	BELDEN No. 8523	Coiled Microphone Cable	
Shielded Hook-up Wire (spiral wrapped)	BELDEN No. 8421	3-conductor (1 shielded) 23AWG	BELDEN No. 9471 (5')
(braided)	BELDEN No. 8401		BELDEN No. 8497 (6')
Speaker Cable (available in 4 colors)	BELDEN No. 8782		BELDEN No. 9472 (7-1/2')
Bonding Strap	BELDEN No. 8672	28AWG	BELDEN No. 9466 (6')
AC Power Cord (6')	BELDEN No. 17106	31AWG	BELDEN No. 9468 (10')
	(9') BELDEN No. 17109	4-conductor (unshielded) 23AWG	BELDEN No. 8415 (6')
		5-conductor (1 shielded) 28AWG	BELDEN No. 9467 (6')
			BELDEN No. 9465 (7-1/2')

