

PHOTOFACT[®] with

CIRCUITRACE[®]

For Supplier Address See PHOTOFACT Index

NOTE

Repair or adjustment of transmitter circuits must be under supervision of a person with first-or second-class radiotelephone license.

(Refer to FCC Rules and Regulations Part 95, Subpart C & D.)

The frequency of the transmitter should be checked periodically with a secondary frequency standard to insure proper and legal operation.

Best results will be obtained when adjusting the final RF output circuit if the antenna normally used is connected and the chassis is as nearly in the cabinet as possible.

Connect either 50-ohm dummy load or the normally used antenna system.



MODEL 5001 (77-005)

MANUFACTURER'S SPECIFICATIONS

General:

Voltage 13.8 V, Positive/
Negative Ground
Operating Range:
10 V to 16 V.

Frequency Stability ... $\pm 0.005\%$.

Temperature Range ... -30° to $+50^{\circ}$ C
(Per FCC Part 15).

Humidity 5-90%.

Vibration EIA Standard RS-424.

Shock EIA Standard RS-424.

Receiver (AM):

Sensitivity. —

Less than 0.7 μ V for 10 dB SN + N to N.

Automatic Gain Control Figure of Merit. —
80 dB.

Audio Squelch Sensitivity. —

Threshold: Less than 10 dB SN + N to N
Ratio.

Tight: 100 μ V minimum, 500 μ V
maximum.

Adjacent Channel Selectivity and
Desensitization. —

60 dB (Two-generator method).

Spurious Response Attenuation. —

60 dB (excluding image at 50 dB).

Audio Power Output. —

4 W @ 10% distortion (load impedance
8 ohms resistive).

Audio Frequency Response (1 KHz, 0 dB
reference) —

300 Hz @ -6 dB.

1000 Hz @ 0 dB.

3000 Hz @ -6 dB.

Hum and Noise, Squelched. —

-45 dB.

Noise Limiting. —

Provided with Switchable ANL and
noise blanker.

S Meter Sensitivity at "S-9" —
100 μ V.

RF Gain Range —
30 dB.

Antenna Input Impedance —
50 ohms, unbalanced

Transmitter (AM):

Carrier Power, No Modulation. —
4 W maximum, 3.6 minimum.

Conducted Spurious Emissions. —
-65 dB.

Radiated Spurious Emissions —
(FCC Part 95)

Audio Frequency Harmonic Distortion. —
10% maximum @ 80%

Audio Frequency Response (1 KHz, 0 dB
reference). —

300 Hz @ -6 dB.

1000 Hz @ 0 dB.

3000 Hz @ -6 dB.

6 dB/octave falling above 3000 Hz.

Hum and Noise. —

-40 dB.

Output Impedance. —

50 ohms, unbalanced.

Output Protection. —

Withstands for 5 minutes all VSWR
around Smith Chart at 20:1 without
damage or failure.

Output Stability. —

Shall not exceed FCC Spurious
emission requirements when operated
into a mismatch load with 5:1 VSWR at
any point on the Smith Chart.

MIDLAND MODEL 5001 (77-005)

Courtesy of the Manufacturer

HOWARD W. SAMS & CO., INC. Indianapolis, Indiana 46206

© 1980 Howard W. Sams & Co., Inc. Printed in U. S. of America 80CE1099

ALIGNMENT INSTRUCTIONS

CAUTION: Use isolation transformer or observe polarity when connecting test equipment. Maintain line voltage at 120V AC. Allow a 15-minute warm-up period. Adjustments made with 13.8 volt DC input. Connect low sides of test equipment to ground unless specified otherwise. Connect 50-ohm dummy load or antenna before keying transmitter. Connect microphone.

Suggested Alignment Tools: GC ELECTRONICS:
 T1 thru T8 9440
 T9, T10, T11 5000, 5009, 8276, 8728, 8728A, 9089
 CT1 5000, 8276, 9089
 L5 9300, 9302, 9304

SYNTHESIZER ALIGNMENT

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Input of frequency counter to TP1 (Q8 Base).	Ch. 19		Check for 10.240MHz $\pm$ 150Hz.
Input of DC meter to TP (Junction of R8 and R9).	Ch. 1	T1	Adjust for 2.00 volts $\pm$.1 volt. The voltage on channel 40 should be between 3.60 volts to 4.60 volts.
Input of DC meter to TP (Junction of R8 and R9).	Ch. 1, XMT	CT1	Adjust for 2.00 volts $\pm$.2 volt. The voltage on channel 40 should be between 3.30 volts to 4.60 volts.
Input of frequency counter to TP4 (IC2 Pin 9).	Ch. 1		Check for 6.030MHz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP4 (IC2 Pin 9).	Ch. 1, XMT		Check for 3.2425MHz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP5 (Junction of T1 and C21).	Ch. 1		Check for 16.270MHz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP5 (Junction of T1 and C21).	Ch. 1, XMT		Check for 13.4825MHz. Check all channels. (See Truth Chart for correct frequencies.)

RECEIVER ALIGNMENT

Connect an AC VTVM or AF wattmeter across speaker voice coil. Adjust volume control to obtain a suitable indication. Set generator output low enough to prevent AGC limiting. Squelch MINIMUM, RF Gain Maximum, Mic Gain Maximum, NB/ANL Off, 19/9/NOR NOR

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to TP1 (Q8 Base). 455kHz, 1000Hz @ 30% modulation.	Ch. 19	T11, T10	Adjust for maximum output.
Output of signal generator to antenna input. 27.185MHz, 1000Hz @ 30% modulation	Ch. 19	T5, T6, T7 T8, T9	Adjust for maximum output. Readjust T10 and T11 for maximum.

RECEIVER ADJUSTMENTS

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.
Squelch MINIMUM, RF Gain Maximum, Mic Gain Maximum, NB/ANL Off, 19/9/NOR NOR

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Output of signal generator to antenna input. 27.185MHz, 1000Hz @ 30% modulation Output 500uV.	Ch. 19 Squelch Maximum	RV1	SQUELCH RANGE Adjust so squelch just breaks.
Output of signal generator to antenna input. 27.185MHz, 1000Hz @ 30% modulation Output 100uV.	Ch. 19	RV3	S METER Adjust for 9 on S scale of meter.

TRANSMITTER ALIGNMENT

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.
NOTE: Be sure to check transmit frequency and power on all active channels after alignment of transmitter.
See page 4 for channel frequencies.

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Input of oscilloscope to TP3 (Q3 Base).	Ch. 19, XMT	T2, T3, T4	Adjust for maximum RF output. (2.00 volts p-p typical.) See Figure 1.
Input of RF wattmeter to antenna input.	Ch. 19, XMT	L5	Adjust for maximum RF output.
Input of RF wattmeter to antenna input.	Ch. 19, XMT	L10	Adjust for 4.3 watts RF output.
Input of RF wattmeter to antenna input.	Ch. 19, XMT	L5	Turn core clockwise for 3.8 watts RF output.

TRANSMITTER ADJUSTMENTS

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.
NOTE: Be sure to check transmit frequency and power on all active channels after adjustment of transmitter.
See page 4 for channel frequencies.

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Input of oscilloscope or modulation meter to antenna input. Inject a 1000Hz; 15mV signal at Mic input.	Ch. 19, XMT	RV2	AMC Adjust for 90% modulation. (See Figure 2.)
Input of RF wattmeter to antenna input.	Ch. 19, XMT	L2	RF POWER METER Adjust so Power Meter reads in red area with 3.8 watts RF output.
Connect a 150-ohm, 5 watt dummy load to antenna connector.	Ch. 19, XMT	RV502	SWR Put S4 in CAL and calibrate SWR meter with calibrate control. Put S4 in SWR and adjust for an SWR reading of 3.
Connect a 250-ohm, 5 watt dummy load to antenna connector.	Ch. 19, XMT	RV501	AWI Adjust till AWI light just turns on.




Figure 1






Figure 2

TRUTH CHART


C H A N N E L	1 = 5.64 Volts 0 = 0 Volts								REC VCO OUTPUT IN MHz AT TP5	XMT VCO OUTPUT IN MHz AT TP5	REC VCO OUTPUT IN MHz AT TP4	XMT VCO OUTPUT IN MHz AT TP4
	IC1 PROGRAM DIVIDER											
	PINS											
	9	10	11	12	13	14	15					
1	1	0	0	1	0	1	0		16.270	13.4825	6.030	3.2425
2	1	0	0	1	0	0	1		16.280	13.4875	6.040	3.2475
3	1	0	0	1	0	0	0		16.290	13.4925	6.050	3.2525
4	1	0	0	0	1	1	0		16.1210	13.5025	6.070	3.2625
5	1	0	0	0	1	0	1		16.320	13.5075	6.080	3.2675
6	1	0	0	0	1	0	0		16.330	13.5125	6.090	3.2725
7	1	0	0	0	0	1	1		16.340	13.5175	6.100	3.2775
8	1	0	0	0	0	0	1		16.360	13.5275	6.120	3.2875
9	1	0	0	0	0	0	0		16.370	13.5325	6.130	3.2925
10	0	1	1	1	1	1	1		16.380	13.5375	6.140	3.2975
11	0	1	1	1	1	1	0		16.390	13.5425	6.150	3.3025
12	0	1	1	1	1	0	0		16.410	13.5525	6.170	3.3125
13	0	1	1	1	0	1	1		16.420	13.5575	6.180	3.3175
14	0	1	1	1	0	1	0		16.430	13.5625	6.190	3.3225
15	0	1	1	1	0	0	1		16.440	13.5675	6.200	3.3275
16	0	1	1	0	1	1	1		16.460	13.5775	6.220	3.3375
17	0	1	1	0	1	1	0		16.470	13.5825	6.230	3.3425
18	0	1	1	0	1	0	1		16.480	13.5875	6.240	3.3475
19	0	1	1	0	1	0	0		16.490	13.5925	6.250	3.3525
20	0	1	1	0	0	1	0		16.510	13.6025	6.270	3.3625
21	0	1	1	0	0	0	1		16.520	13.6075	6.280	3.3675
22	0	1	1	0	0	0	0		16.530	13.6125	6.290	3.3725
23	0	1	0	1	1	0	1		16.560	13.6275	6.320	3.3875
24	0	1	0	1	1	1	1		16.540	13.6175	6.300	3.3775
25	0	1	0	1	1	1	0		16.550	13.6225	6.310	3.3825
26	0	1	0	1	1	0	0		16.570	13.6325	6.330	3.3925
27	0	1	0	1	0	1	1		16.580	13.6375	6.340	3.3975
28	0	1	0	1	0	1	0		16.590	13.6425	6.350	3.4025
29	0	1	0	1	0	0	1		16.600	13.6475	6.360	3.4075
30	0	1	0	1	0	0	0		16.610	13.6525	6.370	3.4125
31	0	1	0	0	1	1	1		16.620	13.6575	6.380	3.4175
32	0	1	0	0	1	1	0		16.630	13.6625	6.390	3.4225
33	0	1	0	0	1	0	1		16.640	13.6675	6.400	3.4275
34	0	1	0	0	1	0	0		16.650	13.6725	6.410	3.4325
35	0	1	0	0	0	1	1		16.660	13.6775	6.420	3.4375
36	0	1	0	0	0	1	0		16.670	13.6825	6.430	3.4425
37	0	1	0	0	0	0	1		16.680	13.6875	6.440	3.4475
38	0	1	0	0	0	0	0		16.690	13.6925	6.450	3.4525
39	0	0	1	1	1	1	1		16.700	13.6975	6.460	3.4575
40	0	1	1	1	1	0	0		16.710	13.7025	6.470	3.4625



CHASSIS-TOP VIEW




CHASSIS-TOP VIEW




MIDLAND MODEL 5001 (77-005)


MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD



MAIN BOARD




MAIN BOARD





* LOCATED ON OTHER SIDE OF BOARD

CHANNEL SELECTOR BOARD




CHANNEL SELECTOR BOARD




A Howard W. Sams CIRCUITRACE® Photo AWI-SWR BOARD

MIDLAND MODEL 5001 (77-005)



BLOCK DIAGRAM



SHIELD LOCATION

PARTS LIST AND DESCRIPTION

(When ordering parts, state Model, Part Number, and Description.)

WIRING DATA

Cable (Speaker)(Unshielded).....	Use BELDEN No. 8782 (AWG24)(4 colors)
Shielding Strap.....	Use BELDEN No. 8660 (3/16" width)
Hook-up Wire (General Use).....	Use BELDEN No. 8524 (AWG22)(13 colors)
Hook-up Wire (Shielded).....	Use BELDEN No. 8401 (Braided Shield)(1 conductor)(AWG25)
	Use BELDEN No. 8421 (Spiral Shield)(1 conductor)(AWG25)
	Use BELDEN No. 8737 (Spiral Shield)(2 conductor)(AWG22)
Microphone Cable (Coiled)	Use BELDEN No. 8497 (3 conductor-1 shielded)(6 ft.)(AWG22)
Microphone Cable (Coiled)	Use BELDEN No. 9466 (3 conductor-1 shielded)(6 ft.)(AWG28)
Microphone Cable (Coiled)	Use BELDEN No. 9468 (3 conductor-1 shielded)(6 ft.)(AWG31)

SEMICONDUCTORS (Select replacement transistor for best results)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA							
			GENERAL ELECTRIC PART No.	MALLORY PART No.	RAYTHEON PART No.	RCA PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
01	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
02	M2306	05-480306		ZM68		SK3778/5012A	ECG5012A	TM5012	WEP1413/5012	
	1T1410	05-200410			REN 612	SK3325/612	ECG612	TM612		103-176
	BB122				REN 612	SK3325/612	ECG612	TM612		103-176
03	MV201				REN 612	SK3325/612	ECG612	TM612		103-176
D5	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D6	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
07	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N60	05-170060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
08	1K261	05-190261	1N34AS	PTC207	REN 109	SK3087	ECG109	TM109/**	WEP134/109	103-Z9001
	1K60	05-190060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
09	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D10	1N60	05-170060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
	1K261	05-190261	1N34AS	PTC207	REN 109	SK3087	ECG109	TM109/**	WEP134/109	103-Z9001
	1K60	05-190060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D11	SRI K-4	05-750004	GE-504A	PTC201	REN 116	SK3311	ECG116	TM116	WEP156	212-76-02
	1S1885	05-181885	GE-504A	PTC201	REN 116	SK3311	ECG116	TM116	WEP156	212-76-02
	SRI K-4	05-750004	GE-504A	PTC201	REN 116	SK3311	ECG116	TM116	WEP156	212-76-02
D13	R09.1E	05-540091	GEZD-9.1	ZB9.1B	REN 139	SK3060/139A	ECG139A	TM139A/**	WEP1109/139A	103-272
	U29.1B	05-860910	GEZD-9.1	ZB9.1B	REN 139	SK3060/139A	ECG139A	TM139A/**	WEP1109/139A	103-272
D14	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D15	1N60	05-170060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
	1K261	05-190261	1N34AS	PTC207	REN 109	SK3087	ECG109	TM109/**	WEP134/109	103-Z9001
	1K60	05-190060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results) (cont)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA							
			GENERAL ELECTRIC PART No.	MALLORY PART No.	RAYTHEON PART No.	RCA PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
D16	1N60	05-170060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-29001
	1K261	05-190261	1N34AS	PTC207	REN 109	SK3087	ECG109	TM109/**	WEP134/109	103-29001
	1K60	05-190060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-29001
D17	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D18	1N60	05-170060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-29001
	1K261	05-190261	1N34AS	PTC207	REN 109	SK3087	ECG109	TM109/**	WEP134/109	103-29001
	1N60	05-170060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-29001
D19	1K261	05-190261	1N34AS	PTC207	REN 109	SK3087	ECG109	TM109/**	WEP134/109	103-29001
	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D20	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D251	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D252	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D253	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D254	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D255	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D256	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D257	1S1555	05-181555	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
	1S2076	05-182076	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
	1N4448	05-174448	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D501	1N60	05-170060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-29001
	1K261	05-190261	1N34AS	PTC207	REN 109	SK3087	ECG109	TM109/**	WEP134/109	103-29001
	1K60	05-190060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-29001
D502	1N60	05-170060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-29001
	1K261	05-190261	1N34AS	PTC207	REN 109	SK3087	ECG109	TM109/**	WEP134/109	103-29001
	1K60	05-190060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-29001
D503	1N60	05-170060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-29001
	1K261	05-190261	1N34AS	PTC207	REN 109	SK3087	ECG109	TM109/**	WEP134/109	103-29001
	1K60	05-190060	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-29001
IC1	PLL03A						ECG1272	TM1272		
IC2	PLL03	02-360003					ECG1272	TM1272		
	C3001A				REN 1192	SK3445/1192	ECG1192	TM1192	WEP2120/1192	221-29061
	C3001	02-373001			REN 1192	SK3445/1192	ECG1192	TM1192	WEP2120/1192	221-29061
	TA7310P	02-257310			REN 1192	SK3445/1192	ECG1192	TM1192	WEP2120/1192	221-29061
IC3	UPC1181H					SK3922				
	UPC1181	02-301181				SK3922				
Q1	2SC710	01-030710	GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107/**	WEP710	121-29000A*
	2SC829	01-030829	GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
Q2	2SC710	01-030710	GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107/**	WEP710	121-29000A*
	2SC1687		GE-20*	PTC121*	REN 123A*	SK3246/229	ECG229*	TM229*	WEP710*	121-29000A*
Q3	2SC1760	01-031760	GE-276	PTC180	REN 306	SK3251/306	ECG306	TM306	WEP771/306	121-29069
	2SC1846		GE-336	PTC904	REN 295	SK3253/295	ECG295	TM295	WEP913/295	121-880
	2SC2036		GE-336		REN 306	SK3251/306	ECG373	TM373	WEP771/306	121-29069
Q4	2SC1306	01-031306	GE-215	PTC186	REN 235	SK3239/235	ECG235	TM235/**	WEP785/235	121-29039
	2SC1678		GE-322	PTC186	REN 235	SK3197/235	ECG235	TM235	WEP785/235	121-29039
	2SC1974		GE-337	PTC186	REN 235	SK3239/235	ECG235	TM235	WEP785/235	121-29039
Q5	2SC2075		GE-215	PTC186	REN 235	SK3197/235	ECG235	TM235	WEP785/235	121-29039
	2SC1047C		GE-60*	PTC132*	REN 229*	SK3132	ECG229*	TM229*	WEP63/161*	121-29021*
	2SC1047	01-031047	GE-60*	PTC132*	REN 229*	SK3132	ECG229*	TM229*	WEP63/161*	121-29021*
	2SC460		GE-61*	PTC136*	REN 107	SK3122	ECG199	TM199/**	WEP460	121-522*
Q6	2SC710	01-030710	GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107/**	WEP710	121-29000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
Q7	2SC710	01-030710	GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107/**	WEP710	121-29000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
Q8	2SC829C		GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
	2SC839	01-030829	GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
	2SC710	01-030710	GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
Q9	2SC829C		GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
	2SC829	01-030829	GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
Q10	2SC829B		GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
	2SC829	01-030829	GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
	2SC710	01-030710	GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107/**	WEP710	121-29000A*
Q11	2SC710	01-030710	GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107/**	WEP710	121-29000A*
	2SC829	01-030829	GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
Q12	2SC710	01-030710	GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107/**	WEP710	121-29000A*
	2SC829	01-030829	GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
Q13	2SC710	01-030710	GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107/**	WEP710	121-29000A*
	2SC829	01-030829	GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results) (cont)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA							
			GENERAL ELECTRIC PART No.	MALLORY PART No.	RAYTHEON PART No.	RCA PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
Q14	25A719R 25A719 25A720 25A564 25A952	01-010719	GE-269	PTC103*	REN 290	SK3114/290	ECG290	TM290/**	WEP911/290	121-29003*
			GE-269	PTC103*	REN 290	SK3114/290	ECG290	TM290/**	WEP911/290	121-29003*
			GE-272	PTC103	REN 298	SK3114/290	ECG298	TM298	WEP915/298	121-875*
			GE-65	PTC103*	REN 234	SK3247/234	ECG234	TM234	WEP495	121-879*
			GE-244*	PTC142*	REN 129*	SK3114/290	ECG129*	TM129*	WEP60/129*	121-29005
Q15	25A733Q 25A733 25A564 25A719 25A952	01-010733	GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
			GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
			GE-65	PTC103*	REN 234	SK3247/234	ECG234	TM234	WEP495	121-879*
			GE-269	PTC103*	REN 290	SK3114/290	ECG290	TM290/**	WEP911/290	121-29003*
			GE-244*	PTC142*	REN 129*	SK3114/290	ECG129*	TM129*	WEP60/129*	121-29005
Q16	25C945AQ 25C945A 25C945 25C828 25C372	01-030945	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-61*	PTC139*	REN 199	SK3122	ECG199	TM199/**	WEP828	121-972*
			GE-61*	PTC121*	REN 123A*	SK3245/199	ECG123AP*	TM123AP**	WEP372	121-29000A*
Q17	25C1327T 25C1327 25C900 25C945 25C1318R	01-031327	GE-85*	PTC139*	REN 199	SK3899	ECG199	TM199	WEP634	121-972*
			GE-85*	PTC139*	REN 199	SK3899	ECG199	TM199	WEP634	121-972*
			GE-62	PTC139*	REN 199	SK3250/315	ECG199	TM199/**	WEP66/199	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-210	PTC123	REN 297	SK3124/289	ECG297	TM297	WEP914/297	921-340
Q18	25C1318R 25C1318 25C2002 25C945AQ 25C945A	01-031318	GE-210	PTC123	REN 297	SK3124/289	ECG297	TM297	WEP914/297	921-340
			GE-271	PTC123*	REN 297	SK3449/297	ECG297	TM297	WEP914/297	921-340*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
Q19	25C828 25C372	01-030945	GE-61*	PTC139*	REN 199	SK3122	ECG199	TM199/**	WEP828	121-972*
			GE-61*	PTC121*	REN 123A*	SK3245/199	ECG123AP*	TM123AP**	WEP372	121-29000A*
			GE-62	PTC139*	REN 199	SK3250/315	ECG199	TM199/**	WEP66/199	121-972*
			GE-62	PTC139*	REN 199	SK3250/315	ECG199	TM199/**	WEP66/199	121-972*
			GE-85*	PTC139*	REN 199	SK3245/199	ECG199	TM199	WEP634	121-972*
Q20	25C900U 25C900 25C1327 25C829C 25C829	01-030900	GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
			GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
			GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
			GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107**	WEP710	121-29000A*
			GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
Q21	25C710 25C829 25C839	01-030710 01-030829	GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107**	WEP710	121-29000A*
			GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
			GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
			GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107**	WEP710	121-29000A*
			GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
Q22	25A733Q 25A733 25C710 25C829 25C839	01-010733 01-030710 01-030829	GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
			GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107**	WEP710	121-29000A*
			GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
			GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
			GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
Q23	25A733Q 25A733 25C710 25C829 25C839	01-010733 01-030710 01-030829	GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
			GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107**	WEP710	121-29000A*
			GE-20*	PTC139*	REN 229*	SK3122	ECG289	TM289/**	WEP829	121-29021*
			GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
			GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
Q501	25C945AP 25C945 25C828 25C945AP 25C945	01-010733	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-61*	PTC139*	REN 199	SK3122	ECG199	TM199/**	WEP828	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
Q502	25C828 25C945 25C828	01-010733	GE-61*	PTC139*	REN 199	SK3122	ECG199	TM199/**	WEP828	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
			GE-61*	PTC139*	REN 199	SK3122	ECG199	TM199/**	WEP828	121-972*
			GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
Q503	25A719R 25A719 25A733 25A564 25A952	01-010733	GE-269	PTC103*	REN 290	SK3114/290	ECG290	TM290/**	WEP911/290	121-29003*
			GE-269	PTC103*	REN 290	SK3114/290	ECG290	TM290/**	WEP911/290	121-29003*
			GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
			GE-65	PTC103*	REN 234	SK3247/234	ECG234	TM234	WEP495	121-879*
			GE-244*	PTC142*	REN 129*	SK3114/290	ECG129*	TM129*	WEP60/129*	121-29005

* Lead configuration may vary from original.

** Also available as exact type replacement.

ELECTROLYTIC CAPACITORS

ITEM No.	RATING	REPLACEMENT DATA				
		MFR. PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C14	47 25V	00-132165	PC50-25	VTT47E25	QV1-77	EV-1426.1
C15	100 10V		PC100-10	VTT100D10	QV1-93	EV-1131
C62	1 50V		PC1-50	VTT1A50	QV1-11	EV-1615
C63	1 50V		PC1-50	VTT1A50	QV1-11	EV-1615
C66	3.3 25V		NLW4-50	VTT3R3A50	QV1-25	EV-1618.1
C72	10 16V	00-132115	PC10-25	VTT10R25	QV1-41	EV-1222
C76	100 16V	00-132175	PC100-16	VTT100E16	QV1-95	EV-1231
C77	4.7 25V	03-003072	PC50-16	TOC686M025FL	QDT1-55	SD25-6R89
C78	47 16V	00-132630	PC50-16	VTT47D16	QV1-73	EV-1226
C80	220 16V	00-132380	PC250-25	VTT220H16	QV1-117	EV-1240
C81	3.3 25V	00-132465	NLW4-50	VTT3R3A50	QV1-25	EV-1618.1
C82	3.3 25V	00-132465	NLW4-50	VTT3R3A50	QV1-25	EV-1618.1
C83	47 25V	00-132630	PC50-25	VTT47E25	QV1-77	EV-1426.1
C85	1000 16V	00-132210	PC1000-16	VTT1000H16	QV1-183	EV-1261
C86	33 6.3V	00-132500	PC30-25	VTT33R10		EV-1225
C87	33 6.3V	00-132500	PC30-25	VTT33R10		EV-1225
C88	4.7 25V	00-132600	PC5-50	VTT47R750	QV1-31	EV-1619.1
C90	100 10V	00-132165	PC100-10	VTT100D10	QV1-93	EV-1131
C96	10 16V	00-132115	PC10-25	VTT10R25	QV1-41	EV-1222
C97	1 50V	00-132055	PC1-50	VTT1A50	QV1-11	EV-1615
C98	1 50V	00-132055	PC1-50	VTT1A50	QV1-11	EV-1615
C99	33 16V	00-132510	PC30-25	VTT33R25	QV1-63	EV-1325
C118	3.3 25V	00-132465	NLW4-50	VTT3R3A50	QV1-25	EV-1618.1
C502	4.7 25V	00-132600	PC5-50	VTT47R750	QV1-31	EV-1619.1


PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA			
			CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C1	.01 50V			MAG5011		
C2	.047 50V (1)		DPMS2S47	EWFA1A147	QF1-171	1PE-S47
C3	330 50V (1)		GP330	GP333	QCT2-33	10TS-T33
C4	68 50V		NP068	CN0468		10TCC-068
C5	.001 50V 10%		OPMS601	M192P10292	QFT2-1	1FT-D10
C6	.01 50V			MAG5011		
C7	.001 50V 10%		DPMS601	M192P10292	QFT2-1	1FT-D10
C8	100 50V		NP0100	CN0310		10TCC-T10
C9	.01 50V			MAG5011		
C10	.001 50V 10%		DPMS601	M192P10292	QFT2-1	1FT-D10
C11	.01 50V			MAG5011		
C12	.047 50V		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C13	56 50V			CN0456		10TCC-056
C16	39 50V			CN0439		10TCC-039
C17	68 50V		NP068	CN0468		10TCC-068
C18	39 50V			CN0439		10TCC-039
C19	120 50V			CN0312		10TCC-T12
C20	22 50V		NP022	CN0422		10TCC-022
C21	5 50V		NP06P8	CN0568		10TCC-V68
C22	15 50V (1)		NP015	CN0415		10TCC-015
C23	.01 50V			MAG5011		
C24	22 50V		NP022	CN0422		10TCC-Q22
C25	82 50V		NP082	CN0482		10TCC-082
C26	220 50V					10TCC-T22
C27	150 50V			CN0315		10TCC-T15
	100 50V		NP0100	CN0310		10TCC-T10
C28	.01 50V			MAG5011		
C29	100 50V		NP0100	CN0310		10TCC-T10
C30	15 50V		NP015	CN0415		10TCC-015
C31	.01 50V			MAG5011		
C32	47 50V (1)		NP047	CN0447	QCC2-26	10TCC-Q47
C33	.01 50V (1)			MAG5011		
C34	10 50V (1)		NP010	CN0410	QCC2-15	10TCC-010
C35	150 50V			CN0315		10TCC-T15
C36	150 50V			CN0315		10TCC-T15
C37	.01 50V			MAG5011		
C38	.01 50V			MAG5011		
C39	100 50V (1)		NP0100	CN0310		10TCC-T10
C40	.01 50V 10%		WMF1S1	M192P1039R8	QFT2-91	1FT-S10
C41	680 50V		GP680	GP368		10TS-T68
C42	.01 50V			MAG5011		
C43	150 50V (1)			CN0315		10TCC-T15
	270 500V					10TCC-T27
C44	220 50V (1)					10TCC-T22
C45	15 50V (1)		NP015	CN0415		10TCC-015
C46	.01 50V			MAG5011		
C47	120 50V			CN0312		10TCC-T12
C48	270 50V					10TCC-T27
C49	390 50V		GP390	GP339	QCT2-34	10TS-T39
C50	33 50V		NP033	CN0433	QCC2-22	10TCC-Q33
C51	.047 50V		OPMS2S47	EWFA1A147	QF1-171	1PB-S47
C52	.01 50V			MAG5011		
C53	2 50V		NP02P2	CN0522		10TCC-V22
	.047 50V 10%		OPMS2S47	M192P4739R8	QFT2-171	1FT-S47
C54	68 50V (1)		NP068	CN0468		10TCC-068
C55	.047 50V 10%		OPMS2S47	EWFA1A147	QF1-171	1PB-S47
C56	.047 50V		OPMS2S47	EWFA1A147	QF1-171	1PB-S47
C57	.01 50V			MAG5011		
C58	.047 50V		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C59	.047 50V		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C60	.0068 50V 10%		WMF1D68	EWFA2A68	QF1-73	1PB-068
C61	.01 50V 10%		WMF1S1	M192P1039R8	QFT2-91	1FT-S10
C64	.047 50V		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C65	.047 50V		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C67	.056 50V 10%		WMF1S56	M192P5639R8	QFT2-185	1FT-S56
C68	.0047 50V		GP4700	GP247		5GA-047
C69	.022 50V 10% (1)			M192P2239R8		192P2239R8
	.01 50V 10%			MAG5011		
C70	.001 50V			GP210	QCT2-41	10TS-010
C71	560 50V			GP356		10TS-T56
C73	.01 50V (1)			MAG5011		
C74	.01 50V			MAG5011		
C75	.0022 50V			GP222	QCT2-46	10TS-022
C79	.068 50V 10%		WMF1S68	EWFA1A168	QF1-195	1PB-S68
C84	.01 50V			MAG5011		
C88	.022 50V 10%		DPMS2S22	M192P2239R8	QFT2-127	1FT-S22
C89	.01 50V			MAG5011		
C91	47 50V		NP047	CN0447	QCC2-26	10TCC-047
C92	.01 50V			MAG5011		
C93	.0047 50V		GP4700	GP247		5GA-047
C94	.01 50V			MAG5011		
C95	.01 50V			MAG5011		
C100	27 50V			CN0427		10TCC-027
C101	220 50V					10TCC-T22
C102	220 50V					10TCC-T22
C103	.0033 50V		GP3300	GP233	QC2-107	5GA-033
C104	.01 50V			MAG5011		
C105	82 50V		NP082	CN0482		10TCC-082
C106	.0022 50V (1)			GP222	QCT2-46	10TS-022
C107	.001 50V (1)			GP210	QCT2-41	10TS-010
C108	.0022 50V (1)			GP222	QCT2-46	10TS-022
C109	.047 50V		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C110	.047 50V		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C111	.047 50V		DPMS2S47	EWFA1A147	QF1-171	1PB-S47
C112	.01 50V			MAG5011		
C115	.01 50V			MAG5011		
C116	.01 50V			MAG5011		
C117	.047 50V 10%		OPMS2S47	M192P4739R8	QFT2-171	1FT-S47
C119	39 50V			CN0439		10TCC-039

MIDLAND MODEL 5001 (77-005)



Waveforms and Voltages taken in Channel 19 with switching in receive unless noted. Item numbers in rectangles appear in the alignment/adjustment instructions. Supply voltage maintained as shown at input. Voltages measured with digital meter, no signal. Controls adjusted for normal operation. Terminal identification may not be found on unit. Resistors are 1/2W or less, 5% unless noted. Value in () used in some versions. Arrow head(s) at coils and transformers indicates accessibility of tuning slug(s).

A PHOTOFAC STANDARD NOTATION SCHEMATIC


WITH **CIRCUITRACE**


© Howard W. Sams & Co., Inc. 1980

POWER SUPPLY SCHEMATIC

A PHOTO

© Ho





--- Circuitry not used in some versions.

--- Circuitry used in some versions.

⊗ Nominal value ⊕ Common tie point

⊥ Ground

⏏ Chassis

Ⓢ See parts list

Waveforms and Voltages taken in Channel 19 with switching in receive unless noted.

Item numbers in rectangles appear in the alignment/adjustment instructions.

Supply voltage maintained as shown at input.

Voltages measured with digital meter, no signal.

Controls adjusted for normal operation.

Terminal identification may not be found on unit.

Resistors are 1/2W or less, 5% unless noted.

Value in () used in some versions.

Arrow head(s) at coils and transformers indicates accessibility of tuning slug(s).


B C E
Q1, Q11,
Q12, Q13
BOTTOM VIEW

A PHOTOFACIT STANDARD NOTATION SCHEMATIC

WITH CIRCUITRACE

© Howard W. Sams & Co., Inc. 1980

P



PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFG. PART No.	REPLACEMENT DATA			
			CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C120	5 50V 10% (1)		HP06P8	CH0568		10TCC-V68
C201	150 50V			CH0315		10TCC-T15
C202	.01 50V			MAG5011		
C203	.01 50V			MAG5011		
C204	.0047 50V (1)		GP4700	GP247		5GA-047
C205	.0047 50V		GP4700	GP247		5GA-047
C206	.0047 50V (1)		GP4700	GP247		5GA-047
C207	.047 50V		OPMS2S47	EWFA147	QF1-171	1PB-S47
C208	.047 50V		OPMS2S47	EWFA147	QF1-171	1PB-S47
C209	.01 50V			MAG5011		
C210	.047 50V		OPMS2S47	EWFA147	QF1-171	1PB-S47
C211	.047 50V		OPMS2S47	EWFA147	QF1-171	1PB-S47
C250	10 50V		HP010	CN0410	QCC2-15	10TCC-010
C501	.01 50V			MAG5011		
C503	.01 50V			MAG5011		
C504	.01 50V			MAG5011		
C505	.01 50V			MAG5011		
C506	.01 50V			MAG5011		
CT1	Trimmer 1-15pF	77-123006				

(1) Value varies.

CONTROLS (All wattages 1/2 watt, or less, unless listed)

ITEM No.	FUNCTION	RESISTANCE	REPLACEMENT DATA		
			MFG. PART No.	MALLORY PART No.	TRW PART No.
RV1	Squelch Range	10K	77-164020	RVA0911H103	U260R103R
RV2	AMC	2000	77-164021	RVA0911H252	U260R252B
RV3	Signal Meter	20K	77-164022	RVA0911H253	U260R253B
RV501	AWI	20K	77-164024	RVA0911V253	X260R253B
RV502	SWR	10K	77-164023	RVA0911V103	X260R103B
VR1	AF Gain/Switch (Volume)	50K	77-166017		
VR2	Squelch	10K	77-166014		
VR3	RF Gain	10K	77-166014		
VR4	Mic Gain	5000	77-166009		
VR5	Calibrate	10K	77-166014		

COILS (RF-IF)

ITEM No.	FUNCTION	REPLACEMENT DATA			REMARKS
		PART No.	OTHER IDENTIFICATION	MILLER PART No.	
L1	RF Choke	77-176024	180A		
L2	RF Choke	77-176075			
L3	RF Choke	77-178003			
L4	RF Choke	77-176077	022E		
L5	RF Driver (27MHz)	77-176079			
L6	RF Choke	77-176078	680A		
L7	RF Choke	77-176049			
L8	RF Choke	77-176027			
L9	RF Choke	77-176076			
L10	Final (27MHz)	77-176074			
L11	Antenna	77-176004			
L12	RF Choke	77-176078	680A		
T1	VCO	77-176083			
T2	Doubler (27MHz)	77-176081	10CB003		
T3	Doubler (27MHz)	77-176081			
T4	RF Predriver (27MHz)	77-090027	10CP005M		
T5	Rec Antenna	77-176086	ETR0333		
T6	RF Amp (27MHz)	77-176080	ETR0334		
T7	RF Amp (27MHz)	77-176082	10CM003M		
T8	Mixer (10.695MHz)	77-176085			
T9	Mixer (10.695MHz)	77-176084	10MA017S		
T10	IF (455kHz)	77-090004			
T11	IF (455kHz)	77-090006	ET10129		

FILTER CHOKE

ITEM No.	RATINGS			REPLACEMENT DATA			NOTES
	CURRENT (Measured)	DC RES.	INDUCTANCE (0 CURRENT 1000~)	MFG. PART No.	THORDARSON PART No.	TRIAD PART No.	
CH1	1.39A	.23	3.3mH	77-178043			

MIDLAND MODEL 5001 (77-005)

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

TRANSFORMER (Audio Output)

ITEM No.	IMPEDANCE		REPLACEMENT DATA			NOTES
	PRI.	SEC. 1	MFGR. PART No.	THORDARSON PART No.	TRIAD PART No.	
T12	2	8 SEC. 2 12.5	77-090026			

SPEAKER

ITEM No.	TYPE	REPLACEMENT DATA		NOTES
		MFGR. PART No.	QUAM PART No.	
SP	3" PM, 8 Ohms	77-060006	30A0528R	

FUSE DEVICES


ITEM No.	DESCRIPTION	REPLACEMENT DATA					
		PART No.		BUSS PART No.		LITTELFUSE PART No.	
		DEVICE	HOLDER	DEVICE	HOLDER	DEVICE	HOLDER
F1	2A Quick-acting		77-034005	AGC-2	HRK	312-002	150145

MISCELLANEOUS

ITEM No.	PART NAME	PART No.	NOTES
CF1	Filter	77-179018	455kHz
J1	Jack	77-153010	Antenna
J2	Jack	77-153011	Microphone
J3	Jack	77-153008	External Speaker
J4	Jack	77-153008	PA
J5	Jack	77-153009	DC
LE0301	LED	77-202020	Channel Indicator 1.95V @ 12.1mA
LE0302	LED	77-202019	RX/TX 1.94V @ 14mA RX/ 1.92V @ 8.3mA TX
LE0303	LED	77-202021	AWL Warning 1.92V @ 6.5mA
LE0304	LED	77-202021	CH. 9 1.90V @ 6.5mA
LE0305	LED	77-202021	CH. 19 1.92V @ 7.6 mA
M1	Meter	77-200014	S/R/F/SWR (Includes PL1 Lamp)
PL1	Pilot Lamp		SV @ 58mA (Part of M1 Meter)
S2	Switch	77-183008	AML/CB
S3	Switch	77-163002	Tone
S4	Switch	77-183008	AML/CB
S5	Switch	77-183008	AML/CB
S6	Switch	77-183008	AML/CB
SW251	Switch	77-180016	Channel Selector
X1	Crystal	77-128020	10.24MHz
XF1	Filter	77-179019	Crystal 10.7MHz
	Microphone	77-038018	
	Board	77-070027	LED Display
	Board	77-070029	Antenna Warn
	Board	77-070030	LED Display
	P.C. Board	77-070026	Main
	P.W.B. Assembly	77-075047	Main
	Board	77-075048	LED
	Board	77-075049	Antenna Warning
	Board	77-075050	LED
	Joint PC	77-070028	
	Joint PC	77-070031	

CABINETS & CABINET PARTS (When ordering specify model, chassis & color)

ITEM	PART No.	ITEM	PART No.
Cover, Bottom	77-011017	Knob, Channel	77-115029
Cover, Top	77-011016	Knob, VR	77-110020
Escutcheon Assembly	77-011015	Panel, Front	77-010046



PHOTOFACT[®] with

CIRCUITRACE[®]

For Supplier Address See PHOTOFACT Index

NOTE

Repair or adjustment of transmitter circuits must be under supervision of a person with first-or second-class radiotelephone license.

(Refer to FCC Rules and Regulations Part 95, Subpart C & D.)

The frequency of the transmitter should be checked periodically with a secondary frequency standard to insure proper and legal operation.

Best results will be obtained when adjusting the final RF output circuit if the antenna normally used is connected and the chassis is as nearly in the cabinet as possible.

Connect either 50-ohm dummy load or the normally used antenna system.



MODEL SSB-500

MANUFACTURER'S SPECIFICATIONS

GENERAL

Channels	: 40 — AM/Single Sideband
Frequency Range	: 26.965 to 27.405 MHz
Frequency Control	: Phaselock Synthesizer
Frequency Tolerance	: $\pm 0.005\%$
Frequency Stability	: $\pm 0.002\%$
Operating Temperature Range	: -30°C to $+50^{\circ}\text{C}$
Microphone	: Plug-in type dynamic with volume control
Input Voltage	: 13.8V DC (Positive or Negative ground)
Current Drain	: Receive 1.5A at maximum audio output 0.5A standby (no signal).
Size	: 10-6/10" L. X 8" W. X 2-1/2" H.
Weight	: 6 lbs.
Antenna Connector	: Standard American type
Semiconductors	: 41 Transistors, 7 FETS, 60 Diodes, 7 ICs
Meter	: Illuminated, indicates relative power output and received signal strength
Power Bandwidth	: 10.5 to 16V

TRANSMITTER

Power	: 4 Watts — AM (max. allowed by FCC) 12 Watts PEP-SSB (max. allowed by FCC)
Modulation	: High and low level Class B amplitude modulation (AM)
Modulation Capability	: 95% Typical (AM)
Harmonic Suppression and Spurious Emissions	: Better than FCC requirement
Frequency Response	: 400 Hz to 2.5 kHz — AM and SSB

Output Impedance	: 50 Ohms, unbalanced
Output Indicators	: Meter shows relative RF output power, Tx red lamp indicates transmit mode.

RECEIVER

Sensitivity — AM	: $.7\mu\text{V}$ for 10 db S/N
Sensitivity — SSB	: $.25\mu\text{V}$ for 10 db S/N
Selectivity	: 6 db at 4.2 kHz 60 db at 7 kHz (AM and SSB)
Image Rejection	: More than 50 db
Automatic Gain Control (AGC)	: Change in audio output less than 10 db from $10\mu\text{V}$ to .5 volts
Squelch	: Adjustable — threshold less than $.5\mu\text{V}$
Audio Frequency Response	: 400Hz to 2.5 kHz
Distortion	: Less than 10% at 3.0 watts output
Adjacent Channel Rejection	: AM: -60 db, SSB: -65db
Cross Modulation	: More than 55 db
IF Frequency	: AM and SSB, 7.8 MHz
Clarifier	: $\pm 1\text{kHz}$
Noise Blanker	: RF type, effective on AM and SSB
Audio Output Power	: More than 3 watts into 8 ohms
Built-in Speaker	: 8 ohms, dynamic
External Speaker (optional)	: Disables internal speaker when connected

PUBLIC ADDRESS (PA) SYSTEM

Power Output	: 3 watts into external speaker
External Speaker for PA (optional)	: When PA switch is in PA mode, the unit functions as a public address system.

PALOMAR MODEL SSB-500

Courtesy of the Manufacturer

HOWARD W. SAMS & CO., INC. Indianapolis, Indiana 46206

© 1980 Howard W. Sams & Co., Inc. Printed in U. S. of America

9CF1088

ALIGNMENT INSTRUCTIONS

CAUTION: Use isolation transformer or observe polarity when connecting test equipment. Maintain line voltage at 120V AC. Allow a 15-minute warm-up period. Adjustments made with 13.8 volt DC input. Connect low sides of test equipment to ground unless specified otherwise. Connect 50-ohm dummy load or antenna before keying transmitter. Connect microphone.

Suggested Alignment Tools:

GC ELECTRONICS:

L1 thru L5, L7, L8, L16, L17, L24, L37 thru L39 ... 9440

L30, L32 8728, 8728A, 9091

SYNTHESIZER ALIGNMENT

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Input of frequency counter to TP11 (IC7 Pin 4).	Ch. 19, AM		Check for 10.240MHz.
Input of frequency counter to TP10 (IC7 Pin 5).	Ch. 19, AM	CT8	Adjust for 5.120MHz.
Input of oscilloscope to TP6 (FET4, G1).	Ch. 19, AM	L24	Adjust for maximum RF (120mV typical). (See Figure 1.)
Input of frequency counter to TP6 (FET4, G1).	Ch. 19, AM Clarifier Midrange	CT6	Adjust for 33.855MHz $\pm$ 20Hz.
Input of frequency counter to TP6 (FET4, G1).	Ch. 19, USB Clarifier Midrange	CT4	Adjust for 33.8574MHz $\pm$ 20Hz.
Input of frequency counter to TP6 (FET4, G1).	Ch. 19, LSB Clarifier Midrange	CT5	Adjust for 33.8526MHz $\pm$ 20Hz.
Input of DC meter to TP7 (Junction of R151 and R152).	Ch. 1, AM	L17	Adjust for 2.00 volts. Check channel 40 for approximately 2.70 volts.
Input of oscilloscope to TP8 (L16 Secondary).	Ch. 19, AM	L16	Adjust for maximum RF (1.6 volts typical). (See Figure 2.)
Input of frequency counter to TP8 (L16 Secondary).	Ch. 1, *AM Clarifier Midrange		Check for 34.765MHz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP8 (L16 Secondary).	Ch. 1, USB Clarifier Midrange		Check for 34.7675MHz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP8 (L16 Secondary).	Ch. 1, LSB Clarifier Midrange		Check for 34.7625MHz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP12 (TR30 Collector).	Ch. 1, AM		Check for .910MHz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP9 (TR28 Emitter).	Ch. 1, USB	CT2	Adjust for 7.8025MHz $\pm$ 5Hz.
	Ch. 1, LSB	CT3	Adjust for 7.7975MHz $\pm$ 5Hz.
Input of frequency counter to antenna jack.	Ch. 1, AM, XMT	VR9	Adjust for 26.965MHz.

RECEIVER ALIGNMENT

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.
Set generator output low enough to prevent AGC limiting.
RF Gain On, Clarifier Midrange, Squelch MINIMUM, NB Switch Off, ANL Switch Off.

AM

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to TP13 (FET1, G1). 7.8MHz, 1000Hz @ 30% modulation.	Ch. 19, AM	L8, L7, L5	Adjust for maximum output.
Output of signal generator to antenna jack. 27.185MHz, 1000Hz @ 30% modulation.	Ch. 19, AM	L4, L3	Adjust for maximum output. If necessary, readjust L5, L6, L7 and L8.
Inject a 100pps, 1uSec. signal at antenna input. Input of oscilloscope to TP14 (TR2 Collector).	Ch. 19, AM	L1, L2	Adjust for maximum (7.5 volts p-p typical). (See Figure 3.)

RECEIVER ALIGNMENT

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.
RF Gain On, Clarifier Midrange, Squelch MINIMUM, ANL Switch Off, NB Switch Off, Volume Maximum.

SSB

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator to antenna jack. 27.186MHz, no modulation. Output .25uV.	Ch. 19, USB	CT1	Adjust for 2 volts audio.

RECEIVER ADJUSTMENTS

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.
RF Gain On, Clarifier Midrange, Squelch MINIMUM, NB Switch Off, ANL Switch Off.

TEST EQUIPMENT	TRANSCEIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to antenna jack. 27.185MHz, 1000Hz @ 30% modulation. Output .5uV.	Ch. 19, AM Volume Maximum	VR5	AM RX GAIN Adjust for 2 volts audio.
Output of signal generator thru .01uF to antenna jack. 27.185MHz, 1000Hz @ 30% modulation. Output 50uV.	Ch. 19, AM RF Gain MINIMUM Squelch Maximum	VR2	RF GAIN Adjust for 2 volts audio.
Output of signal generator thru .01uF to antenna jack. 27.185MHz, 1000Hz @ 30% modulation. Output 1000uV.	Ch. 19, AM Squelch Maximum	VR3	SQUELCH RANGE Adjust so that squelch just breaks.
Output of signal generator thru .01uF to antenna jack. 27.185MHz, 1000Hz @ 30% modulation. Output 100uV.	Ch. 19, AM	VR1	SIGNAL METER Adjust for 9 on Signal scale of meter.

TRANSMITTER ALIGNMENT

Connect a 50-ohm, 25-watt dummy load to antenna connector.
 NOTE: Be sure to check transmit frequency and power on all active channels after alignment of transmitter.
 See page 4 for channel frequencies.

SSB

TEST EQUIPMENT	TRANSCIEVER	ADJUST	REMARKS
Input of RF wattmeter to antenna input. Inject a 1000Hz, 5mV signal at Mic input.	Ch. 19, USB	L39,L38,L37, L32,L30,CT7	Adjust for maximum.
Input of RF wattmeter to antenna input. Inject a 1000Hz, 200mV signal at Mic input.	Ch. 19, USB	CT7	Adjust for 12 watts.

TRANSMITTER ADJUSTMENTS

Connect a 50-ohm, 25-watt dummy load to antenna connector.
 NOTE: Be sure to check transmit frequency and power on all active channels after adjustment of transmitter.
 See page 4 for channel frequencies.

TEST EQUIPMENT	TRANSCIEVER	ADJUST	REMARKS
Connect current meter in series with circuit at TP4.	Ch. 19, USB, XMT, No modulation.	VR15	BIAS Adjust for 40mA.
Connect current meter in series with circuit at TP2.	Ch. 19, USB, XMT, No modulation.	VR16	BIAS Adjust for 15mA.
Connect a RF wattmeter to antenna connector.	Ch. 19, USB, XMT, No modulation.	VR4	BALANCE Adjust VR4 for MINIMUM RF.
	Ch. 19, AM, XMT *	VR8	AM POWER Adjust for 4 watts maximum.
Inject a 1000Hz, 5mV signal at Mic input. Input of oscilloscope or modulation meter to antenna jack.	Ch. 19, AM, XMT	VR408,VR7	MIC GAIN & AM AMC Turn VR7 (from top) fully clockwise. Adjust VR6 for 50% modulation. Increase audio to 200mV. Adjust VR7 for 100% modulation maximum. (See Figure 4.)
Connect a RF wattmeter to antenna connector.	Ch. 19, AM, XMT	VR12	TX POWER METER Adjust so the Power meter agrees with the RF wattmeter.




Figure 1




Figure 2




Figure 3





Figure 4


TRUTH CHART

CHANNEL	1 = 4.68 Volts 0 = 0 Volts								AM (REC) SYNTHESIZER OUTPUT IN MHz AT TP8	USB (REC & XMT) AM (XMT) SYNTHESIZER OUTPUT IN MHz AT TP8	LSB (REC & XMT) SYNTHESIZER OUTPUT IN MHz AT TP8	AM,USB,LSB (REC & XMT) DIVIDER INPUT IN MHz AT TP12
	IC7 PROGRAM DIVIDER											
	PINS											
	10	11	12	13	14	15	16	17				
1	0	1	0	1	1	0	1	1	34.765	34.7675	34.7625	.910
2	0	1	0	1	1	1	0	0	34.775	34.7775	34.7725	.920
3	0	1	0	1	1	1	0	1	34.785	34.7875	34.7825	.930
4	0	1	0	1	1	1	1	1	34.805	34.8075	34.8025	.950
5	0	1	1	0	0	0	0	0	34.815	34.8175	34.8125	.960
6	0	1	1	0	0	0	0	1	34.825	34.8275	34.8225	.970
7	0	1	1	0	0	0	1	0	34.835	34.8375	34.8325	.980
8	0	1	1	0	0	1	0	0	34.855	34.8575	34.8525	1.000
9	0	1	1	0	0	1	0	1	34.865	34.8675	34.8625	1.010
10	0	1	1	0	0	1	1	0	34.875	34.8775	34.8725	1.020
11	0	1	1	0	0	1	1	1	34.885	34.8875	34.8825	1.030
12	0	1	1	0	1	0	0	1	34.905	34.9075	34.9025	1.050
13	0	1	1	0	1	0	1	0	34.915	34.9175	34.9125	1.060
14	0	1	1	0	1	0	1	1	34.925	34.9275	34.9225	1.070
15	0	1	1	0	1	1	0	0	34.935	34.9375	34.9325	1.080
16	0	1	1	0	1	1	1	0	34.955	34.9575	34.9525	1.100
17	0	1	1	0	1	1	1	1	34.965	34.9675	34.9625	1.110
18	0	1	1	1	0	0	0	0	34.975	34.9775	34.9725	1.120
19	0	1	1	1	0	0	0	1	34.985	34.9875	34.9825	1.130
20	0	1	1	1	0	0	1	1	35.005	35.0075	35.0025	1.150
21	0	1	1	1	0	1	0	0	35.015	35.0175	35.0125	1.160
22	0	1	1	1	0	1	0	1	35.025	35.0275	35.0225	1.170
23	0	1	1	1	1	0	0	0	35.055	35.0575	35.0525	1.200
24	0	1	1	1	0	1	1	0	35.035	35.0375	35.0325	1.180
25	0	1	1	1	0	1	1	1	35.045	35.0475	35.0425	1.190
26	0	1	1	1	1	0	0	1	35.065	35.0675	35.0625	1.210
27	0	1	1	1	1	0	1	0	35.075	35.0775	35.0725	1.220
28	0	1	1	1	1	0	1	1	35.085	35.0875	35.0825	1.230
29	0	1	1	1	1	1	0	0	35.095	35.0975	35.0925	1.240
30	0	1	1	1	1	1	0	1	35.105	35.1075	35.1025	1.250
31	0	1	1	1	1	1	1	0	35.115	35.1175	35.1125	1.260
32	0	1	1	1	1	1	1	1	35.125	35.1275	35.1225	1.270
33	1	0	0	0	0	0	0	0	35.135	35.1375	35.1325	1.280
34	1	0	0	0	0	0	0	1	35.145	35.1475	35.1425	1.290
35	1	0	0	0	0	0	1	0	35.155	35.1575	35.1525	1.300
36	1	0	0	0	0	0	1	1	35.165	35.1675	35.1625	1.310
37	1	0	0	0	0	1	0	0	35.175	35.1775	35.1725	1.320
38	1	0	0	0	0	1	0	1	35.185	35.1875	35.1825	1.330
39	1	0	0	0	0	1	1	0	35.195	35.1975	35.1925	1.330
40	1	0	0	0	0	1	1	1	35.205	35.2075	35.2025	1.350


PALOMAR MODEL SSB-500




CHASSIS-BOTTOM




CHASSIS-BOTTOM




CHASSIS-BOTTOM



PALOMAR MODEL SSB-500




MAIN BOARD




PALOMAR MODEL SSB-500


MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD



MAIN BOARD




MAIN BOARD




MAIN BOARD


55



MAIN BOARD





MAIN BOARD




MAIN BOARD








CHANNEL INDICATOR BOARD



- X— Circuitry not used in some versions.
 - Circuitry used in some versions.
 - ⊗ Nominal value ▽ Common tie point
 - ⊥ Ground
 - ⏏ Chassis
 - Ⓢ See parts list
- Waveforms and Voltages taken in Channel 19 with switching in receive unless noted. Item numbers in rectangles appear in the alignment/adjustment instructions. Supply voltage maintained as shown at input. Voltages measured with digital meter, no signal. Controls adjusted for normal operation. Terminal identification may not be found on unit. Resistors are 1/2W or less, 5% unless noted. Value in () used in some versions. Arrow head(s) at coils and transformers indicates accessibility of tuning slug(s).



PALOMAR MODEL SSB-500



- Circuitry not used in some versions.
- - - Circuitry used in some versions.
- ⊗ Nominal value ∇ Common tie point
- ⊥ Ground
- ⌞ Chassis
- ⊖ See parts list

Waveforms and Voltages taken in Channel 19 with switching in receive unless noted.

Item numbers in rectangles appear in the alignment/adjustment instructions.

Supply voltage maintained as shown at input.

Voltages measured with digital meter, no signal.

Controls adjusted for normal operation.

Terminal identification may not be found on unit.

Resistors are 1/2W or less, 5% unless noted.


Value in () used in some versions.

Arrow head(s) at coils and transformers indicates accessibility of tuning slugs(s).

A PHOTOFAC STANDARD NOTATION SCHEMATIC

WITH **CIRCUITRACE**

© Howard W. Sams & Co., Inc. 1980




Rear view




Bottom view

Terminal Guides




Top view




Front view





TR29, TR30
TR32 thru TR34
TR38 thru TR40



PLL SCHEMATIC



POWER SUPPLY SCHEMATIC



CHANNEL SELECTOR BOARD



PARTS LIST AND DESCRIPTION

(When ordering parts, state Model, Part Number, and Description.)

WIRING DATA

Cable (Speaker)(Unshielded).....	Use BELDEN No. 8782 (AWG24)(4 colors)
Shielding Strap.....	Use BELDEN No. 8660 (3/16" width)
Hook-up Wire (General Use).....	Use BELDEN No. 8524 (AWG22)(13 colors)
Hook-up Wire (Shielded).....	Use BELDEN No. 8401 (Braided Shield)(1 conductor)(AWG25)
	Use BELDEN No. 8421 (Spiral Shield)(1 conductor)(AWG25)
	Use BELDEN No. 8737 (Spiral Shield)(2 conductor)(AWG22)
Coax (Transmission Line).....	Use BELDEN No. 8216 (RG-174/U, 50 ohms)
Microphone Cable (Coiled).....	Use BELDEN No. 8497 (3 conductor-1 shielded)(6 ft.)(AWG22)
Microphone Cable (Coiled).....	Use BELDEN No. 9466 (3 conductor-1 shielded)(6 ft.)(AWG28)
Microphone Cable (Coiled).....	Use BELDEN No. 9468 (3 conductor-1 shielded)(6 ft.)(AWG31)

SEMICONDUCTORS (Select replacement transistor for best results)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA							
			GENERAL ELECTRIC PART No.	MALLORY PART No.	RAYTHEON PART No.	RCA PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
D1	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D2	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D3	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D4	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D5	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D6	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D7	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D8	1N60		1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D9	1N60		1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D10	1N60		1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
	1N60P		1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D11	1N60		1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D12	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D13	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D14	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D15	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D16	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D17	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D18	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D19	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D20	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D21	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D22	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D23	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D24	CZ092		GEZD-9.1	ZB9.1A	REN 139	SK3060/139A	ECG139A	TM139/**	WEP1109/139	103-272
	MZ409B		GEZD-9.1	ZB9.1B	REN 139	SK3060/139A	ECG139A	TM139/**	WEP1109/139A	103-272
D25	MZ408B		GEZD-8.2	ZB8.2B	REN 5072	SK3136/5072A	ECG5072A	TM5072A/**	WEP1108/5072A	103-Z9021
	MZ408A		GEZD-8.2	ZB8.2B	REN 5072	SK3136/5072A	ECG5072A	TM5072A/**	WEP1108/5072A	103-Z9021
D26	WZ-050			ZM5.1B		SK3776/5010A	ECG5010A	TM5010	WEP1411/5010	103-279-10
D27	1N4002		GE-504A	1N4002	REN 116	SK3312	ECG116	TM116	WEP156	212-76-02
	10D1		GE-504A	PTC201	REN 116	SK3311	ECG116	TM116	WEP156	212-76-02
D28	MZ409		GEZD-9.1	ZB9.1B	REN 139	SK3060/139A	ECG139A	TM139A/**	WEP1109/139A	103-272
	MZ409B		GEZD-9.1	ZB9.1B	REN 139	SK3060/139A	ECG139A	TM139A/**	WEP1109/139A	103-272
D29	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D30	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D31	WZ061		GEZD-6.2	ZB6.2B	REN 137	SK3058/137A	ECG137A	TM137A/**	WEP1154/137A	103-Z9008
	MZ306B		GEZD-6.2	ZB6.2B	REN 137	SK3778/5012A	ECG5012A	TM5012	WEP1413/5012	103-Z9008
D32	WZ061		GEZD-6.2	ZB6.2B	REN 137	SK3058/137A	ECG137A	TM137A/**	WEP1154/137A	103-Z9008
	MZ306B		GEZD-6.2	ZB6.2B	REN 137	SK3778/5012A	ECG5012A	TM5012	WEP1413/5012	103-Z9008
D33	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D34	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D35	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D36	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D37	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D38	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D39	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D40	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D41	MV201			PTC311			ECG611	TM611		103-146
D42	1S2687			PTC311	REN 612	SK3325/612	ECG612	TM612		103-176
	MV201			PTC311			ECG611	TM611		103-146
D43	MV201			PTC311			ECG611	TM611		103-146
D44	CZ092		GEZD-9.1	ZB9.1A	REN 139	SK3060/139A	ECG139A	TM139/**	WEP1109/139	103-272
	MZ409B		GEZD-9.1	ZB9.1B	REN 139	SK3060/139A	ECG139A	TM139A/**	WEP1109/139A	103-272
D45	MV201			PTC311			ECG611	TM611		103-146
D46	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D47	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D48	1N60		1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D49	KB162			PTC301	REN 601	SK3463/601	ECG601	TM601		
D50	KB162W			PTC301	REN 601	SK3463/601	ECG601	TM601		
D51										
D52	KB162			PTC301	REN 601	SK3463/601	ECG601	TM601		
	KB162W			PTC301	REN 601	SK3463/601	ECG601	TM601		
D53	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D54	1N4002		GE-504A	1N4002	REN 116	SK3312	ECG116	TM116	WEP156	212-76-02
	10D1		GE-504A	PTC201	REN 116	SK3311	ECG116	TM116	WEP156	212-76-02
D56	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D57	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D58	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D59	1N60		1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D60	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results) (cont)

ITEM No.	TYPE No.	MFG. PART No.	REPLACEMENT DATA							
			GENERAL ELECTRIC PART No.	MALLORY PART No.	RAYTHEON PART No.	RCA PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
D61	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D62	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D63	1S2473		GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
FET1	3SK458		GE-FET-4	PTC182*	REN 222	SK3065/222	ECG222	TM222	WEP905/222	121-826
	3SK45		GE-FET-4	PTC182*	REN 222	SK3065/222	ECG222	TM222	WEP905/222	121-826
FET2	2SK33F		GE-FET-2	PTC161	REN 132*	SK3834/132	ECG312*	TM312*	WEP920/312*	921-1067*
	2SK33		GE-FET-2	PTC161	REN 132*	SK3834/132	ECG312*	TM312*	WEP920/312*	921-1067*
	JF1033		GE-FET-2*	PTC161*	REN 132*	SK3448	ECG312*	TM312	WEP920/312*	921-1067*
FET3	2SK34D		GE-FET-2*	PTC161*	REN 132*	SK3448	ECG312*	TM312*	WEP920/312*	921-1067*
	2SK34P		GE-FET-2*	PTC161*	REN 132*	SK3448	ECG312*	TM312*	WEP920/312*	921-1067*
	2SK34		GE-FET-2*	PTC161*	REN 132*	SK3448	ECG312*	TM312*	WEP920/312*	921-1067*
	2SK68		GE-FET-1	PTC151*	REN 133*	SK3448	ECG459*	TM459*	WEP801/133*	921-1019*
FET4	3SK45B		GE-FET-4	PTC182*	REN 222	SK3065/222	ECG222	TM222	WEP905/222	121-826
	3SK45		GE-FET-4	PTC182*	REN 222	SK3065/222	ECG222	TM222	WEP905/222	121-826
	3SK44		GE-FET-4	PTC182*	REN 222	SK3065/222	ECG222	TM222	WEP905/222	121-826
FET5	2SK34D		GE-FET-2*	PTC161*	REN 132*	SK3448	ECG312*	TM312*	WEP920/312*	921-1067*
	2SK34P		GE-FET-2*	PTC161*	REN 132*	SK3448	ECG312*	TM312*	WEP920/312*	921-1067*
	2SK34		GE-FET-2*	PTC161*	REN 132*	SK3448	ECG312*	TM312*	WEP920/312*	921-1067*
	2SK68		GE-FET-1	PTC151*	REN 133*	SK3448	ECG459*	TM459*	WEP801/133*	921-1019*
FET6	2SK33F		GE-FET-2	PTC161	REN 132*	SK3834/132	ECG312*	TM312*	WEP920/312*	921-1067*
	2SK33		GE-FET-2	PTC161	REN 132*	SK3834/132	ECG312*	TM312*	WEP920/312*	921-1067*
FET7	3SK45B		GE-FET-4	PTC182*	REN 222	SK3065/222	ECG222	TM222	WEP905/222	121-826
	3SK45		GE-FET-4	PTC182*	REN 222	SK3065/222	ECG222	TM222	WEP905/222	121-826
IC1	TA7061AP		GEIC-92	PTC781	REN 1100	SK3223/1100	ECG1100	TM1100	WEP941/1100	221-29023
	UPC7061AP		GEIC-92	PTC781	REN 1100	SK3223/1100	ECG1100	TM1100	WEP941/1100	221-29023
IC2	MC1496P						ECG973D	TM973D		
	MC1496A						ECG973D	TM973D		
IC3	UPC592H2					SK3469/1195	ECG1195	TM1195		905-137
	UPC592H2					SK3469/1195	ECG1195	TM1195		905-137
IC4	UPC1156H					SK3484/1194	ECG1194	TM1194	WEP2126/1194	221-29063
IC5	TA7310P				REN 1192	SK3445/1192	ECG1192	TM1192	WEP2120/1192	221-29061
	TA7310				REN 1192	SK3445/1192	ECG1192	TM1192	WEP2120/1192	221-29061
IC6	MC78L05ACP		GEVR-100		REN 977	SK3462/977	ECG977	TM977		221-29044
	78L05		GEVR-100		REN 977	SK3462/977	ECG977	TM977		221-29044
IC7	MC145106P									
	MC145106									
TR1	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR2	2SA628D		GE-82*	PTC103*	REN 159*	SK3114/290	ECG159*	TM159/**	WEP62/159	121-29003*
	2SA628		GE-82*	PTC103*	REN 159*	SK3114/290	ECG159*	TM159/**	WEP62/159	121-29003*
TR3	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR4	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR5	2SC1730L		GE-17*	PTC136*	REN 107	SK3293/107	ECG316*	TM316*	WEP535/107	121-29093
	2SC1730		GE-17*	PTC136*	REN 107	SK3293/107	ECG316*	TM316*	WEP535/107	121-29093
TR6	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
TR7	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
TR8	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
TR9	2SC710D		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
TR10	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293/**	WEP1945	121-29000A*
TR11	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR12	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR13	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR14	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR15	2SC710E		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR16	2SC710D		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR17	2SA628D		GE-82*	PTC103*	REN 159*	SK3114/290	ECG159*	TM159/**	WEP62/159	121-29003*
	2SA628		GE-82*	PTC103*	REN 159*	SK3114/290	ECG159*	TM159/**	WEP62/159	121-29003*
	2SA733		GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
TR18	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-29000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*

PALOMAR MODEL SSB-500

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results) (cont)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA							
			GENERAL ELECTRIC PART No.	MALLORY PART No.	RAYTHEON PART No.	RCA PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
TR19	2SA628D 2SA628 2SA733		GE-82*	PTC103*	REN 159*	SK3114/290	ECG159*	TM159*/**	WEP62/159	121-Z9003*
TR20	2SC710D		GE-82*	PTC103*	REN 159*	SK3114/290	ECG159*	TM159*/**	WEP62/159	121-Z9003*
	2SC710		GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290*/**	WEP911/290	121-Z9067
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC945		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR21	2SC710C		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199*/**	WEP1945	121-972*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC945		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710C		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199*/**	WEP1945	121-972*
TR22	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR23	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199*/**	WEP1945	121-972*
	2SC1419C		GE-66	PTC167	REN 152	SK3197/235	ECG152	TM152	WEP745/152	121-987-03
	2SC1419		GE-66	PTC167	REN 152	SK3197/235	ECG152	TM152	WEP745/152	121-987-03
TR24	2SD712		GE-66	PTC167	REN 152	SK3197/235	ECG152	TM152	WEP745/152	121-987-03
	2SC1419C		GE-66	PTC167	REN 152	SK3197/235	ECG152	TM152	WEP745/152	121-987-03
	2SD712		GE-66	PTC167	REN 152	SK3197/235	ECG152	TM152	WEP745/152	121-987-03
	2SC1419C		GE-66	PTC167	REN 152	SK3197/235	ECG152	TM152	WEP745/152	121-987-03
TR25	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC1675		GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-Z9021*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR26	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC1675		GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-Z9021*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR27	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC1675		GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-Z9021*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR28	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC1675		GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-Z9021*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR29	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR30	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC1675		GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-Z9021*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR31	2SA628D		GE-82*	PTC103*	REN 159*	SK3114/290	ECG159*	TM159*/**	WEP62/159	121-Z9003*
	2SA628		GE-82*	PTC103*	REN 159*	SK3114/290	ECG159*	TM159*/**	WEP62/159	121-Z9003*
	2SA733		GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290*/**	WEP911/290	121-Z9067
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR32	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293*/**	WEP1945	121-Z9000A*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199*/**	WEP1945	121-972*
TR33	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR34	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR35	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR36	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR37	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR38	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR39	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC839		GE-61*	PTC132*	REN 123A*	SK3124/289	ECG293	TM293*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR40	2SC710D		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC1675		GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-Z9021*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR41	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR42	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC710		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
	2SC945		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199*/**	WEP1945	121-972*
	2SC710C		GE-211*	PTC132*	REN 123AP*	SK3356	ECG107*	TM107*/**	WEP710	121-Z9000A*
TR43	2SC1945A		GE-215	PTC186	REN 235	SK3197/235	ECG235	TM235	WEP785/235	121-Z9039
TR44	2SC2166C		GE-285*	PTC143*	REN 293	SK3849/293	ECG293	TM293	WEP912/293	121-Z9066
TR45	2SC1973									

* Lead configuration may vary from original.
 /** Also available as exact type replacement.

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

ELECTROLYTIC CAPACITORS

ITEM No.	RATING	REPLACEMENT DATA				
		MFRG. PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C14	33 16V		PC30-25	VTT33D25	QV1-63	EV-1325
C35	1 50V		PC1-50	VTT1A50	QV1-11	EV-1615
C39	.1 16V			TDC104M050EL	QDT1-2	SD50-R109
C42	10 16V		PC10-25	VTT10B25	QV1-41	EV-1222
C43	4.7 16V		PC5-50	VTT4R7B50	QV1-31	EV-1619.1
C44	2.2 25V		PC2-100	VTT2R2A50	QV1-21	EV-1617.1
C47	47 10V		PC50-16	VTT47D16	QV1-73	EV-1226
C49	47 10V		PC50-16	VTT47D16	QV1-73	EV-1226
C50	47 10V		PC50-16	VTT47D16	QV1-73	EV-1226
C52	.1 16V		PC2-100	TDC104M050EL	QDT1-2	SD50-R109
C55	2.2 25V		PC1-50	VTT2R2A50	QV1-21	EV-1617.1
C58	1 50V		PC50-16	VTT1A50	QV1-11	EV-1615
C59	47 10V			VTT47D16	QV1-73	EV-1226
C60	.1 16V			TDC104M050EL	QDT1-2	SD50-R109
C63	10 10V		PC10-25	VTT10B25	QV1-41	EV-1222
C66	47 10V		PC50-16	VTT47D16	QV1-73	EV-1226
C67	4.7 16V		PC5-50	VTT4R7B50	QV1-31	EV-1619.1
C68	4.7 16V		PC5-50	VTT4R7B50	QV1-31	EV-1619.1
C69	10 16V		PC10-25	VTT10B25	QV1-41	EV-1222
C76	47 10V		PC50-16	VTT47D16	QV1-73	EV-1226
C77	.47 50V		PC1-50	VTT47A63	QV1-3	EV-1610
C78	.47 50V		PC1-50	VTT47A63	QV1-3	EV-1610
C79	.47 50V		PC1-50	VTT47A63	QV1-3	EV-1610
C81	220 16V		PC250-25	VTT220H16	QV1-117	EV-1240
C84	1 50V		PC1-50	VTT1A50	QV1-11	EV-1615
C87	10 16V		PC10-25	VTT10B25	QV1-41	EV-1222
C88	4.7 25V		PC5-50	VTT4R7B50	QV1-31	EV-1619.1
C89	33 16V		PC30-25	VTT33D25	QV1-63	EV-1325
C92	33 16V		PC30-25	VTT33D25	QV1-63	EV-1325
C94	1000 16V		PC1000-16	VTT1000M16	QV1-183	EV-1261
C95	470 16V		PC500-16	VTT470K16	QV1-151	EV-1251
C98	1 50V		PC1-50	VTT1A50	QV1-11	EV-1615
C99	10 16V		PC10-25	VTT10B25	QV1-41	EV-1222
C101	220 16V		PC250-25	VTT220H16	QV1-117	EV-1240
C102	220 16V		PC250-25	VTT220H16	QV1-117	EV-1240
C103	470 10V		PC500-16	VTT470K16	QV1-151	EV-1251
C104	330 10V		WRR300-35*	VTT330G10	QV1-131	EV-1145
C107	1000 16V		PC1000-16	VTT1000M16	QV1-183	EV-1261
C110	.1 16V			TDC104M050EL	QDT1-2	SD50-R109
C120	10 16V		PC10-25	VTT10B25	QV1-41	EV-1222
C135	220 16V		PC250-25	VTT220H16	QV1-117	EV-1240
C140	1 50V		PC1-50	VTT1A50	QV1-11	EV-1615
C141	10 16V		PC10-25	VTT10B25	QV1-41	EV-1222
C158	1 50V		PC1-50	VTT1A50	QV1-11	EV-1615
C161	4.7 25V		PC5-50	VTT4R7B50	QV1-31	EV-1619.1
C179	2.2 25V		PC2-100	VTT2R2A50	QV1-21	EV-1617.1
C199	1 50V		PC1-50	VTT1A50	QV1-11	EV-1615
C211	2.2 25V		PC2-100	VTT2R2A50	QV1-21	EV-1617.1
C218	4.7 25V		PC5-50	VTT4R7B50	QV1-31	EV-1619.1

* Axial replacement for radial device.

PALOMAR MODEL SSB-500

CAPACITORS

ITEM No.	RATING	MFRG. PART No.	REPLACEMENT DATA			
			CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C1	33		NP033	CN0433	QCC2-22	10TCC-Q33
C2	.01 10%			MAG5011		
C3	10 NPO		NP010	CN0410	QCC2-15	10TCC-Q10
C4	.01 10%			MAG5011		
C5	.01 10%			MAG5011		
C6	.01 10%			MAG5011		
C7	.022		NP0100	CN0310	QC1-173	HY-725
C8	100 NPO					10TCC-T10
C9	.001		GP1000	GP210	QC2-81	5GA-D10
C10	.0047		GP4700	GP247		5GA-D47
C11	.0047		GP4700	GP247		5GA-D47
C12	.0047		GP4700	GP247		5GA-D47
C13	.0047		GP4700	GP247		5GA-D47
C15	.01 10%			MAG5011		
C16	.01 10%			MAG5011		
C17	.01 10%			MAG5011		
C18	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C19	.022 10%		DPMS2S22	M192P2239R8	QFT2-127	1FT-S22
C20	.022				QC1-173	HY-725
C21	.022				QC1-173	HY-725
C22	.022				QC1-173	HY-725
C23	.022				QC1-173	HY-725
C24	.001		GP1000	GP210	QC2-81	5GA-D10
C25	.039 10%					1FT-S39
C26	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C27	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C28	.022				QC1-173	HY-725
C29	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C30	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C31	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C32	5 NPO		NP04P7	CN0547	10TCC-V47	
C33	.022				QC1-173	HY-725
C34	.022				QC1-173	HY-725
C36	5 NPO		NP04P7	CN0547	10TCC-V47	
C37	10 NPO		NP010	CN0410	QCC2-15	10TCC-Q10

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFGR. PART No.	REPLACEMENT DATA			
			CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C38	330		GP330	GP333	QCT2-33	10TS-T33
C40	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C41	.022				QC1-173	HY-725
C45	47 NPO 5%		NP047	CN0447	QCC2-26	10TCC-Q47
C46	.01 10%			MAG5011		
C48	.01 10%		WMF1S1	M192P1039R8	QFT2-91	1FT-S10
C51	.022 10%		DPMS2S22	M192P2239R8	QFT2-127	1FT-S22
C53	.01			MAG5011		
C54	33 NPO 5%		NP033	CN0433	QCC2-22	10TCC-Q33
C56	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C57	.022				QC1-173	HY-725
C61	.047 10%		DPMS2S47	M192P4739R8	QFT2-171	1FT-S47
C62	.047 10%		DPMS2S47	M192P4739R8	QFT2-171	1FT-S47
C64	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C71	.068 10%			MAG25168		HY-740
C72	.022 10%		DPMS2S22	M192P2239R8	QFT2-127	1FT-S22
C73	.1 10%		WMF05P1	M192P1049R8	QFT2-215	1FT-P10
C74	.022 10%		DPMS2S22	M192P2239R8	QFT2-127	1FT-S22
C75	.1 10%		WMF05P1	M192P1049R8	QFT2-215	1FT-P10
C80	.01 10%		WMF1S1	M192P1039R8	QFT2-91	1FT-S10
C82	.047 10%		DPMS2S47	M192P4739R8	QFT2-171	1FT-S47
C83	.01 10%		WMF05P1	M192P1049R8	QFT2-215	1FT-P10
C85	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C86	.022 10%		DPMS2S22	M192P2239R8	QFT2-127	1FT-S22
C90	20 NPO 5%		NP020	CN0420	QCC2-19	10TCC-Q20
C91	.1 10%		WMF05P1	M192P1049R8	QFT2-215	1FT-P10
C98	68 10%		NP068	CN0468		10TCC-Q68
C96	.1 10%		WMF05P1	M192P1049R8	QFT2-215	1FT-P10
C100	.022				QC1-173	HY-725
C105	.022				QC1-173	HY-725
C106	.022				QC1-173	HY-725
C108	.01 10%			MAG5011		
C109	.022			MAG16168		HY-640
C111	15 N470			*		10TCU-Q15
C112	15 N470			*		10TCU-Q15
C113	.001		GP1000	GP210	QC2-81	5GA-D10
C114	.001		GP1000	GP210	QC2-81	5GA-D10
C115	100 NPO 10%		NP0100	CN0310		10TCC-T10
C116	10 NPO		NP010	CN0410	QCC2-15	10TCC-Q10
C117	2		NP02P2	CN0522		10TCC-V22
C118	.022				QC1-173	HY-725
C119	.022				QC1-173	HY-725
C121	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C122	47 NPO		NP047	CN0447	QCC2-26	10TCC-Q47
C123	47 NPO		NP047	CN0447	QCC2-26	10TCC-Q47
C124	.01 10%			MAG5011		
C125	.01 10%			MAG5011		
C126	220 NPO 10%					10TCC-T22
C127	470 NPO 10%		GP470	GP347	QCT2-35	10TS-T47
C128	220 NPO 10%					10TCC-T22
C129	.01 10%			MAG5011		
C130	10 NPO		NP010	CN0410	QCC2-15	10TCC-Q10
C131	47 NPO		NP047	CN0447	QCC2-26	10TCC-Q47
C132	47 NPO		NP047	CN0447	QCC2-26	10TCC-Q47
C133	.1 10%		WMF05P1	M192P1049R8	QFT2-215	1FT-P10
C134	.1 10%		WMF05P1	M192P1049R8	QFT2-215	1FT-P10
C136	470 NPO 10%		GP470	GP347	QCT2-35	10TS-T47
C137	220 NPO 10%					10TCC-T22
C138	.01 10%			MAG5011		
C139	10		NP010	CN0410	QCC2-15	10TCC-Q10
C142	56 NPO			CN0456		10TCC-Q56
C144	.022				QC1-173	HY-725
C145	.02			MAG5012		
C146	.022				QC1-173	HY-725
C147	470 10%		GP470	GP347	QCT2-35	10TS-T47
C148	220 10%					10TCC-T22
C149	.01			MAG5011		
C150	10 NPO		NP010	CN0410	QCC2-15	10TCC-Q10
C151	.01 10%			MAG5011		
C152	.01 10%			MAG5011		
C153	68 NPO		NP068	CN0468		10TCC-Q68
C154	.047 10%		DPMS2S47	M192P4739R8	QFT2-171	1FT-S47
C155	2 NPO		NP02P2	CN0522		10TCC-V22
C156	.022				QC1-173	HY-725
C157	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C159	.0047		GP4700	GP247		5GA-D47
C160	.0047		GP4700	GP247		5GA-D47
C162	.02			MAG5012		
C163	68 NPO		NP068	CN0468		10TCC-Q68
C164	150 NPO 10%			CN0315		10TCC-T15
C165	220 NPO 10%					10TCC-T22
C166	.0047		GP4700	GP247		5GA-D47
C167	330 NPO 10%		GP330	GP333	QCT2-33	10TS-T33
C168	1 NPO			CN0510		10TCC-V10
C169	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C170	470 NPO 10%		GP470	GP347	QCT2-35	10TS-T47
C171	47 NPO		NP047	CN0447	QCC2-26	10TCC-Q47
C172	.0047		GP4700	GP247		5GA-D47
C173	180 N220 5%			GP318	QCT2-27	10TS-T18
C174	56 NPO 10%			CN0456		10TCC-Q56
C175	.1 10%		WMF05P1	M192P1049R8	QFT2-215	1FT-P10
C176	120			CN0312		10TCC-T12
C177	.0047		GP4700	GP247		5GA-D47
C178	.0047		GP4700	GP247		5GA-D47

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA			
			CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C182	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C183	.0047		GP4700	GP247		5GA-D47
C184	120 NPO 10%			CN0312		10TCC-T12
C185	.0047		GP4700	GP247		5GA-D47
C186	.0047		GP4700	GP247		5GA-D47
C187	.0047		GP4700	GP247		5GA-D47
C188	.047 10%		DPMS2S47	M192P4739R8	QFT2-171	1FT-S47
C189	.047 10%		DPMS2S47	M192P4739R8	QFT2-171	1FT-S47
C190	.01 10%			MAG5011		
C191	33 NPO 5%		NP033	CN0433	QCC2-22	10TCC-Q33
C192	.01 10%			MAG5011		
C193	.022				QC1-173	HY-725
C194	18 NPO			CN0418		10TCC-Q18
C195	.01 10%			MAG5011		
C196	.022				QC1-173	HY-725
C197	.022				QC1-173	HY-725
C198	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C200	.01 10%		WMF1S1	M192P1039R8	QFT2-91	1FT-S10
C201	.01 10%		WMF1S1	M192P1039R8	QFT2-91	1FT-S10
C204	.01 10%			MAG5011		
C205	.01 10%			MAG5011		
C206	.022				QC1-173	HY-725
C207	.01 10%			MAG5011		
C208	.01 10%			MAG5011		
C209	.01 10%			MAG5011		
C210	.01 10%			MAG5011		
C213	.1 10%		WMF05P1	M192P1049R8	QFT2-215	1FT-P10
C214	.01 10%			MAG5011		
C215	.022				QC1-173	HY-725
C216	.022				QC1-173	HY-725
C217	.022				QC1-173	HY-725
C219	.022				QC1-173	HY-725
C220	.022				QC1-173	HY-725
C221	.022				QC1-173	HY-725
C222	.022				QC1-173	HY-725
C223	.022				QC1-173	HY-725
C224	.022				QC1-173	HY-725
C225	.022				QC1-173	HY-725
C226	.022				QC1-173	HY-725
C227	.022				QC1-173	HY-725
C228	.022				QC1-173	HY-725
C229	.01 10%			MAG5011		
C230	.022				QC1-173	HY-725
C231	.022				QC1-173	HY-725
C241	.039 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S10
C242	47 NPO 5%		NP047	CN0447	QCC2-26	10TCC-Q47
C401	.047 10%		DPMS2S47	M192P4739R8	QFT2-171	1FT-S47
C405	.01 10%			MAG5011		
C406	.01 10%			MAG5011		
C408	.01 10%			MAG5011		
C410	.01 10%			MAG5011		
C415	.01 10%			MAG5011		
C416	.01 10%			MAG5011		
C417	.01 10%			MAG5011		
C418	.01 10%			MAG5011		
C421	.01 10%			MAG5011		
C422	.022				QC1-173	HY-725
C423	.022				QC1-173	HY-725
C606	.01 10%			MAG5011		
C608	.01 10%			MAG5011		

* Not normally in distributor's stock. Available thru distributor on order to manufacturer.

PALOMAR MODEL SSB-500

CONTROLS (All wattages 1/2 watt, or less, unless listed)

ITEM No.	FUNCTION	RESISTANCE	REPLACEMENT DATA		
			MFR. PART No.	MALLORY PART No.	TRW PART No.
VR1	Signal Meter	20K	(6)	RVA0911H253	U260R253B
VR2	RF Gain	100K		RVA0911H104	U260R104B
VR3	RF Gain	20K			
VR4	Squelch Range	100K		RVA0911H104	U260R104B
VR5	Balance	50K		RVA0911H503	U260R503B
VR6	AM RX Gain	100K		RVA0911H104	U260R104B
VR7	Mic Level	5000			
VR8	AM AMC	5000		RVA0911H502	U260R502B
VR9	AM TX Level	10K		RVA0911H103	U260R103B
VR12	TX Freq	5000		RVA0911H502	U260R502B
VR15	TX Power Meter	100K		RVA0911H104	U260R104B
VR16	Bias	500		RVA0911H501	U260R501B
VR401	Bias	500		RVA0911H501	U260R501B
VR404	Clarifier	20K			
VR405	Squelch	100K			
VR408	Volume/Switch	10K			
VR408	Mic Gain	20K		RVA0911H253	U260R253B

(6) Alternate part, may be used in some versions.

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

RESISTORS (Power and Special)

ITEM No.	RATING	REPLACEMENT DATA		ITEM No.	RATING	REPLACEMENT DATA	
		MFCR. PART No.	WORKMAN PART No.			MFCR. PART No.	WORKMAN PART No.
R107	10 5W WW		24-3030				

COILS (RF-IF)

ITEM No.	FUNCTION	REPLACEMENT DATA			REMARKS
		PART No.	OTHER IDENTIFICATION	MILLER PART No.	
L1	Noise Blanker		LA029	CBS740-T	
L2	Noise Blanker		LA155		
L3	Rec Antenna (27MHz)		LA152		
L4	Rec RF (27MHz)		LA156		
L5	Rec Mixer (7.8MHz)		LA179		
L7	Carrier Insert (7.8MHz)		LA038	CBS512-7TC	
L8	IF (7.8MHz)		LA096	CBS511-7TC	
L9	RF Choke (470uH)				
L10	RF Choke (56mH)				
L11	RF Choke (68mH)				
L12	RF Choke (470uH)				
L13	RF Choke (470uH)				
L14	RF Choke (470uH)				
L16	VCO Output (34MHz)		LA160		
L17	VCO Osc.		LA191		
L18	RF Choke (470uH)				
L19	RF Choke (100uH)				
L20	RF Choke (470uH)				
L21	RF Choke (470uH)				
L22	RF Choke (470uH)				
L23	RF Choke (470uH)				
L24	Tripler (33MHz)		LA190		
L25	RF Choke (470uH)				
L26	RF Choke (470uH)				
L27	RF Choke				
L28	RF Choke				
L29	RF Choke				
L30	XMT Antenna (27MHz)				
L31	RF Choke				
L32	Final (27MHz)				
L33	RF Choke				
L34	RF Choke				
L35	XMT Amp				
L36	XMT Buffer				
L37	XMT Mixer (27MHz)		JHLA157(1)		
L38	XMT Mixer (27MHz)		JHLA157(1)		
L39	XMT Mixer (7.8MHz)		LA038	CBS512-7TC	
L40	RF Choke				
L43	RF Choke (1uH)				
L44	RF Choke (1uH)				
L45	RF Choke (470uH)				
L401	RF Choke (4.7uH)				
L403	RF Choke (4.7uH)				
L405	RF Choke (4.7uH)				
L406	RF Choke (4.7uH)				
L407	RF Choke (4.7uH)				
L408	RF Choke (4.7uH)				
L410	RF Choke (4.7uH)				
L411	RF Choke (4.7uH)				
L412	RF Choke (4.7uH)				

(1) Number on unit.

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

TRANSFORMER (Audio Output)

ITEM No.	IMPEDANCE		REPLACEMENT DATA			NOTES
	PRI.	SEC.	MFGR. PART No.	THORDARSON PART No.	TRIAD PART No.	
T1	7.5	12.6	TF106			

SPEAKER


ITEM No.	TYPE	REPLACEMENT DATA		NOTES
		MFGR. PART No.	QUAM PART No.	
SP401	3 1/2" PM, 8 Ohms		3A0528	

FUSE DEVICES

ITEM No.	DESCRIPTION	REPLACEMENT DATA					
		PART No.		BUSS PART No.		LITTELFUSE PART No.	
		DEVICE	HOLDER	DEVICE	HOLDER	DEVICE	HOLDER
F401	3A Quick-acting			AGC3	HRK	312003	150145

MISCELLANEOUS

ITEM No.	PART NAME	PART No.	NOTES
D65	LED		Red 50 1.90V @ 8mA, TX
D66	LED		Green 50 2.07V @ 14mA, RX
D401	LED		Channel Indicator (Each segment supplied with 1.93V @ 8mA)
FT1	Filter		7.8MHz
J401	Jack		Antenna Connector
J402	Connector		Microphone
J403	Jack		3P, PA, SP
J404	Jack		3P, EXT SP
J407	Jack		DC
M401	Meter		200UA, SIG/RF/TX Power (Includes PL401 Lamp)
PL401	Lamp		13.71V @ 40mA (Part of M401)
RL1	Relay		RL023, 3P
S401	Switch		Off/NB, Slide
S402	Switch		AM/USB/LSB, Rotary
S403	Switch		NB/Off, Slide
S404	Switch		RF Gain/On/Off, Slide
S405	Switch		CB/PA, Slide
S406	Switch		Red/Orange
S407	Switch		Brite/Dim, Slide
S408	Switch		Channel Selector
X1	Crystal		X-TAL 7.8025MHz, HC-25C/U
X2	Crystal		X-TAL 7.7975MHz, HC-25C/U
X3	Crystal		X-TAL 11.2858MHz, HC-25C/U
X4	Crystal		X-TAL 11.2842MHz, HC-25C/U
X5	Crystal		X-TAL 10.240MHz, HC-25C/U
X6	Crystal		X-TAL 11.2850MHz, HC-25C/U
	Microphone		
	P.C. Board		A
	P.C. Board		B
	P.C. Board		Main



PHOTOFACT[®] with

CIRCUITRACE[®]

For Supplier Address See PHOTOFACT Index

NOTE

Repair or adjustment of transmitter circuits must be under supervision of a person with first-or second-class radiotelephone license.

(Refer to FCC Rules and Regulations Part 95, Subpart C & D.)

The frequency of the transmitter should be checked periodically with a secondary frequency standard to insure proper and legal operation.

Best results will be obtained when adjusting the final RF output circuit if the antenna normally used is connected and the chassis is as nearly in the cabinet as possible.

Connect either 50-ohm dummy load or the normally used antenna system.



MODEL STALKER XV

MANUFACTURER'S SPECIFICATIONS

GENERAL

Channels	40
Frequency Range	26.965 MHz to 27.405 MHz
Frequency Control	PLL Synthesized
Antenna Impedance	50 ohm
Power Input	117V AC or 13.8V DC
Accessories	AC and DC power cord, detachable dynamic microphone, microphone hanger, mounting bracket
Size	14-31/32"(W) x 12-13/32"(D) x 4-23/32"(H); including knobs
Weight	14-1/4 lbs.

TRANSMITTER

Output Power	AM 4 watts SSB 12 watts PEP
Emission Type AM	6A3
Emission Type SSB	3A3J
Hum and Noise	Better than -60dB
Frequency Tolerance	0.003%
Modulation Percentage (Peak)	100%

RECEIVER

Sensitivity at 10 dB S+N/N	AM 0.5 μ V SSB 0.25 μ V
Sensitivity for 500 mW Audio Output	AM 0.25 μ V SSB 0.15 μ V
Squelch Threshold	AM 0.5 μ V SSB 0.5 μ V
Squelch Deepest Point	1000 μ V
"S" Meter S-9	100 μ V
Delta Tune/Clarifier	$\pm$ 1.25 kHz
Maximum AF Output Power	4 watts
AF Output Power/10% Distortion	3 watts
Selectivity BW @ 6 dB Down	6 kHz
Adjacent Channel Rejection	-55 dB
Image Rejection	Greater than -40 dB
Speaker Impedance	8 ohms

PUBLIC ADDRESS

Output Power @ 10% Distortion	3.0 Watts
-------------------------------	-----------

TEABERRY MODEL Stalker XV

Courtesy of the Manufacturer

HOWARD W. SAMS & CO., INC. Indianapolis, Indiana 46206

© 1980 Howard W. Sams & Co., Inc. Printed in U. S. of America

9CF1085

ALIGNMENT INSTRUCTIONS

CAUTION: Use isolation transformer or observe polarity when connecting test equipment. Maintain line voltage at 120V AC. Allow a 15-minute warm-up period. Adjust RT301 for 13.80 volts at TP15. Connect low sides of test equipment to ground unless specified otherwise. Connect 50-ohm dummy load or antenna before keying transmitter. Connect microphone.

Suggested Alignment Tools:

GC ELECTRONICS:

L1 thru L10, L13, L14, L17 thru L20, L26 thru L29 ... 9440

L36, L39 8728, 8728A, 9304

CT1, CT2, CT3 5000, 8276, 9089

SYNTHESIZER ALIGNMENT

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Input of frequency counter to TP12 (IC2 Pin 8).	Ch. 19, AM		Check for 10.240MHz.
Input of oscilloscope to TP16 (L18 Secondary).	Ch. 19, AM Clarifier Midrange	L18	Adjust for maximum RF (200mV typical). (See Figure 1.)
Input of DC meter to TP9 (IC1 Pin 5).	Ch. 40, AM	L13	Adjust for 5.00 volts. Check for approx. 3.30 volts on channel 1.
Input of oscilloscope to TP1 (L14 Secondary).	Ch. 19, USB	L14	Adjust for maximum RF (1.40 volts typical). (See Figure 2.)
Input of frequency counter to TP1 (L14 Secondary).	Ch. 19, USB Clarifier Midrange	CT3	Adjust for 34.9875MHz +20Hz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP1 (L14 Secondary).	Ch. 19, LSB Clarifier Midrange	L19	Adjust for 34.9825MHz +20Hz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP1 (L14 Secondary).	Ch. 19, AM Clarifier Midrange	L20	Adjust for 34.9850MHz +20Hz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP1 (L14 Secondary).	Ch. 19, XMT, LSB	VR3	Adjust for 34.9825MHz +20Hz.
Input of frequency counter to TP10 (Junction of L12 and C68).	Ch. 1, USB		Check for 1.430MHz. Check all channels. (See Truth Chart for correct frequencies.)
Input of frequency counter to TP3 (TR13 Base).	Ch. 19, USB	CT1	Adjust for 7.8025MHz +5Hz or -0Hz.
Input of frequency counter to TP3 (TR13 Base).	Ch. 19, LSB	CT2	Adjust for 7.7975MHz +0Hz or -5Hz.
Input of frequency counter to TP3 (TR13 Base). Disconnect TP7 and TP8 (at Final Amp TR41).	Ch. 19, XMT, AM	L17	Adjust for 7.8000MHz +5Hz.

RECEIVER ALIGNMENT

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.
Set generator output low enough to prevent AGC limiting.
Mode AM, RF Gain Maximum, Squelch MINIMUM, Clarifier Midrange, ANL/NB Off.

AM

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to TP13 (TR10 Collector). 7.8MHz, 1000Hz @ 30% modulation.	Ch. 19	L3, L4	Adjust for maximum output.
Output of signal generator thru .01uF to antenna input. 27.185MHz, 1000Hz @ 30% modulation	Ch. 19	L5, L6, L7 L8, L9, L10	Adjust for maximum output. If necessary readjust L3 and L4 for maximum.
Output of signal generator thru .01uF to antenna input. Input of oscilloscope to TP14 (TR6 Emitter). Inject a 100pps, 1uSec. pulse width signal at antenna input. Output 10db signal to noise plus noise ratio of receiver.	Ch. 19 ANL/NB On	L1, L2	Adjust for maximum amplitude pulses. (3.2 volts typical.) (See Figure 3.)

RECEIVER ADJUSTMENTS

Connect an AC VTVM or AF wattmeter across speaker voice coil.
Adjust volume control to obtain a suitable indication.
Mode AM, RF Gain Maximum, Squelch MINIMUM, Clarifier Midrange, ANL/NB Off.

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Output of signal generator thru .01uF to antenna input. 27.185MHz, 1000Hz @ 30% modulation Output 1000uV.	Ch. 19 Squelch Maximum	VR2	SQUELCH RANGE Adjust so that squelch just breaks.
Output of signal generator thru .01uF to antenna input. 27.185MHz, 1000Hz @ 30% modulation Output 100uV.	Ch. 19 S/RF/MOD S/RF	VR1	SIG METER Adjust for 9 on sig scale of meter.

TRANSMITTER ALIGNMENT

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.
NOTE: Be sure to check transmit frequency and power on all active channels after alignment of transmitter.
See page 4 for channel frequencies.

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Input of RF wattmeter and 50-ohm, 25 watt dummy load to antenna input. Inject a two tone 50mV signal at Mic input.	Ch. 19, USB Mike Gain Maximum	L26, L27 L28, L29, L36	Set VR 7 to MINIMUM. Adjust for maximum RF output.
Input of spectrum analyzer or harmonic meter to antenna input.	Ch. 19, AM Mike Gain MINIMUM	L39	Adjust for MINIMUM at 54MHz (2nd harmonic).

TEABERRY MODEL Stalker XV

TRANSMITTER ADJUSTMENTS

Connect an RF wattmeter and 50-ohm, 25-watt dummy load to antenna connector.

NOTE: Be sure to check transmit frequency and power on all active channels after adjustment of transmitter.

See page 4 for channel frequencies.

TEST EQUIPMENT	TRANSCIVER	ADJUST	REMARKS
Input of oscilloscope or modulation meter to antenna input.	Ch. 19, AM S/RF/MOD MOD	VR12	MOD METER Adjust so that MOD meter agrees with external modulation meter.
Insert a 0-150mA DC current meter at TP8. No modulation.	Ch. 19, USB Mike Gain MINIMUM	VR8	RF DRIVER BIAS Adjust for 35mA idle current. Reconnect TP8.
Insert a 0-150mA DC current meter at TP7. No modulation.	Ch. 19, USB Mike Gain MINIMUM	VR9	RF FINAL BIAS Adjust for 45mA idle current. Reconnect TP7.
Input of RF wattmeter and 50-ohm, 25 watt dummy load to antenna input. No modulation.	Ch. 19, USB Mike Gain MINIMUM	VR5	CARRIER BALANCE Adjust for MINIMUM RF output. Check LSB and readjust if necessary for MINIMUM RF output.
Input of RF wattmeter and 50-ohm, 25 watt dummy load to antenna input. Inject a two tone, 50mV signal at Mic input.	Ch. 19, USB Mike Gain Maximum	VR7	RF ALC Adjust for 11.0 watts PEP RF output maximum.
Input of RF wattmeter and 50-ohm, 25 watt dummy load to antenna input. No modulation.	Ch. 19, AM Mike Gain MINIMUM	VR6	AM POWER Adjust for 4.0 watts RF output maximum.
Input of RF wattmeter and 50-ohm, 25 watt dummy load to antenna input. No modulation.	Ch. 19, AM Mike Gain MINIMUM S/RF/MOD S/RF	VR10	RF PWR METER Adjust so that PWR meter agrees with RF wattmeter.




Figure 1




Figure 2





Figure 3

TRUTH CHART


Truth Chart

Channel	1 = 7.98 Volts 0 = 0 Volts								DIVIDER INPUT IN MHz AT TP10	AM REC VCO OUTPUT IN MHz AT TP1	USB REC VCO OUTPUT IN MHz AT TP1
	IC2 PROGRAM DIVIDER										
	PINS										
	11	12	13	14	15	16					
1	0	0	1	1	1	1			1.430	34.765	34.7675
2	0	1	0	0	0	0			1.440	34.775	34.7775
3	0	1	0	0	0	1			1.450	34.785	34.7875
4	0	1	0	0	1	1			1.470	34.805	34.8075
5	0	1	0	1	0	0			1.480	34.815	34.8175
6	0	1	0	1	0	1			1.490	34.825	34.8275
7	0	1	0	1	1	0			1.500	34.835	34.8375
8	0	1	1	0	0	0			1.520	34.855	34.8575
9	0	1	1	0	0	1			1.530	34.865	34.8675
10	0	1	1	0	1	0			1.540	34.875	34.8775
11	0	1	1	0	1	1			1.550	34.885	34.8875
12	0	1	1	1	0	1			1.570	34.905	34.9075
13	0	1	1	1	1	0			1.580	34.915	34.9175
14	0	1	1	1	1	1			1.590	34.925	34.9275
15	1	0	0	0	0	0			1.600	34.935	34.9375
16	1	0	0	0	1	0			1.620	34.955	34.9575
17	1	0	0	0	1	1			1.630	34.965	34.9675
18	1	0	0	1	0	0			1.640	34.975	34.9775
19	1	0	0	1	0	1			1.650	34.985	34.9875
20	1	0	0	1	1	1			1.670	34.005	35.0075
21	1	0	1	0	0	0			1.680	35.015	35.0175
22	1	0	1	0	0	1			1.690	35.025	35.0275
23	1	0	1	1	0	0			1.720	35.055	35.0575
24	1	0	1	0	1	0			1.700	35.035	35.0375
25	1	0	1	0	1	1			1.710	35.045	35.0475
26	1	0	1	1	0	1			1.730	35.065	35.0675
27	1	0	1	1	1	0			1.740	35.075	35.0775
28	1	0	1	1	1	1			1.750	35.085	35.0875
29	1	1	0	0	0	0			1.760	35.095	35.0975
30	1	1	0	0	0	1			1.770	35.105	35.1075
31	1	1	0	0	1	0			1.780	35.115	35.1175
32	1	1	0	0	1	1			1.790	35.125	35.1275
33	1	1	0	1	0	0			1.800	35.135	35.1375
34	1	1	0	1	0	1			1.810	35.145	35.1475
35	1	1	0	1	1	0			1.820	35.155	35.1575
36	1	1	0	1	1	1			1.830	35.175	35.1675
37	1	1	1	0	0	0			1.840	35.175	35.1775
38	1	1	1	0	0	1			1.850	35.185	35.1875
39	1	1	1	0	1	0			1.860	35.195	35.1975
40	1	1	1	0	1	1			1.870	35.205	35.2075


TEABERRY MODEL Stalker XV




CHASSIS-VIEW




CHASSIS VIEW




MAIN BOARD



MAIN BOARD




MAIN BOARD




TEABERRY MODEL Stalker XV

MAIN BOARD




MAIN BOARD




TEABERRY MODEL Stalker XV


MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD




MAIN BOARD





MAIN BOARD




TEABERRY MODEL Stalker XV




CHANNEL SELECTOR BOARD





AC POWER BOARD




TEABERRY MODEL Stalker XV




PHONE JACK BOARD




MIC JACK BOARD



TEABERRY MODEL Stalker XV




PA-EXT SPEAKER BOARD




INDICATOR BOARD


A Howard W. Sams **CIRCUITRACE®** Photo



SWITCH BOARD



AC INPUT FILTER BOARD




* LOCATED ON OTHER SIDE OF BOARD

CHANNEL READOUT BOARD






© Howard W. Sams & Co., Inc. 1980







PARTS LIST AND DES

(When ordering parts, state Model,)

WIRING DATA

Cable (Speaker) (Unsh

Shielding Strap.....

Hook-up Wire (Genera

Hook-up Wire (Shilde

Coax (Transmission L

Microphone Cable (Co


Microphone Cable (Co

AC Power Cord.....

AC Power Cord.....

SEMICONDUCTORS (Sel

ITEM No.	TYPE No.	MFG. PART No.
D1	1N60	DDAY001004
D2	1N60	DDAY001004
D3	1S1588	DDAY047001
D4	1S1588	DDAY047001
D5	1S1588	DDAY047001
D6	1S1588	DDAY047001
D7	1S1588	DDAY047001
D8	1S1588	DDAY047001
D9	1N60	DDAY001004
D10	1S1588	DDAY047001
D11	1S1588	DDAY047001
D12	1S1588	DDAY047001
D13	MC301	DDAY090001
D14	MC301	DDAY090001
D15	1S1588	DDAY047001
D16	1S1588	DDAY047001
D17	1S1588	DDAY047001
D18	1S1588	DDAY047001
D19	1S1588	DDAY047001
D20	1S1588	DDAY047001
D21	1N60	DDAY001004
D22	1N60	DDAY001004
D23	1S1588	DDAY047001
D24	1S1588	DDAY047001
D25	1S1588	DDAY047001
D26	1S1588	DDAY047001
D27	1S1588	DDAY047001
D28	1S1588	DDAY047001
D29	1S1588	DDAY047001
D30	1S1588	DDAY047001
D31	1S1588	DDAY047001
D32	1S1588	DDAY047001
D33	1S1588	DDAY047001
D34	1S1588	DDAY047001
D35	1S1588	DDAY047001
D36	1S1588	DDAY047001
D37	1S2687D	DDAY067001
D38	1S1588	DDAY047001
D39	1S1588	DDAY047001
D40	1S1588	DDAY047001
D41	1S1588	DDAY047001
D42	1N60	DDAY001004
D43	1S1588	DDAY047001
D44	1S1588	DDAY047001
D46	MV1Y	DDFY020001
D47	MV1 3YH	DDFY021001
D48	1S1588	DDAY047001
D49	1S1588	DDAY047001
D50	1S1588	DDAY047001
D53	1N60	DDAY001004
D61	1S1588	DDAY047001
D62	1S1588	DDAY047001
D64	1S1588	DDAY047001
D70	1S1588	DDAY047001
D301	WZ061	DDAY008001
D302	BZ162	DDAY009003
D407	SRT K2	DDAY002002
D408	SSVB10	DDAY066001
FET1	2SK198L	DDCY001002
IC1	UHIC-007	DDEY133001
IC2	MB8719	DDEY101001
IC3	AN612	DDEY130001
IC4	TA7222P	DDEY146001
IC5	MB3756	DDEY131001
IC6	SO42P	DDEY132001
TR1	2SC1675L	DDBY259001
TR2	2SC1675L	DDBY259001
TR3	2SC1730L	DDBY269001
TR4	2SC945Q	DDBY224003
	2SC945AQ	DDBY224003




✕ Circuitry not used in some versions.
 --- Circuitry used in some versions.
 ✱ Nominal value ▽ Common tie point
 ⊥ Ground
 [] Chassis
 See parts list
 Waveforms and Voltages taken in Channel 19 with switching in receive unless noted. Item numbers in rectangles appear in the alignment/adjustment instructions.
 A PHOTOFAC STANDARD NOTATION SCHEMATIC WITH **CIRCUITRACE™**
 © Howard W. Sams & Co., Inc. 1980

Supply voltage maintained as shown at input. Voltages measured with digital meter, no signal. Controls adjusted for normal operation. Terminal identification may not be found on unit. Resistors are 1/2W or less, 5% unless noted. Value in () used in some versions. Arrow head(s) at coils and transformers indicates accessibility of tuning slug(s).

PLL SCHEMATIC

TEABERRY MODEL Stalker XV



PLL SCHEMATIC

TEABERRY MODEL Stalker XV

PARTS LIST AND DESCRIPTION

(When ordering parts, state Model, Part Number, and Description.)

WIRING DATA

Cable (Speaker) (Unshielded).....	Use BELDEN No. 8782 (AWG24) (4 colors)
Shielding Strap.....	Use BELDEN No. 8660 (3/16" width)
Hook-up Wire (General Use).....	Use BELDEN No. 8524 (AWG22) (13 colors)
Hook-up Wire (Shielded).....	Use BELDEN No. 8401 (Braided Shield) (1 conductor) (AWG25)
	Use BELDEN No. 8421 (Spiral Shield) (1 conductor) (AWG25)
	Use BELDEN No. 8737 (Spiral Shield) (2 conductor) (AWG22)
Coax (Transmission Line).....	Use BELDEN No. 8216 (RG-174/U, 50 ohms)
Microphone Cable (Coiled).....	Use BELDEN No. 8491 (4 conductor-2 shielded) (6 ft.) (AWG23)
Microphone Cable (Coiled).....	Use BELDEN No. 9467 (5 conductor-1 shielded) (6 ft.) (AWG28)
AC Power Cord.....	Use BELDEN No. 17106 (6 ft.) (2 conductors)
AC Power Cord.....	Use BELDEN No. 17109 (9 ft.) (2 conductors)

SEMICONDUCTORS (Select replacement transistor for best results)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA							
			GENERAL ELECTRIC PART No.	MALLORY PART No.	RAYTHEON PART No.	RCA PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
D1	1N60	DDAY001004	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D2	1N60	DDAY001004	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D3	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D4	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D5	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D6	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D7	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D8	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D9	1N60	DDAY001004	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D10	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D11	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D12	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D13	MC301	DDAY090001	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
D14	MC301	DDAY090001	GE-300	PTC214	REN 177	SK3175/177	ECG177	TM177	WEP1062/177	103-131
D15	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D16	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D17	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D18	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D19	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D20	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D21	1N60	DDAY001004	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D22	1N60	DDAY001004	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D23	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D24	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D25	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D26	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D27	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D28	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D29	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D30	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D31	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D32	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D33	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D34	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D35	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D36	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D37	1S26870	DDAY067001	GE-514	PTC214	REN 612	SK3325/612	ECG612	TM612	WEP925/519	103-176
D38	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D39	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D40	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D41	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D42	1N60	DDAY001004	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D43	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D44	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D46	MV1Y	DDFY020001	GE-514	PTC301	REN 601	SK3463/601	ECG601	TM601	WEP925/519	103-131
D47	MV1 3YH	DDFY021001	GE-514	PTC302	REN 177	SK3864/605	ECG605	TM605	WEP925/519	103-131
D48	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D49	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D50	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D53	1N60	DDAY001004	1N60	PTC206	REN 109	SK3088	ECG109	TM109/**	WEP134/109	103-Z9001
D61	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D62	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D64	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D70	1S1588	DDAY047001	GE-514	PTC214	REN 177	SK3100/519	ECG519	TM519	WEP925/519	103-131
D301	WZ061	DDAY008001	GEZD-6.2	ZB6.28	REN 137	SK3058/137A	ECG137A	TM137A/**	WEP1154/137A	103-Z9008
D302	BZ162	DDAY009003	GEZD-16	ZB16B	REN 5075	SK3751/5075A	ECG5075A	TM5075A/**	WEP1160/5075A	103-Z9013
D407	SRI K2	DDAY002002	GE-504A	PTC201	REN 116	SK3311	ECG116	TM116	WEP156	212-76-02
D408	SSVB10	DDAY066001	GE-206	PTC204(4)	REN 156(4)	SK3051/156(4)	ECG513	TM156(4)	WEP1044	212-Z9000(4)
FET1	2SK198L	DDCY001002	GE-FET-2	PTC161	REN 132*	SK3834/132	ECG132*	TM132*	WEP920/312*	921-1067*
IC1	UHC-007	DDEY133001					ECG1262	TM1262		
IC2	MB8719	DDEY101001								
IC3	AN612	DDEY130001								
IC4	TA7222P	DDEY146001								
IC5	MB3756	DDEY131001								
IC6	S042P	DDEY132001								
TR1	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-Z9021*
TR2	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-Z9021*
TR3	2SC1730L	DDBY269001	GE-17*	PTC136*	REN 107	SK3293/107	ECG316*	TM316*	WEP535/107	121-Z9093
TR4	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
	2SC945AQ		GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

SEMICONDUCTORS (Select replacement transistor for best results) (cont)

ITEM No.	TYPE No.	MFR. PART No.	REPLACEMENT DATA							
			GENERAL ELECTRIC PART No.	MALLORY PART No.	RAYTHEON PART No.	RCA PART No.	SYLVANIA PART No.	THORDARSON PART No.	WORKMAN PART No.	ZENITH PART No.
TR5	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR6	2SC945AQ	DDBY259001	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR7	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-29021*
TR8	2SA733P	DDBY003001	GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
TR9	2SC1730L	DDBY269001	GE-17*	PTC136*	REN 107	SK3293/107	ECG316*	TM316*	WEP535/107	121-29093
TR10	2SC945AQ	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR11	2SC1674L	DDBY295002	GE-61*	PTC132*	REN 229*	SK3132	ECG229*	TM229*	WEP784	121-29021*
TR12	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-29021*
TR13	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR14	2SC945AQ	DDBY259001	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR15	2SA733P	DDBY003001	GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
TR16	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR17	2SC1674L	DDBY295002	GE-61*	PTC132*	REN 229*	SK3132	ECG229*	TM229*	WEP784	121-29021*
TR18	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-29021*
TR19	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR20	2SC945AQ	DDBY259001	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR21	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-29021*
TR22	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-29021*
TR23	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-29021*
TR24	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-29021*
TR25	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-29021*
TR27	2SC945AQ	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR28	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR29	2SC945AQ	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR30	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR31	2SA733AP	DDBY003001	GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
TR32	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR33	2SC945AQ	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR34	2SC1419C	DDBY278002	GE-66	PTC167	REN 152	SK3197/235	ECG152	TM152	WEP745/152	121-987-03
TR35	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR36	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR37	2SC458C	DDBY273001	GE-210	PTC121*	REN 289	SK3124/289	ECG289	TM289/**	WEP458	121-29065
TR38	2SC945AQ	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR39	2SC1973	DDBY272001	GE-285*	PTC143*	REN 293	SK3849/293	ECG293	TM293	WEP912/293	121-29066
TR40	2SC1306	DDBY230001	GE-215	PTC186	REN 235	SK3239/236	ECG235	TM235/**	WEP785/235	121-29039
TR41	2SC496-0	DDBY246001	GE-57	PTC163	REN 295	SK3253/295	ECG295	TM295/**	WEP913/295	121-880
TR42	2SC1969B	DDBY307001	GE-216	PTC186	REN 236	SK3239/236	ECG236	TM236	WEP840/236	121-29040
TR43	2SC1675L	DDBY259001	GE-213	PTC132*	REN 229*	SK3122	ECG229*	TM229*	WEP773	121-29021*
TR44	2SC945Q	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR45	2SC945AQ	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR46	2SA733AP	DDBY003001	GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
TR47	2SA733P	DDBY003001	GE-48	PTC127	REN 294	SK3114/290	ECG290	TM290/**	WEP911/290	121-29067
TR301	2SC945AQ	DDBY224003	GE-212	PTC121*	REN 199	SK3124/289	ECG199	TM199/**	WEP1945	121-972*
TR302	2SC1419C	DDBY278002	GE-66	PTC167	REN 152	SK3197/235	ECG152	TM152	WEP745/152	121-987-03
TR401	2SD188M	DDBY403001	GE-75	PTC118	REN 130	SK3297/280	ECG130	TM130	WEP704/130	121-29011

* Lead configuration may vary from original.

/** Also available as exact type replacement.

(4) Four required.

TEABERRY MODEL Stalker XV

ELECTROLYTIC CAPACITORS

ITEM No.	RATING	REPLACEMENT DATA				
		MFR. PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
C7	.22 35V	CSEZ512286		TDC224M050EL	QDT1-10	SD50-R229
C13	.1 35V	CSEZ511086		TDC104M050EL	QDT1-2	SD50-R109
C15	2.2 25V	CELZ512290	PC2-100	VTT2R2A50	QV1-21	EV-1617.1
C16	2.2 25V	CSEZ512296		TDC225M035FL	QV1-3	SD35-2R29
C17	.47 50V	CELZ814780	PC1-50	VTT4R7A63	QV1-3	EV-1610
C19	.22 35V	CSEZ512286		TDC224M050EL	QDT1-10	SD50-R229
C24	.47 10V	CELZ114700	PC50-16	VTT47D16	QV1-73	EV-1226
C26	.47 10V	CELZ114700	PC50-16	VTT47D16	QV1-73	EV-1226
C27	.47 50V	CELZ814780	PC1-50	VTT4R7A63	QV1-3	EV-1610
C59	1 25V	CSEZ511096		TDC105M035EL	QDT1-10	SD35-19
C62	2.2 25V	CSEZ512296		TDC225M035FL	QV1-179	SD35-2R29
C63	2.2 25V	CSEZ512296		TDC225M035FL	QDT1-48	SD35-2R29
C66	1000 10V	CELZ111020	PC1000-16	VTT1000L10	QV1-179	EV-1161
C72	4.7 10V	CSEZ114796		TDC475M010EL	QDT1-48	SD10-4R79
C73	4.7 25V	CELZ514790	PC5-50	VTT4R7B50	QV1-31	EV-1619.1
C79	4.7 10V	CELZ114700	PC50-16	VTT47D16	QV1-73	EV-1226
C83	2.2 25V	CELZ512290	PC2-100	VTT2R2A50	QV1-21	EV-1617.1
C84	22 6V	CSEZ902206		TDC226M015FL	QDT1-82	SD15-229
C90	10 16V	CELZ311000	PC10-25	VTT10B25	QV1-41	EV-1222
C92	47 10V	CELZ114700	PC50-16	VTT47D16	QV1-73	EV-1226
C107	220 10V	CELZ112210	PC250-10	VTT220F10	QV1-115	EV-1140

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

ELECTROLYTIC CAPACITORS (cont)

ITEM No.	RATING	REPLACEMENT DATA				
		MFR. PART No.	CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C108	.47 50V	CELZ814780	PC1-50	VTT47A63	QV1-3	EV-1610
C109	22 6V	CSEZ902206		TDC226M015FL	QDT1-82	SD15-229
C112	4.7 25V	CELZ514790	PC5-50	VTT47B50	QV1-31	EV-1619.1
C113	22 6V	CSEZ902206		TDC226M015FL	QDT1-82	SD15-229
C114	47 10V	CELZ114700	PC50-16	VTT47D16	QV1-73	EV-1226
C117	10 25V	CELZ511000	PC10-25	VTT10B25		EV-1422
C118	470 10V	CELZ114710	PC500-16	VTT470K16	QV1-151	EV-1251
C119	1 50V	CELZ811090	PC1-50	VTT1A50	QV1-11	EV-1615
C120	10 16V	CELZ311000	PC10-25	VTT10B25	QV1-41	EV-1222
C121	.47 50V	CELZ814780	PC1-50	VTT47A63	QV1-3	EV-1610
C133	10 16V	CELZ311000	PC10-25	VTT10B25	QV1-41	EV-1222
C134	1000 25V	CELZ511020	WBR1000-25*	VTT1000N25	QV1-185	EV-1360
C141	2.2 50V		PC2-100	VTT2R2A50	QV1-21	EV-1617.1
C142	.47 50V	CELZ814780	PC1-50	VTT47A63	QV1-3	EV-1610
C146	1 50V	CELZ811090	PC1-50	VTT1A50	QV1-11	EV-1615
C162	1 50V	CELZ811090	PC1-50	VTT1A50	QV1-11	EV-1615
C164	10 25V	CELZ511000	PC10-25	VTT10B25		EV-1422
C169	1 50V	CELZ811090	PC1-50	VTT1A50	QV1-11	EV-1615
C180	22 10V	CELZ112200	PC25-25	VTT22B16	QV1-55	EV-1224
C183	1 50V	CELZ811090	PC1-50	VTT1A50	QV1-11	EV-1615
C191	47 10V	CELZ114700	PC50-16	VTT47D16	QV1-73	EV-1226
C193	1 25V	CSEZ511096		TDC105M035EL		SD35-19
C215	47 10V	CELZ114700	PC50-16	VTT47D16	QV1-73	EV-1226
C302	220 16V	CELZ312210	PC250-25	VTT220H16	QV1-117	EV-1240
C304	3300 35V	CCZY046001	AA0155A	FP062		TVLU-1129

* Axial replacement for radial device.

CAPACITORS

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA			
			CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C1	.022 50V		MGP025	TA125		TG-S25
C2	.022 50V		MGP025	TA125		TG-S25
C3	.001 50V			GP210	QCT2-41	10TS-D10
C4	.022 50V		MGP025	TA125		TG-S25
C5A	.022 50V		MGP025	TA125		TG-S25
C5B	27 NPO 50V 10%			CN0427		10TCC-Q27
C6	.001 50V			GP210	QCT2-41	10TS-D10
C8	82 NPO 50V 5%		NP082	CN0482	QCT2-41	10TCC-Q82
C9	.001 50V			GP210		10TS-D10
C10	100		NP0100	CN0310		10TCC-T10
C11	.022 50V		MGP025	TA125		TG-S25
C12	.022 50V		MGP025	TA125		TG-S25
C14	.022 50V		MGP025	TA125		TG-S25
C18	.022 50V		MGP025	TA125		TG-S25
C20	.022 50V		MGP025	TA125		TG-S25
C21	5 NPO 50V		NP06P8	CN0568		10TCC-V68
C22	3 NPO 50V		NP03P3	CN0533		10TCC-V33
C23	3 NPO 50V		NP03P3	CN0533		10TCC-V33
C25	.047 50V 10%		DPMS2S47	EW1A147	QFT2-171	1FT-S47
C28	.1 50V 10%		WMF05P1	EW05010	QFT2-215	1FT-P10
C29	12 NPO 50V			CN0412		10TCC-Q12
C30	.001 50V			GP210	QCT2-41	10TS-D10
C31	.001 50V			GP210	QCT2-41	10TS-D10
C32	.001 50V			GP210	QCT2-41	10TS-D10
C33	.0047 50V		GP4700	GP247	QCT2-41	56A-D47
C34	.001 50V			GP210		10TS-D10
C35	.0047 50V		GP4700	GP247		56A-D47
C36	4 NPO 50V		NP04P7	CN0547		10TCC-V47
C37	.0047 50V		GP4700	GP247		56A-D47
C38	2 NPO 50V		NP02P2	CN0522		10TCC-V22
C39	.001 50V			GP210	QCT2-41	10TS-D10
C40	.001 50V			GP210	QCT2-41	10TS-D10
C41	.001 50V			GP210	QCT2-41	10TS-D10
C42	2 NPO		NP02P2	CN0522		10TCC-V22
C43	33 NPO 50V 10%		NP033	CN0433	QCC2-22	10TCC-Q33
C44	2 NPO		NP02P2	CN0522		10TCC-V22
C45	.022 50V		MGP025	TA125		TG-S25
C46	.022 50V		MGP025	TA125		TG-S25
C47	.022 50V		MGP025	TA125		TG-S25
C48	.01 50V			MAG5011		
C49	.022 50V		MGP025	TA125		TG-S25
C50	.022 50V		MGP025	TA125		TG-S25
C51	.022 50V		MGP025	TA125		TG-S25
C52	.022 50V		MGP025	TA125		TG-S25
C55	.022		DPMS2S22	M192P2239R8	QFT2-127	1FT-S22
C56	.022 50V		MGP025	TA125		TG-S25
C58	.001 10%		DPMS601	EW1A210	QFT2-1	1FT-D10
C60	.01			MAG5011		
C61	.1 50V 10%		WMF05P1	EW05010	QFT2-215	1FT-P10
C64	18 NPO 50V 10%			CN0418		10TCC-Q18
C65	10 NPO 50V		NP010	CN0410	QCC2-15	10TCC-Q10
C67	.01 50V			MAG5011		
C68	.022 50V		MGP025	TA125		TG-S25
C69	47 NPO 50V 10%		NP047	CN0447	QCC2-26	10TCC-Q47

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA			
			CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C70	47 NPO 50V 10%	CCRZ811215	NP047	CN0447	QCC2-26	10TCC-047
C71	.047 10%		DPMS2S47	EWFA1A147	QFT2-171	1FT-S47
C74	.01 50V			MAG5011		
C75	.01 50V			MAG5011		
C77	.01 50V			MAG5011		
C78	.01 50V			MAG5011		
C80	4 NPO 50V		NP04P7	CN0547		10TCC-V47
C81	270 N750 50V 10%			CN7327		10TCU-T27
C82	.0047 10%		WMF1D47	M192P4729R8	QFT2-63	1FT-D47
C85	.0033		WMF1D33	M192P3329R8	QFT2-43	1FT-D33
C86	.0068		WMF1D68	EWFA1A268	QFT2-73	1FT-D68
C87	.022 50V		MGP025	TA125		TG-S25
C88	.01 10%		WMF1S1	EWFA1A110	QFT2-91	1FT-S10
C89	.01 10%		WMF1S1	EWFA1A110	QFT2-91	1FT-S10
C91	.001		DPMS601	EWFA1A210	QFT2-1	1FT-D10
C93	.01 10%		WMF1S1	EWFA1A110	QFT2-91	1FT-S10
C94	.01 50V			MAG5011		
C95	.01 50V			MAG5011		
C98	.001 50V			GP210	QCT2-41	10TS-D10
C99	.01 50V			MAG5011		
C100	.01 50V			MAG5011		
C101	470 50V		GP470	GP347	QCT2-35	10TS-T47
C102	100 NPO 50V 10%		NP0100	CN0310		10TCC-T10
C103	.01 50V			MAG5011		
C104	18 NPO 50V 10%			CN0418		10TCC-Q18
C105	10 NPO 50V		NP010	CN0410	QCC2-15	10TCC-Q10
C106	.01 50V			MAG5011		
C110	.1 10%		WMF05P1	EWFO5010	QFT2-215	1FT-P10
C111	.022		DPMS2S22	M192P2239R8	QFT2-127	1FT-S22
C115	.001		DPMS601	EWFA1A210	QFT2-1	1FT-D10
C116	.1		WMF05P1	EWFO5010	QFT2-215	1FT-P10
C122	.01 50V			MAG5011		
C123	.01 50V			MAG5011		
C124	.01 50V			MAG5011		
C125	.01 50V			MAG5011		
C126	10 NPO 50V		NP010	CN0410	QCC2-15	10TCC-Q10
C127	220 50V			GP322		10TS-T22
C128	470 50V		GP470	GP347	QCT2-35	10TS-T47
C129	.01 50V			MAG5011		
C130	.01 50V			MAG5011		
C131	.01 50V			MAG5011		
C139	1 NPO 50V			CN0510		10TCC-V10
C140	10 NPO 50V		NP010	CN0410	QCC2-15	10TCC-Q10
C143	68 NPO 50V 5%		NP068	CN0468		10TCC-Q68
C144	39 NPO 50V 10%			CN0439		10TCC-Q39
C145	180 N750 50V 10%					10TCU-T18
C147	1 NPO 50V			CN0510		10TCC-V10
C148	390 N750 50V 10%					10TCU-T39
C149	330 N750 50V 10%		N330	CN7333		10TCU-T33
C150	.1		WMF05P1	EWFO5010	QFT2-215	1FT-P10
C151	470 N750 50V 10%					10TCU-T47
C152	.0047 50V		GP4700	GP247		5GA-D47
C153	.1 50V 10%		WMF05P1	EWFO5010	QFT2-215	1FT-P10
C154	.0047 50V		GP4700	GP247		5GA-D47
C155	.0047 50V		GP4700	GP247		5GA-D47
C156	.0047 50V		GP4700	GP247		5GA-D47
C157	.0047 50V		GP4700	GP247		5GA-D47
C158	47 NPO 50V 10%		NP047	CN0447	QCC2-26	10TCC-Q47
C159	330 N750 50V 5%		N330	CN7333		10TCU-T33
C160	2 NPO 50V		NP02P2	CN0522		10TCC-V22
C161	.01		WMF1S1	EWFA1A110	QFT2-91	1FT-S10
C163	120 N220 50V 10%					10TS-D10
C165	.001 50V			GP210	QCT2-41	TG-S25
C167	.022 50V			TA125		1FT-S47
C168	.047		DPMS2S47	EWFA1A147	QFT2-171	10TS-T10
C170	100 50V		GP100	GP310	QCT2-24	10TCC-Q56
C171	56 NPO 50V 10%			CN0456		10TS-D10
C172	.001 50V			GP210	QCT2-41	5GA-D47
C173	.0047 50V		GP4700	GP247		10TCU-T22
C174	220 N750 50V 10%		N220	CN7322		10TCC-Q33
C175	33 NPO 50V 10%		NP033	CN0433	QCC2-22	
C181	.01 50V			MAG5011		5GA-D47
C184	.0047 50V		GP4700	GP247		
C189	.01 50V			MAG5011		
C190	.047		DPMS2S47	EWFA1A147	QFT2-171	1FT-S47
C192	.001 50V			GP210	QCT2-41	10TS-D10
C195	47 NPO 50V 10%		NP047	CN0447	QCC2-26	10TCC-Q47
C196	.0047		GP4700	GP247		5GA-D47
C197	.0047		WMF1D47	M192P4729R8	QFT2-63	1FT-D47
C202	.0047 50V		GP4700	GP247		5GA-D47
C203	.0047 50V		GP4700	GP247		5GA-D47
C204	.0047 50V		GP4700	GP247		5GA-D47
C206	.022 50V		MGP025	TA125		TG-S25
C207	.1 50V			MAG5001		
C208	.022 50V		MGP025	TA125		TG-S25
C212	.01			MAG5011		
C214	.047 10%		DPMS2S47	EWFA1A147	QFT2-171	1FT-S47
C216	.0047		GP4700	GP247		5GA-D47
C220	330 50V		GP330	GP333	QCT2-33	10TS-T33

TEABERRY MODEL Stalker XV

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

CAPACITORS (cont)

ITEM No.	RATING	MFR. PART No.	REPLACEMENT DATA			
			CORNELL-DUBILIER PART No.	MALLORY PART No.	SPRAGUE PART No.	
					Q-LINE	GENERAL LINE
C221	330 50V		GP330	GP333	QCT2-33	10TS-T33
C222	10 NPO		NP010	CN0410	QCC2-15	10TCC-Q10
C301	.039 50V 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C303	.039 50V 10%		DPMS6S39	M192P3939R8	QFT2-159	1FT-S39
C310	.047 10%		DPMS2S47	EWFA1A147	QFT2-171	1FT-S47
C401	.0047 50V		GP4700	GP247		5GA-D47
C402	.0047 50V		GP4700	GP247		5GA-D47
C403	.001 50V			GP210	QCT2-41	10TS-D10
C404	.001 50V			GP210	QCT2-41	10TS-D10
C405	.001 50V			GP210	QCT2-41	10TS-D10
C406	.001 50V			GP210	QCT2-41	10TS-D10
C407	.001 50V			GP210	QCT2-41	10TS-D10
C408	.0047 50V		GP4700	GP247		5GA-D47
C409	.0047 50V		GP4700	GP247		5GA-D47
C410	.0047 50V		GP4700	GP247		5GA-D47
C411	.0047 50V		GP4700	GP247		5GA-D47
C412	.01 50V			MAG5011		
C413	.01 50V			MAG5011		
C414	.1 50V			MAG5001		
C416	.01 50V			MAG5011		
C417	.001 50V			GP210	QCT2-41	10TS-D10
C420	.0033 50V		GP3300	GP233	QC2-107	5GA-D33
C421	.0047 50V		GP4700	GP247		5GA-D47
C422	.001 125V			GP210	QCT2-41	10TS-D10
C423	.001 125V			GP210	QCT2-41	10TS-D10
C424	.001 125V			GP210	QCT2-41	10TS-D10
C425	.001 125V			GP210	QCT2-41	10TS-D10
CC1		HHAY003001				
CT1	20	CCVY028004				
CT2	20	CCVY028004				
CT3	20	CCVY028004				

CONTROLS (All wattages 1/2 watt, or less, unless listed)

ITEM No.	FUNCTION	RESISTANCE	REPLACEMENT DATA		
			MFR. PART No.	MALLORY PART No.	TRW PART No.
RT301	Voltage	300	RRVY146002	MTC32L1	X201R351B
VR1	SIG Meter	10K	RRVY189005	RVA0911H103	U260R103B
VR2	Squelch Range	1000	RRVY189003	RVA0911H102	U260R102B
VR3	XMT Freq.	3000	RRVY189004	RVA0911H502	U260R502B
VR5	Carrier Balance	10K	RRVY189005	RVA0911H103	U260R103B
VR6	AM Power	5000	RRVY189010	RVA0911H502	U260R502B
VR7	RF ALC	10K	RRVY189005	RVA0911H103	U260R103B
VR8	RF Driver Bias	500	RRVY189002	RVA0911H501	U260R501B
VR9	RF Final Bias	5000	RRVY189010	RVA0911H502	U260R502B
VR10	TX Power Meter	100K	RRVY189008	RVA0911H104	U260R104B
VR12	MOD	100K	RRVY189008	RVA0911H104	U260R104B
VR401	Squelch	100K	RRVY126001		
VR402	Clarifier	20K	RRVY139001		
VR403	Volume/Power Switch	10K	RRVY008001		
VR404	RF Gain	10K	RRVY324001		
VR405	Mic Gain	10K	RRVY036001		

RESISTORS (Power and Special)

ITEM No.	RATING	REPLACEMENT DATA		ITEM No.	RATING	REPLACEMENT DATA	
		MFR. PART No.	WORKMAN PART No.			MFR. PART No.	WORKMAN PART No.
R306	150 Ohm 2W Flame-proof 10%	RSJZ201515	22-4076	R426	3.9 Ohm 5W 10%	RXJZ503995	

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

COILS (RF-IF)

ITEM No.	FUNCTION	REPLACEMENT DATA			REMARKS
		PART No.	OTHER IDENTIFICATION	MILLER PART No.	
L1	Noise Blanker	LLAY038001		CBS512-7TC	
L2	Noise Blanker	LLAY179001			
L3	IF Amp (7.8MHz)	LLAY255001			
L4	IF Amp (7.8MHz)	LLAY263001			
L5	Mixer (7.8MHz)	LLAY262001			
L6	Mixer (7.8MHz)	LLAY257001			
L7	Mixer (7.8MHz)	LLAY258001			
L8	RF Amp (27MHz)	LLAY259001			
L9	RF Amp (27MHz)	LLAY260001			
L10	Receive Antenna (27MHz)	LLAY261001			
L11	RF Choke (470uH)	LLZY012004			
L12	Mixer (100uH)	LLZY012001			
L13	VCO/Mixer	LLAY216001			
L14	VCO/Mixer (34MHz)	LLAY195001			
L15	RF Choke (470uH)	LLZY012004			
L16	RF Choke (470uH)	LLZY012004			
L17	Carrier Shift (7.8000MHz)	LLAY217001			
L18	Tripler (33MHz)	LLAY256001			
L19	Oscillator (34.9825MHz)	LLAY217001			
L20	Oscillator (34.9850MHz)	LLAY218001			
L21	RF Choke (470uH)	LLZY012004			
L22	RF Choke (470uH)	LLZY012004			
L23	RF Choke (470uH)	LLZY012004			
L24	RF Choke (470uH)	LLZY012004			
L25	RF Choke (100uH)	LLZY012001			
L26	XMT Mixer (7.8MHz)	LLAY219001			
L27	VCO/Mixer (35MHz)	LLAY160001			
L28	XMT Mixer (27MHz)	LLAY220001			
L29	XMT Mixer (27MHz)	LLAY254001			
L30	XMT Predriver	LLDY096001			
L33	RF Choke	LLDY098001			
L35	RF Choke	LLDY098001			
L36	Final (27MHz)	LLCY019001		CB305	
L37	Pi Filter	LLEY051001			
L38	Antenna Matching	LLEY051001			
L39	TVI Trap (54MHz) Min	LLCY019001		CB305	
L401	RF Choke	LLDY013001			
L402	RF Choke	LLDY013001			
L403	RF Choke	LLDY089001			
L406	RF Choke	LLDY089001			
L407	RF Choke	LLDY089001			
L408	RF Choke	LLDY089001			
L409	RF Choke	LLDY027001			
L410	RF Choke	LLDY027001			

TEABERRY MODEL Stalker XV

TRANSFORMER (Power)

ITEM No.	RATING		REPLACEMENT DATA			NOTES
	PRI.	SEC. 1	MFGR. PART No.	THORDARSON PART No.	TRIAD PART No.	
T401	120V AC @ 1A AC	17.40V AC @ 3.78A AC	TTFY143001			

SPEAKER

ITEM No.	TYPE	REPLACEMENT DATA		NOTES
		MFGR. PART No.	QUAM PART No.	
SP401	3 1/2" PM, 8 Ohms	ASPY060001	3A05Z8	

PARTS LIST AND DESCRIPTION (CONTINUED)

(When ordering parts, state Model, Part Number, and Description.)

FUSE DEVICES

ITEM No.	DESCRIPTION	REPLACEMENT DATA						
		PART No.		BUSS PART No.		LITTELFUSE PART No.		WORKMAN PART No.
		DEVICE	HOLDER	DEVICE	HOLDER	DEVICE	HOLDER	DEVICE
F401	4A Quick-acting	FS-012	FH-002	AGC4	HRK	311004	150145	
F402	4A Quick-acting	FS-012		AGC4	HKP	311004	442006	

MISCELLANEOUS

ITEM No.	PART NAME	PART No.	NOTES
D401	LED	DDAY078001	Channel Display (TLR321) Tens, Units (1.99V @ 5.8mA each segment)
D402	LED	DDAY007001	XMT (TLR104)(Red)(2.00V @ 15mA)
D405	LED	DDAY032001	Receive (TLG103)(Green)(2.07V @ 15mA)
D410	LED	DDAY100001	AM (Red)(2.00V @ 14.1mA) TLR124
D411	LED	DDAY100001	USB (Red)(2.00V @ 14.1mA) TLR124
D412	LED	DDAY100001	LSB (Red)(2.00V @ 14.1mA) TLR124
FT1	Filter	FFLY065001	7.8MHz (FL-065) Crystal
FT2	Filter	FFLY046001	7.8MHz (FL-046) Crystal
J401	Jack	JJKY010001	PA Speaker (JK-010)
J402	Jack	JJKY010001	External Speaker (JK-010)
J403	Jack	JJKY052001	DC Power (JK-052)
J404	Jack	JJKY107001	Mic (JK-107)
J405	Jack	JJKY068001	Antenna (M-Type)(JK-068)
J406	Jack	JJKY005002	Phone (JK-005)
L31	Ferrite Bead	LLDY087001	LD-087
L32	Ferrite Bead	LLDY101001	LD-101
L34	Ferrite Bead	LLDY087001	LD-087
L50	Ferrite Bead	LLDY077001	LD-077
L51	Ferrite Bead	LLDY077001	LD-077
L52	Ferrite Bead	LLDY077001	LD-077
L404	Ferrite Bead	LLDY077001	LD-077
L405	Ferrite Bead	LLDY077001	LD-077
M401	Meter	ZMTY135001	Signal/XMT Power (MT-135)
M402	Motor		Clock (Part of Clock Assembly)
PL401	Lamp	VPLY065011	Meter (10.39V @ 32mA AC) (PL-065)
PL402	Lamp		Part of Clock (7.16V @ 70mA AC)
P403	Plug		DC Power (Part of DC Power Cord)
P404	Plug		Mic (Part of Microphone)
S401	Switch	SSRY208001	Channel Selector, Rotary SR-208
S402	Switch		Power (Part of VR403)
S403	Switch	SSRY205001	AM/USB/CSB, Rotary SR-205
S404	Switch	SSWY144001	Squelch (CB/PA) Push SW-144
S405	Switch	SSWY144001	NB/ANL (On/Off) Push SW-144
S408	Switch	SSWY144001	S/R/MOD Push SW-144
S409	Switch	SSWY099001	AC/DC Slide, SW-099
X1	Crystal	QQXY077001	10.240MHz, QX-077
X2	Crystal	QQXY084001	7.8025MHz, QX-084
X3	Crystal	QQXY083001	7.7975MHz, QX-083
X4	Crystal	QQXY098001	11.1125MHz, QX-098
	Clock	ZCKY007001	Digital, CK-007
	Cord	WMZY022001	AC Power, WZ-022
	Cord	WZDZ070273	DC Power, W-070273
	Microphone	AMKY108001	MK-108
	P.C. Board	PPCY460011	Channel LED, PC-460AA
	P.C. Board	PPCY395001	Channel Switch, PC-395AA
	P.C. Board	PPCY372011	Filter, PC-372AA
	P.C. Board	PPCY385014	Main, PC-385AD
	P.C. Board	PPCY459011	Mic, PC-459AA
	P.C. Board	PPCY461011	Phone, PC-461AA
	P.C. Board	PPCY457011	Push Switch, PC-457AA
	P.C. Board	PPCY006052	Power Supply, PC-006EB
	P.C. Board	PPCY401011	Speaker Jack, PC-401AA
	P.C. Board	PPCY458011	Mode LED, PC-458AA

CABINETS & CABINET PARTS (When ordering specify model, chassis & color)

ITEM	PART No.	ITEM	PART No.
Cover, Bottom	MDBP204592	Knob	MDMP406543
Cover, Top	MDBP204583	Knob	MDMP402181
Filter, Optical, Channel Display	MDAP404595	Knob, Channel	MDMP406425
Foot (Black)	MZTT010002	Panel, Front	MDMP104577
Foot (Black)	MZTT010004	Panel, Rear	MDBP20608A
Knob	MDMP406545	Plate, Decoration	MDAP406550
Knob	MDMP406544	Button (Push)	MDMP404046